

The Transformation of Repurposed Copper: Traditional Coppersmithing, Metallurgy, and Urban Sourcing in Berlin

The revitalization of traditional coppersmithing within modern urban environments represents a sophisticated intersection of historical metallurgical techniques and contemporary circular economy principles. For the independent artisan or hobbyist operating in a metropolis like Berlin, Germany, the procurement of raw materials has shifted from relying solely on primary industrial suppliers to the strategic harvesting of urban infrastructure—specifically, discarded electrical wiring and scrap plumbing pipes. This paradigm shift requires an exhaustive understanding of physical metallurgy, thermodynamic processing, and the stringent legal and environmental frameworks governing waste recovery.

Transforming a cylindrical, work-hardened plumbing pipe or a bundle of stranded electrical wire into a pristine, cold-rolled copper sheet suitable for deep drawing or repoussé involves a multi-stage metallurgical lifecycle. The material must be legally sourced, mechanically extracted, thermally annealed to eliminate prior work-hardening, systematically flattened, cold-rolled to the desired gauge, and chemically pickled to remove complex oxidation layers. Each phase is governed by strict crystallographic constraints. Furthermore, working with scavenged materials introduces unpredictable variables, including trace alloy contaminants that can induce catastrophic material failures such as liquid metal embrittlement. The following analysis provides an expert-level examination of the entire coppersmithing lifecycle from an urban scavenging perspective, detailing the mechanical, chemical, and traditional processing methodologies required to optimize repurposed copper.

Part I: The Regulatory and Commercial Landscape in Berlin

The extraction of copper from urban waste streams in Germany is heavily regulated to prevent environmental contamination and ensure the safe processing of hazardous by-products. Artisans sourcing materials in Berlin must navigate a complex legal framework governing electronic waste and construction scrap.

The Legal Framework: KrWG, ElektroG, and StGB

The foundation of waste management and recycling in Germany is the Circular Economy Act (*Kreislaufwirtschaftsgesetz*, KrWG), which mandates the prioritization of waste avoidance, preparation for reuse, and recycling over disposal¹. Under the KrWG, discarded copper pipes from plumbing renovations and stripped wiring from electrical upgrades are classified as valuable secondary raw materials¹.

For electrical wiring, the Electrical and Electronic Equipment Act (*Elektro- und Elektronikgerätegesetz*, ElektroG) imposes strict guidelines¹. Electrical cables are legally classified as electronic waste, meaning they must not be disposed of in standard household

trash¹. The ElektroG requires manufacturers, large retailers, and online platforms to provide free take-back systems for end-of-life electronic equipment¹.

A critical legal boundary for the urban scavenger involves the extraction of the copper core from its polymer insulation. Historically, illicit scrap gatherers utilized open-air burning to incinerate PVC or cross-linked polyethylene insulation, leaving behind bare copper wire. In Germany, this practice constitutes a severe criminal offense under Section 326 of the German Criminal Code (*Strafgesetzbuch*, § 326 StGB), which criminalizes the unauthorized handling, storage, and thermal destruction of hazardous waste⁵. The combustion of cable insulation releases highly toxic dioxins, furans, and hydrogen chloride gas, posing severe ecological and public health hazards⁷. Therefore, extraction must be performed purely mechanically, utilizing manual cable strippers, granulators, or precision slitting tools.

Sourcing via BSR and Commercial Scrap Trade

In Berlin, the municipal waste management entity, *Berliner Stadtreinigung* (BSR), operates numerous recycling centers (*Recyclinghöfe*) that accept consumer e-waste and scrap metal⁸. While removing material directly from BSR collection bins is prohibited, artisans frequently source materials legally through direct arrangements with local plumbers, demolition contractors, or by purchasing from commercial scrap metal dealers (*Schrotthandel*) operating in districts like Kreuzberg and Reinickendorf⁹.

Commercial scrap dealers categorize copper based on purity and source, which directly dictates its market value and metallurgical utility⁹. These local prices are dynamically hedged against the London Metal Exchange (LME), which dictates global baseline valuations in metric tonnes⁹.

Scrap Classification	Description	Local Purchasing Estimate (€/kg)	Metallurgical Utility
Kupfer Millberry	Bare, bright, unalloyed copper wire; free of insulation, ash, and oxidation ¹⁰ .	~9.70	Optimal for melting or direct forging due to near 99.9% purity ⁹ .
Kupfer Rohre (Clean)	Clean plumbing tubing containing minimal oxidation or residue ⁹ .	~9.50	Excellent for cold-rolling; requires annealing and flattening.
Kupfer Rohre mit Anhaftungen	Pipes bearing residues of lead-tin solder, paint, or insulation ⁹ .	~9.50	High risk of liquid metal embrittlement; requires aggressive

			mechanical cleaning ¹³ .
Kupfer Kabel (Thick)	Insulated copper cables requiring mechanical stripping ⁹ .	~3.40	Labor-intensive extraction, but yields high-purity Cu-ETP ⁹ .

Part II: Metallurgical Profiling of Scavenged Copper

Copper is not a monolithic material; its trace elemental composition is highly tailored to its intended industrial application. The artisan must recognize that electrical wiring and plumbing pipes represent two distinct grades of copper, each reacting differently to extreme heat, cold rolling, and welding.

Cu-ETP (Electrolytic Tough Pitch) - Electrical Wiring

Electrical wiring is almost exclusively manufactured from Electrolytic Tough Pitch copper, designated internationally as Cu-ETP, C11000, or CW004A¹⁵.

Cu-ETP is refined electrolytically to achieve a minimum copper purity of 99.90% (including trace silver), maximizing its electrical and thermal conductivity to 100% IACS¹⁵. However, the defining metallurgical characteristic of Cu-ETP is its controlled oxygen content, which typically ranges

from 0.02% to 0.04% (200 to 400 ppm), present primarily as cuprous oxide (Cu_2O) inclusions¹⁶. The oxygen is intentionally introduced during the refining process to scavenge impurities (such as bismuth, antimony, and iron) by oxidizing them, thereby removing them from the solid solution matrix where they would otherwise scatter electrons and severely degrade conductivity¹⁵.

While highly conductive and ductile at room temperature, Cu-ETP possesses a fatal flaw for the traditional coppersmith: it is highly susceptible to hydrogen embrittlement¹⁵. If Cu-ETP is heated above 370°C in a reducing atmosphere—such as the carbon-rich core of a traditional solid-fuel forge—hydrogen atoms effortlessly diffuse into the copper lattice. These interstitial hydrogen atoms react violently with the internal cuprous oxide inclusions according to the reaction:



The resulting water vapor cannot diffuse out of the dense metal matrix. Instead, it generates localized internal steam pressures that exceed the tensile strength of the copper at elevated temperatures, leading to microscopic intergranular fissures, severe blistering, and the catastrophic structural disintegration of the metal¹⁵. Therefore, Cu-ETP electrical wire must only be annealed in neutral or oxidizing atmospheres.

Cu-DHP (Deoxidized High Phosphorus) - Plumbing Pipes

Scrap plumbing pipes, manufactured to standards such as EN 1057 or ASTM B88, are

composed of Deoxidized High Phosphorus copper, designated as Cu-DHP, C12200, or CW024A²¹.

Unlike wiring, plumbing infrastructure requires extensive brazing, soldering, and localized heating during installation. To render the copper immune to hydrogen embrittlement, manufacturers remove the oxygen by introducing phosphorus into the melt. Cu-DHP contains a minimum of 99.90% copper and a residual phosphorus content between 0.015% and 0.040%²¹. The phosphorus acts as a highly effective deoxidizer, leaving the metal with virtually zero free oxygen (less than 0.001%)²¹.

Because it lacks internal Cu_2O inclusions, Cu-DHP can be aggressively heated, forged, and welded in reducing atmospheres without fear of steam-induced embrittlement¹⁸. It exhibits excellent ductility, making it the superior candidate for cold-rolling into sheet metal. However, the residual phosphorus significantly reduces its electrical conductivity (down to ~70% IACS), rendering it unsuitable for precision electrical applications²¹.

Property Specification	Cu-ETP (Electrical Wiring)	Cu-DHP (Plumbing Pipes)
UNS Designation	C11000	C12200
EN Designation	CW004A	CW024A (EN 1057)
Copper Content	$\geq$	$\geq$
Oxygen Content	0.02% —	$<$
Phosphorus Content	None	0.015% —
Hydrogen Embrittlement	Highly Susceptible (>370°C) ¹⁵	Immune ¹⁹
Tensile Strength (Annealed)	220 – 275 MPa ¹⁵	220 – 270 MPa ²¹

Impurity Mechanics: Liquid Metal Embrittlement and Hot Shortness

When repurposing scrap, the artisan inevitably encounters localized contamination. Solder joints on plumbing pipes frequently contain tin (Sn), lead (Pb), and occasionally bismuth (Bi). Exposure to trace amounts of lead or bismuth induces severe high-temperature degradation known as Liquid Metal Embrittlement (LME) and hot shortness¹⁴. Lead and bismuth are practically insoluble in the solid copper matrix. Instead, they segregate to

the grain boundaries as discrete, microscopic inclusions¹⁴. The spatial morphology of these lead inclusions is governed by the dihedral angle, representing the thermodynamic balance between the solid-solid grain boundary energy and the solid-liquid interfacial energy¹⁴. At elevated temperatures (specifically around 400°C, near the melting point of lead), these inclusions liquefy.

If the solid copper is subjected to stress (such as forging or bending) while the lead is liquid, the liquid lead exhibits perfect wetting behavior, aggressively penetrating the copper grain boundaries²⁷. The rapid penetration destroys intergranular cohesion, causing the solid copper to spontaneously fracture and crumble with practically zero plastic deformation—a phenomenon known as hot shortness¹³. Furthermore, sulfur contamination (e.g., from degraded rubber insulation) similarly segregates to grain boundaries, forming brittle copper sulfide precipitates that drastically lower ductility and cause intermediate-temperature embrittlement between 450°C and 600°C³⁰.

Consequently, all soldered joints, oxidized paint, and unknown accretions must be physically excised from the scrap pipe using a hacksaw prior to any thermal processing.

Part III: Traditional Solid-Fuel Forge Architecture

To transform a rigid, cylindrical Cu-DHP pipe into a flat sheet, the artisan must first slit the pipe longitudinally and unfold it³². Because the pipe was heavily work-hardened during its original industrial extrusion, it retains high residual stresses and a rigid crystalline lattice. Forcing the pipe flat at room temperature will likely induce longitudinal stress fractures. The material must first be thermally annealed³². For the traditional coppersmith, this requires the construction of a solid-fuel forge capable of reaching temperatures between 600°C and 800°C.

The JABOD Side-Blast Charcoal Forge

For urban hobbyists seeking an efficient forge architecture that requires virtually no metal fabrication, the side-blast trench forge—commonly referred to as the JABOD (Just A Box Of Dirt)—presents a historically accurate and highly capable alternative³³. Derived from ancient African and Asian smelting traditions, the side-blast forge completely eliminates complex bottom plumbing manifolds in favor of a horizontal tuyere (air pipe) entering the fire bed directly from the side³³.

The structural housing consists of a simple wooden box, optimally 24 by 24 inches square with a depth of 7 to 9 inches³³. The box is filled to the brim with a tightly tamped matrix of non-combustible earthen materials, ideally a mixture of heavy clay, loamy soil, and wood ash³³. The builder excavates a trench-like depression into the center of the dirt matrix, roughly 4 inches wide, 8 inches long, and 4 inches deep, with gently sloped sides to encourage the fuel to gravity-feed into the center³³.

A horizontal tuyere (typically a 3/4-inch to 1-inch inside diameter black iron pipe) is driven through the wooden wall and dirt matrix until it terminates flush with the side wall of the trench³³. Crucially, the tuyere must enter the trench 1 to 2 inches above the absolute bottom floor of the depression³³. This empty space below the air blast serves as the catch-basin for molten slag and ash, ensuring the air pipe remains unobstructed. The JABOD utilizes a sacrificial tuyere

mechanism; the exposed tip of the pipe slowly oxidizes and burns away over hours of use. When the pipe degrades, the smith simply hacksaws off the ruined inch and advances the pipe forward through the dirt³³.

This design is uniquely optimized for lump charcoal. Charcoal is roughly one-tenth the density of bituminous coal; it is highly porous, burns rapidly, and requires a shallow, wide fire bed³⁴. Crucially, a deep charcoal fire generates a heavily reducing atmosphere (rich in carbon monoxide), which actively scavenges oxygen from the metal surface, minimizing scale formation on Cu-DHP³³.

The Bottom-Blast Brake Drum Coal Forge

For smiths utilizing bituminous (soft) coal, the bottom-blast forge is the optimal configuration. In this architectural design, air is forced vertically upward through a grate at the base of a conical firepot, creating a deep, highly concentrated heat core. The most durable method for constructing a hobbyist bottom-blast forge involves repurposing an automotive cast-iron brake drum (ideally 8 to 10 inches in diameter and 3 to 4 inches deep)³³.

A 2-inch black iron floor flange is bolted to the bottom of the drum over the central hub hole³³. A plumbing manifold is assembled using a vertical drop pipe and a T-connector, separating the incoming horizontal forced air from a gravity-fed vertical ash dump³³. A robust grate, typically a 1/4-inch steel plate drilled with a cloverleaf pattern or a cast-iron floor drain, is installed inside the drum over the air inlet to diffuse the blast and support the coal bed³³. Under no circumstances should galvanized steel be utilized in any part of the forge construction, as temperatures exceeding 400°C rapidly vaporize the zinc coating, producing highly toxic zinc oxide fumes capable of causing severe metal fume fever³³.

When fresh bituminous coal is banked around the perimeter of the firepot, destructive distillation drives off moisture and volatile gases, leaving behind porous, lightweight coke³³. The air blast creates distinct chemical zones within the fuel bed:

1. **Oxidizing Zone:** Located at the absolute bottom near the air inlet. Oxygen is highly abundant; copper placed here will rapidly scale and burn³³.
2. **Neutral Zone:** Located approximately 4 inches above the air inlet where all free oxygen has been consumed, creating the ideal heating environment³³.
3. **Reducing Zone:** The uppermost zone dominated by unburned carbon monoxide, which traps radiant heat and prevents atmospheric oxidation³³.

Refractory Engineering and Quartz Inversion

To protect the forge walls and concentrate thermal energy, the firepot must be lined with a refractory material. A pervasive error in DIY forge construction is the utilization of Plaster of Paris or standard Portland cement, which fail catastrophically under forging temperatures due to bound water turning to steam and severe thermal shock³³. Furthermore, any refractory utilizing silica sand is subject to a violent crystallographic phenomenon known as quartz inversion³³. At precisely 573°C, the crystalline structure of silica undergoes a sudden, reversible phase transition from alpha-quartz to beta-quartz, accompanied by an immediate volumetric expansion of approximately 2%³³. In a rigid matrix like concrete, this rapid expansion shears internal bonds, causing the lining to crumble into dust³³.

Historical blacksmiths developed a composite refractory lining to survive this extreme heat. The traditional recipe relies on a volumetric ratio of approximately 60% high-silica sand (or pre-fired grog), 30% fireclay, and 10% organic temper (historically, finely chopped straw or equine manure)³³. The mixture is applied to the forge walls and cured slowly over several days. During the initial firing, the organic cellulose fibers from the horse manure incinerate, achieving "carbon burn-out"³³. This leaves behind a network of microscopic voids throughout the fired clay. These voids act as physical expansion chambers, absorbing the 2% volumetric shift of the quartz inversion while drastically reducing the thermal conductivity of the lining, transforming it into a highly efficient insulator³³.

Pneumatic Propulsion Systems

While modern smiths frequently utilize electric blowers (such as repurposed bathroom exhaust fans or hair dryers controlled by rheostats), traditional manual bellows provide volumetric, highly controllable airflow that scales perfectly with the physical effort of the smith³³.

The Double-Lung Accordion Bellows: To rectify the pulsing airflow of primitive single-chamber bellows, medieval engineers developed the double-lung bellows, a three-chambered device constructed from rigid wooden boards and flexible leather walls³³. The middle board serves as the stationary structural spine and contains upward-opening one-way flapper valves connecting the lower intake chamber to the upper exhaust chamber³³. As the lower lung is pumped, it inflates the upper lung, which is heavily weighted to provide a constant, uninterrupted downward pressure, delivering a steady blast of air through the nozzle³³. The leather walls are traditionally sealed and waterproofed using a heated compound of 2 parts beeswax to 1 part rendered beef tallow and neatsfoot oil³³.

The Asian Fuigo (Box Bellows): An alternative, highly efficient design is the Japanese fuigo, which utilizes a rigid, double-acting wooden piston moving horizontally within a sealed box³³. The piston edges are traditionally sealed with badger fur, raccoon fur, or folded washi paper³³. The fuigo achieves a continuous air blast on both the push and the pull stroke through a brilliant orchestration of four precisely calibrated wooden flap valves (*ben*) and a secondary internal air channel (*plenum*)³³. The wooden flaps are planed into a specific wedge shape—thick at the base to snap shut under pressure, and thin at the top to swing open easily, hung using linen string hinges rather than metal hardware³³.

Part IV: Annealing Dynamics and Mechanical

Flattening

As the copper pipe or electrical wire is heated in the forge to a dull red luminescence (approximately 600°C), it undergoes dynamic structural changes³².

Oxidation Kinetics

Heating copper in an ambient atmosphere initiates rapid thermal oxidation, following a parabolic rate law³⁶. This indicates a diffusion-controlled mechanism where the thickening oxide layer acts as a barrier, gradually slowing the reaction rate. The oxidation scale forms as a bipartite structure:

1. **Cuprous Oxide** (Cu_2O): The primary, inner layer adjacent to the raw metal. It grows predominantly via the outward lattice diffusion of copper cations (Cu^{+}) migrating through vacancies in the Cu_2O structure³⁶.
2. **Cupric Oxide** (CuO): The secondary, outer layer that forms at the boundary between the Cu_2O and the atmosphere, typically requiring higher temperatures (exceeding 300°C) and prolonged exposure³⁷.

Once the copper reaches annealing temperature, the rigid, elongated grains formed during previous cold-working undergo complete dynamic recrystallization²⁶. The metal nucleates into new, equiaxed, stress-free grains, dramatically lowering the yield strength and restoring maximum ductility²⁶. The metal is then removed from the forge and quenched in ambient water. Quenching offers the added benefit of mechanically shocking the brittle oxide scale, causing significant portions of the black CuO to spall off via differential thermal contraction²⁷.

Mechanical Flattening Techniques

Following annealing, the copper pipe or wire must be flattened prior to cold-rolling. For thin strips or wire, flattening must be executed gently to prevent premature work-hardening.

Industrial shears or snips can induce burrs and curl the edges of the metal⁴¹.

Artisans employ several traditional and improvised methods to achieve absolute flatness:

- **Manual Manipulation:** Striking the metal directly with a hardened steel hammer will introduce unwanted localized work-hardening and mar the surface. Instead, the material is gently tapped using a rawhide, nylon, or wooden mallet against a smooth anvil or a wooden stump⁴¹.
- **Spoon and Vice Methods:** For thin, foil-like strips, the rolling squeeze of two serving spoons can overcome minor springback without altering the material's thickness⁴¹. Alternatively, the copper can be clamped tightly in a bench vice between two perfectly smooth, flat blocks of wood or 1/8-inch thick steel plates⁴¹.
- **Thermal Clamping:** For severe warping, the copper sheet can be tightly gripped between two heavy steel plates using steel G-clamps. The entire steel-copper sandwich is then heated with a torch until the steel glows a dull red, effectively re-annealing the copper while mechanically forcing it perfectly flat⁴³.

Part V: Cold-Rolling Mechanics and Strain Hardening

Once flattened, the rough copper sheet is processed through a cold-rolling mill to achieve uniform thickness, precise surface finish, and the desired mechanical temper.

Rolling Mill Operations and Pass Schedules

Cold rolling is executed by passing the copper through a set of highly polished, hardened steel cylindrical rolls (typically in a 2-Hi stand configuration)⁴⁴. As the sheet is drawn through the roll gap, it undergoes severe compressive plastic deformation. Because the volume of the metal

remains constant, the reduction in thickness is proportionally translated into an elongation of the sheet in the direction of rolling, with minimal lateral spreading⁴⁵.

The operation requires a precise pass reduction schedule. Copper cannot be reduced from its original thickness to a foil-like gauge in a single pass⁴⁶. Excessive reduction ratios generate immense rolling forces that deform the mill rolls, induce severe friction, and cause the material to fracture. Annealed Cu-DHP allows for aggressive initial reductions, often between 25% and 35% reduction in cross-sectional area per pass⁴⁷. As the material thins and hardens, subsequent passes must be reduced to 15% - 20% to prevent edge cracking⁴⁷.

Typical Cold-Rolling Pass Schedule for Cu-DHP	Entry Thickness	Exit Thickness	Reduction Percentage	Material Condition / Rolling Force
Pass 1 (Initial)	1.50 mm	1.05 mm	30.0%	Readily yields; high plasticity; low force ⁴⁷ .
Pass 2 (Intermediate)	1.05 mm	0.80 mm	23.8%	Noticeable hardening; increased torque required ⁴⁷ .
Pass 3 (Finishing)	0.80 mm	0.65 mm	18.7%	Severely work-hardened ; high dislocation density ⁴⁶ .

During heavy cold rolling, the equiaxed grains of the annealed copper are mechanically crushed and elongated in the rolling direction, developing a pronounced crystallographic texture⁴⁶.

Intensive shear forces activate multiple slip systems within the Face-Centered Cubic (FCC)

lattice, leading to the proliferation of low-angle sub-grain boundaries and $\Sigma 3$ -type deformation twins⁴⁶. This microstructural evolution directly dictates the macroscopic strengthening of the material, alongside introducing planar anisotropy in the elastic and strength properties across the sheet⁴⁹.

Strain Hardening: The Hollomon Power Law

The fundamental physics governing the stiffening of the copper sheet during rolling is described by strain hardening (or work hardening). As plastic deformation forces crystallographic planes to

slide past one another, dislocations within the atomic lattice multiply exponentially and entangle³⁵. These entangled dislocations act as physical barriers to further slip, requiring significantly higher forces to continue deforming the metal⁴⁸.

This behavior is mathematically quantified by the Hollomon Equation³⁵:

$$\sigma = K \cdot \varepsilon^n$$

Where σ is the true applied flow stress in MPa, K is the strength coefficient, ε is the true plastic strain, and n is the strain hardening exponent³⁵.

Fully annealed pure copper possesses an exceptionally high strain hardening exponent, typically between 0.44 and 0.54³⁵. This indicates vast reserves of ductility, allowing for profound deep-drawing before ductile fracture occurs⁵¹. However, it also dictates that the yield strength escalates violently during the initial rolling passes. For instance, the yield strength of annealed Cu-DHP sits at a highly malleable 60 - 90 MPa²¹. After cold-rolling to a hard temper, the yield strength spikes to over 250 MPa, and the ultimate tensile strength approaches 350 MPa²³.

Springback and Dimensional Recovery

As the rolled copper sheet is subsequently bent or formed by the coppersmith, it undergoes both plastic (permanent) and elastic (temporary) deformation⁵². Upon release of the bending force, the elastic stresses within the metal lattice relax, causing the material to partially return toward its original geometry—a phenomenon known as springback⁵².

The magnitude of springback ($\Delta\alpha$) is directly proportional to the material's yield strength (σ_y) and inversely proportional to its Young's modulus of elasticity (E)⁵². It is estimated using the relationship:

$$\Delta\alpha \approx \left(\frac{\sigma_y \cdot t}{E \cdot R} \right) \times K$$

Where t is sheet thickness, R is bend radius, and K is a geometric process coefficient⁵⁴.

Because cold rolling dramatically increases the yield strength while the elastic modulus ($E \approx 120$

GPa for copper) remains constant, a work-hardened copper sheet will exhibit significantly greater springback than a fully annealed sheet⁵¹. For a tight bend (where the inside radius equals the material thickness), annealed copper exhibits negligible springback (0.0° to 0.5°), whereas work-hardened metals can spring back by several degrees⁵⁴. To achieve precise dimensional tolerance, the coppersmith must either calculate and apply "overbending" to compensate for the elastic recovery, or execute an intermediate annealing cycle to reset the

yield strength prior to final forming⁵².

Part VI: Chemical Pickling and Surface Restoration

Following thermal annealing, the copper sheet is invariably coated with a tenacious, abrasive layer of black cupric oxide and red cuprous oxide³⁷. Attempting to cold-roll a heavily oxidized sheet will drive the brittle oxide shards deep into the pure copper matrix, destroying the surface finish and potentially scoring the hardened steel rolls of the mill. The scale must be dissolved chemically through a process known as pickling⁵⁷.

Traditional vs. Eco-Conscious Pickling Kinetics

The pickling of copper relies on dilute acids capable of protonating and dissolving metal oxides without aggressively attacking the underlying pure copper substrate⁵⁷.

Sodium Bisulfate (Traditional Industrial Pickle): Historically, jewelers relied on dilute sulfuric acid, which has been largely replaced by sodium bisulfate ($NaHSO_4$), commercially sold as swimming pool pH reducer⁶⁰. When dissolved in water, it yields a highly acidic solution (pH 1.0 to 2.0)⁶³. The primary dissolution reaction for cuprous oxide disproportionates into aqueous cupric ions (Cu^{2+}) and elemental copper dust (Cu^0), which often leaves a faint pink film on the metal⁵⁸. Sodium bisulfate acts aggressively, particularly when heated to 60°C, stripping fire scale in a matter of minutes⁶¹.

Citric Acid (The Eco-Conscious Alternative): To mitigate caustic fumes, many urban artisans have transitioned to citric acid ($C_6H_8O_7$)⁶⁵. Citric acid is a weak organic acid with a pKa of 3.1, approximately ten times less acidic than sodium bisulfate⁶⁴. However, it compensates through exceptional chelating properties. The citrate anion actively bonds to cupric ions to form a highly stable, water-soluble coordination complex known as copper citrate⁵⁹. The efficacy of citric acid pickling is heavily dependent on fluid dynamics, modeled by the Levich equation for diffusion-controlled electrochemical reactions⁶⁸. Experimental kinetic studies utilizing the rotating disc method reveal that the dissolution of copper oxides in citric acid is not limited by the chemical reaction rate at the surface, but by the diffusion of citrate ions through the hydrodynamic boundary layer⁶⁸. The activation energy for this process is remarkably low (calculated around 23 kJ/mol to 46.8 kJ/mol), confirming a diffusion-controlled mechanism⁶⁸. Consequently, the pickling speed can be exponentially increased by elevating the temperature (to ~60°C) and introducing mechanical agitation to thin the boundary layer⁶⁶. A standard formulation utilizes a 10% mass fraction of anhydrous citric acid powder to distilled water, yielding a bright surface finish without toxic vapor emissions⁶⁵.

Environmental Remediation and Disposal

As the pickling process continues, the bath progressively turns a deep blue, signaling saturation with aqueous copper sulfate or copper citrate⁶². Disposing of spent pickle down the municipal drain is a violation of the KrWG, as heavy metal copper ions are highly toxic to aquatic ecosystems and disrupt bacterial processing at water treatment plants¹.

The spent acidic solution must first be neutralized by adding sodium bicarbonate ($NaHCO_3$) until effervescence ceases, indicating the neutralization of free hydronium ions⁶⁰. While the pH is rectified, the copper ions remain in solution. The artisan must execute heavy metal remediation:

1. **Evaporation:** The neutralized solution is left to evaporate. The remaining crystalline copper citrate/sulfate sludge is deposited at a BSR hazardous waste collection point (*Schadstoffsammelstelle*)⁸.
2. **Cementation Extraction:** Utilizing galvanic displacement, sacrificial scrap iron (e.g., steel wool) is introduced into the pickle. Iron, being more anodic, dissolves into solution ($Fe \rightarrow Fe^{2+} + 2e^-$), while copper ions are reduced and precipitate as solid elemental copper sludge ($Cu^{2+} + 2e^- \rightarrow Cu$)⁷⁶. The solution turns pale green, and the extracted copper sludge can be legally surrendered to a scrap metal recycler⁷⁶.

Conclusion

The practice of traditional coppersmithing utilizing scavenged urban infrastructure demands a profound synthesis of metallurgical science, historical thermodynamics, and environmental compliance. Operating within Berlin's stringent regulatory landscape, the artisan must extract materials mechanically to satisfy the KrWG and § 326 StGB, prioritizing ecological stewardship over expedient thermal degradation. By understanding the distinct chemical typologies of Cu-ETP electrical wiring and Cu-DHP plumbing pipes, the smith can manipulate solid-fuel forge atmospheres to prevent catastrophic failures such as hydrogen embrittlement or lead-induced hot shortness. Through the precise calibration of cold-rolling pass schedules, the management of strain-hardening kinetics, and the application of diffusion-controlled organic pickling agents, the modern coppersmith elevates discarded industrial scrap into pristine, highly functional sheet metal, ensuring the viability of this ancient craft within the 21st-century circular economy.

Works cited

1. WHAT TO DO WITH OLD AND OBSOLETE CABLES - KabelDirekt, <https://kabeldirekt-store.de/en/blogs/news/alte-kabel-entsorgen-so-gehts-richtig-und-nachhaltig>
2. Stakeholder map and regional readiness for a systemic territorial, https://circular-foam.eu/Outcomes/Deliverables/_/CIRCULAR%20FOAM_Deliverable%201.1.pdf
3. Umweltgerechter Umgang mit Elektrogeräten, https://www.duh.de/fileadmin/user_upload/download/Projektinformation/ElektroG/240503_DUH_Stellungnahme_ElektroG_2024.pdf
4. REPORT FOR 2018 - D-EITI, https://d-eiti.de/Downloads/D-EITI%20Report%202018%20%28EN%29.pdf?_t=1618415784
5. Geprüfte Schutz- und Sicherheitskraft (IHK): Lehrbuch für Prüfung, <https://dokumen.pub/geprfte-schutz-und-sicherheitskraft-ihk-lehrbuch-fr-prfung-un>

- [d-praxis-4-aufl-9783658303747-9783658303754.html](https://www.bsped-3131407131-9783131407139.html)
6. Fachkunde für Kaufleute im Gesundheitswesen [3. aktualisierte, <https://dokumen.pub/fachkunde-fr-kaufleute-im-gesundheitswesen-3-aktualisierten-bsped-3131407131-9783131407139.html>]
 7. Amtsblatt für Brandenburg - BRAVORS, https://bravors.brandenburg.de/fm/76/Amtsblatt%2013_23.pdf
 8. Holes in the Circular Economy: - WEEE Leakage from Europe, https://fvg-vreg.ch/wp-content/uploads/2019/06/BAN_Report_WEEE_Leakage_EU_2019.pdf
 9. Berlin Altmetall Schrottplatz Ankauf Schrotthandel Altmetallhandel, <https://www.beller-das.de/>
 10. Schrottplatz Kreuzberg | Peglow Schrott und Metall Berlin, <https://schrott-berlin.de/schrottplatz-kreuzberg/>
 11. Copper scrap Germany | B2B companies and suppliers | europages, <https://www.europages.co.uk/companies/germany/copper%20scrap.html>
 12. VDM Magazin, https://www.vdm.berlin/wp-content/uploads/2022/04/677_VDM_LME-Skript-Print-NEU-NOV.pdf
 13. Hot shortness from Copper contamination of steel scrap - Dierk Raabe, <https://www.dierk-raabe.com/hot-shortness-from-copper-contamination-of-steel-scrap/>
 14. Microstructure and embrittlement of leaded copper alloys, <https://infoscience.epfl.ch/entities/publication/fc2a2b14-1af0-41ae-a9e4-9defb438672d>
 15. UNS C11000 Copper, ASTM B152/B187 - JINTIAN Copper Group, <https://jtcopper.com/c11000-copper.html>
 16. Cu-ETP: C11000 Industrial Rolled | PDF | Copper - Scribd, <https://www.scribd.com/document/496604892/Cu-ETP>
 17. Precision Strip & Wire Copper Alloys, <https://precision-metals.be/material/copper-alloys/>
 18. Copper Alloy Data Sheet & Specs | Austral Wright Metals, <https://www.australwright.com.au/technical-data/advice/copper-brass/copper-alloys/>
 19. UNS C11000 Copper Alloys - Dongmeng Group, <https://www.cndmmetal.com/copper-alloys/uns-c11000-copper-alloys.html>
 20. C110 Copper (ETP — Electrolytic Tough Pitch) Properties & Machining, <https://nextgencompllc.com/materials/copper-c110/>
 21. Plumbing Copper Pipes (Type K, L, M) | ASTM B88 C12200 Cu-DHP, <https://rvmetco.com/plumbing-copper-pipe.html>
 22. Product Catalogue Industry, <https://xamxyg7fn.filerobot.com/logstor/logstor-gb/logstor-content-fragments/documents/documentation/catalogs-and-manuals/industry/kingspan-logstor-product-catalogue-industry-specifications-en-eur.pdf>
 23. Plumbing Copper Tube - BS EN 1057 Table X - Brymec Portal, <https://portal.brymec.com/download-resource/ug72fk2bl93nf9a74b8redk268>

24. تسمه مسی - tabanmes - Taban Mes Iranian, <https://en.tabanmes.com/copper-belt/>
25. Medical Grade Copper Pipe Manufacturers in India, <https://metrosteel.com/medical-grade-copper-pipe-manufacturer-in-india.php>
26. Comments on the Intermediate-Temperature Embrittlement of Metals, <https://www.mdpi.com/2075-4701/14/3/270>
27. (PDF) Microstructure and embrittlement of leaded copper alloys, https://www.researchgate.net/publication/37413938_Microstructure_and_embrittlement_of_leaded_copper_alloys
28. The effect of Ag, Pb and Bi impurities on grain boundary sliding and, <https://www.repository.cam.ac.uk/items/9ac41476-2fcf-4758-b995-fa6bc7edff57>
29. A Review of Liquid Metal Embrittlement: Cracking Open ... - NSF PAR, <https://par.nsf.gov/servlets/purl/10323461>
30. Copper Alloy Design for Preventing Sulfur-Induced Embrittlement in, <https://www.mdpi.com/1996-1944/17/2/350>
31. SKI Report 99:44 The Effects of Impurities on the Properties of OFP, <https://www.stralsakerhetsmyndigheten.se/contentassets/2fbc58326d9d45a29931b4a767de3489/9944-the-effects-of-impurities-on-the-properties-of-ofp-copper-specified-for-the-copper-iron-canister>
32. Copper Sheet From Copper Water Pipe - Instructables, <https://www.instructables.com/Copper-Sheet-From-Copper-Water-Pipe/>
33. 2-DIY Traditional Blacksmith Forge Guide.pdf
34. 2-The Forge_ Building a Forced-Air Solid-Fuel Forge from Salvaged Materials.pdf
35. Strain hardening exponent - Wikipedia, https://en.wikipedia.org/wiki/Strain_hardening_exponent
36. (PDF) Brief review of oxidation kinetics of copper at 350 °C to 1050 °C, https://www.researchgate.net/publication/248131730_Brief_review_of_oxidation_kinetics_of_copper_at_350_C_to_1050_C
37. The Oxidation of Copper in Air at Temperatures up to 100 °C - MDPI, <https://www.mdpi.com/2624-5558/2/4/33>
38. Oxidation mechanism of thin Cu films: A gateway towards the, <https://pubs.aip.org/aip/adv/article/8/5/055114/923119/Oxidation-mechanism-of-thin-Cu-films-A-gateway>
39. Temperature-dependent oxidation behavior of thin copper films and, <https://opg.optica.org/ome/abstract.cfm?uri=ome-15-6-1196>
40. Grain Boundaries: Description, Structure and Thermodynamics, https://www.researchgate.net/publication/251244742_Grain_Boundaries_Description_Structure_and_Thermodynamics
41. Flattening thin copper strips - what would work best? - I Forge Iron, <https://www.iforgeiron.com/topic/42396-flattening-thin-copper-strips-what-would-work-best/>
42. Flattening and cleaning copper sheet for etching, <http://deborahreadcom.blogspot.com/2014/02/flattening-and-cleaning-copper-sheet.html>
43. Ideas/Techniques on re-flattening sheet metal after working it?, <https://orchid.ganoksin.com/t/ideas-techniques-on-re-flattening-sheet-metal-after->

[working-it/53869](#)

44. Rolling Practices - Cambridge University Press & Assessment,
https://resolve.cambridge.org/core/services/aop-cambridge-core/content/view/12F8FCB8DCBCCB0B39E3CF2D25CB45AF/9781139879293c3_p104-167_CBO.pdf/rolling_practices.pdf
45. Microstructure and Mechanical Properties of Copper/Graphene,
<https://www.mdpi.com/2075-4701/14/1/4>
46. Mechanical properties, microstructure, and texture evolution of,
https://www.researchgate.net/publication/363939661_Mechanical_properties_microstructure_and_texture_evolution_of_copper_sheets_subjected_to_differential_speed_rolling_process
47. Key Operation Points of 4 Hi Cold Rolling Mill,
<https://coldrollingmills.com/key-operation-points-of-4-hi-cold-rolling-mill-2/>
48. Size Effect on Mechanical Properties and Texture of Pure Copper,
<https://www.mdpi.com/1996-1944/10/5/538>
49. (PDF) Anisotropy of the elastic and strength properties of cold-rolled,
https://www.researchgate.net/publication/251368755_Anisotropy_of_the_elastic_and_strength_properties_of_cold-rolled_copper_sheets
50. Effects of Cold Rolling Reduction Rate on the Microstructure and,
<https://pmc.ncbi.nlm.nih.gov/articles/PMC10573223/>
51. Hollomon Equation: Strain Hardening Law Explained,
<https://engineersviews.com/blog/hollomon-equation-strain-hardening-law-explained/>
52. Understanding Springback In Sheet Metal Bending - SC Machinery,
<https://www.shen-chong.com/understanding-springback-in-sheet-metal-bending/>
53. Analytical prediction of springback based on residual differential,
<http://wpfiles.mines.edu/wp-content/uploads/aspprc/ResearchMaterials/Publications/352-Yi.pdf>
54. How to Reduce Springback in Sheet Metal Bending - CNHAWE,
<https://www.cnhawe.com/how-to-reduce-springback-in-sheet-metal-bending-6-proven-methods-for-precision/>
55. Springback - AHSS Guidelines, <https://ahssinsights.org/forming/springback/>
56. Avoiding Spring Back – How to Ensure Accurate Bends in Stainless,
<https://www.datumalloys.com/avoiding-spring-back/>
57. The chemistry of pickling - The Workshop,
<https://workshoparoundthecorner.wordpress.com/2016/12/30/the-chemistry-of-pickling/>
58. Pickle and Pickling - Nancy L T Hamilton,
<https://nancylthamilton.com/questions-and-answers/soldering-questions-2/pickle-and-pickling/>
59. The Influence of Citric Acid on the Corrosion Process of Different,
https://www.researchgate.net/publication/385736070_The_Influence_of_Citric_Acid_on_the_Corrosion_Process_of_Different_Metallic_Materials
60. How to Make and Neutralize Pickle Acid that is used to ... - YouTube,
<https://www.youtube.com/watch?v=Oi9NPZ1msQ0>

61. Pickling agent for copper | Home Model Engine Machinist Forum,
<https://www.homemodelenginemachinist.com/threads/pickling-agent-for-copper.3631/>
62. Be Kind to Fish! Dispose of ALL Spent Pickle Responsibly.,
<https://www.shoeboxstudio.com/2016/03/02/be-kind-to-fish-dispose-of-all-spent-pickle-responsibly/>
63. Pickle and polishing clarification - Ganoksin Orchid,
<https://orchid.ganoksin.com/t/pickle-and-polishing-clarification/10311>
64. What types of pickling solutions do you use - Ganoksin Orchid,
<https://orchid.ganoksin.com/t/what-types-of-pickling-solutions-do-you-use/60550>
65. Safer Studio - Citric Acid Pickle - Copperheart,
<http://copperheartdesigns.blogspot.com/2010/07/studio-safety-citric-acid-pickle.html>
66. Citric Acid-Based Treatment for Refining Mineral Fractions,
https://duepublico2.uni-due.de/servlets/MCRFileNodeServlet/duepublico_derivate_00083377/applsci_15_249.pdf
67. Effect of temperature on the dissolution of copper with citric acid,
https://www.researchgate.net/figure/Effect-of-temperature-on-the-dissolution-of-copper-with-citric-acid-solution-Operation_fig8_244362463
68. Rotating disc method to study the dissolution kinetics of copper,
https://www.researchgate.net/publication/378012300_Rotating_disc_method_to_study_the_dissolution_kinetics_of_copper_metal_in_citric_acid_and_hydrogen_peroxide
69. The effect of nitric acid concentration on the amount of copper,
https://www.researchgate.net/figure/The-effect-of-nitric-acid-concentration-on-the-amount-of-copper-dissolved-293-K-3142_fig1_244323368
70. Selective Separation of Cu and Zn in the Citric Acid Leachate of,
<https://pubs.acs.org/doi/10.1021/ie0616242>
71. A comprehensive study of the leaching behavior and dissolution,
https://scientiairanica.sharif.edu/article_20161_115d3f47028fe3e20144d4a6682af85d.pdf
72. The Leaching Kinetics of Iron from Titanium Gypsum in a Citric Acid,
<https://www.mdpi.com/1420-3049/28/3/952>
73. Just a small question about quenching/neutralizing pickle - Reddit,
https://www.reddit.com/r/SilverSmith/comments/8oi9o7/just_a_small_question_about_quenchingneutralizing/
74. New silversmith! - Reddit,
https://www.reddit.com/r/SilverSmith/comments/iw80s9/new_silversmith/
75. Method of removing copper and copper oxide from a ferrous metal,
<https://patents.google.com/patent/US4452643A/en>
76. How to extract copper from pickle solution - Ganoksin Orchid,
<https://orchid.ganoksin.com/t/how-to-extract-copper-from-pickle-solution/42651>
77. Removal of Cl(-I) from strongly acidic wastewater containing Cu(II),
https://www.researchgate.net/publication/347836742_Removal_of_Cl-I_from_strongly_acidic_wastewater_containing_CuII_by_complexation-precipitation_using_thi

[ourea_Efficiency_enhancement_by_ascorbic_acid](#)