

The Metallurgical and Artisanal Synthesis of Seamless Coppersmithing: Raising, Planishing, and Tinning in the Berlin Context

The transformation of a flat, two-dimensional sheet of copper into a seamless, three-dimensional cooking kettle represents one of the most sophisticated intersections of traditional craftsmanship and metallurgical physics. Unlike modern industrial deep-drawing or spin-forming, traditional hand-raising relies entirely on the precise, manual orchestration of compressive forces to induce plastic deformation without fracturing the crystalline lattice¹. When executing this craft in a contemporary urban environment such as Berlin, Germany, the process is further complicated by stringent legal frameworks governing material sourcing, environmental remediation, the preservation of cultural heritage, and the specific chemical requirements of food-safe vessels⁴.

The creation of a seamless cooking kettle without the use of welding or brazed seams demands an exhaustive understanding of non-ferrous metallurgy, crystallographic texture evolution, and thermodynamic phase transformations. The artisan must navigate the material from its raw, scavenged state through iterative cycles of high-temperature annealing, chemical pickling, mechanical raising, and planishing, culminating in the precise application of a liquid-metal tin lining via intermetallic bonding⁴. This analysis provides a comprehensive, expert-level examination of the seamless coppersmithing lifecycle, detailing the mechanical techniques, the underlying microstructural physics, and the specific socio-regulatory ecosystem of Berlin.

The Berlin Ecosystem: Regulation, Sourcing, and Craft Preservation

For the contemporary coppersmith operating within the city limits of Berlin, the procurement of raw materials has largely shifted toward the urban scavenging of discarded infrastructure. However, the extraction and processing of secondary copper are tightly constrained by German ecological legislation, primarily the Circular Economy Act (*Kreislaufwirtschaftsgesetz*, KrWG) and the Electrical and Electronic Equipment Act (*ElektroG*)⁴.

Under the KrWG, discarded copper from plumbing renovations and stripped electrical wiring are classified as highly valuable secondary raw materials⁴. Artisans frequently source these materials through direct agreements with local demolition contractors or from commercial scrap dealers (*Schrotthandel*) located in industrial districts such as Kreuzberg or Reinickendorf¹. The municipal waste management entity, *Berliner Stadtreinigung* (BSR), also plays a critical role in the urban circular economy, managing the legal disposal of hazardous chemical by-products generated during the metallurgical restoration process⁴.

A critical legal boundary exists regarding the extraction of copper from insulated electrical

cables. Historically, illicit scrap gatherers utilized open-air incineration to destroy polyvinyl chloride (PVC) or cross-linked polyethylene insulation. In Germany, this constitutes a severe criminal offense under Section 326 of the German Criminal Code (§ 326 StGB), which criminalizes the unauthorized thermal destruction of hazardous waste due to the release of highly toxic dioxins, furans, and hydrogen chloride gas⁴. Consequently, all urban copper must be extracted via pure mechanical stripping or purchased as *Kupfer Millberry* (bare, bright, unalloyed wire) or clean plumbing tubing⁴.

Institutional Heritage and Contemporary Workshops

The preservation of this demanding craft in Berlin is supported by a robust network of historic workshops, master craftsmen, and institutional incentives. The Berlin Chamber of Crafts (*Handwerkskammer Berlin*, HWK) actively promotes the continuation of advanced metallurgical disciplines through the *Meisterprüfung* (Master Craftsman Examination)⁹. To combat the attrition of traditional skills in the face of mass industrial stamping, the state of Berlin, in collaboration with the HWK, offers a *Meister- und MeisterinnenBONUS*—a financial grant of up to €6,000 awarded to artisans who successfully complete their rigorous master certifications in metalworking trades¹¹.

This institutional framework allows independent and historic workshops to thrive. For example, the Rixdorfer Schmiede at Richardplatz in Neukölln, which has operated for over 400 years, continues to offer open workshop access, allowing apprentices and hobbyists to practice traditional forging and raising techniques¹³. The legacy of seamless metal forming is also maintained by master restorers like Peter Trappen, who spent decades refining copper repoussé and raising techniques at the VEB Kunstschmiede under Achim Kühn, eventually restoring monumental copper figures such as the Apollo on the Berlin Konzerthaus and the eagle at the Märkisches Museum¹⁴. Work from modern ateliers such as Alte Schmiede Birkenwerder and Zyklus Metallwerkstatt further demonstrate the enduring viability of custom, handcrafted non-ferrous metalwork in the region¹⁵.

Berlin Metallurgical Institution / Workshop	Historical Significance & Focus
Handwerkskammer Berlin (HWK)	Regulatory body issuing the <i>Meisterbrief</i> ; provider of the €6,000 <i>Meisterbonus</i> for advanced skill retention ¹¹ .
Rixdorfer Schmiede	Historic forge (>400 years old) at Richardplatz offering open workshops for foundational and advanced metal forming ¹³ .
Atelier Achim Kühn / VEB Kunstschmiede	Historic locus of East Berlin's architectural metalwork; trained master coppersmiths in deep-drawing and repoussé ¹⁴ .

Peter Trappen (Master Restorer)	Authored definitive texts on copper craft (<i>Vom Kupferblech über das Handwerk zur Kuppelfigur</i>); restored major Berlin copper monuments ¹⁴ .
Zyklus Metallwerkstatt	Contemporary metalworking firm specializing in bespoke non-ferrous prototyping and architectural installations ¹⁶ .

Metallurgical Typologies: Cu-ETP vs. Cu-DHP


The source of the scavenged copper dictates its trace elemental composition, which fundamentally alters its response to high-temperature forging, raising, and cold-working⁴. The coppersmith must differentiate between electrical wiring and plumbing pipes to prevent catastrophic material failure during the kettle's fabrication.

Electrical wiring is almost exclusively manufactured from Electrolytic Tough Pitch copper (Cu-ETP, UNS C11000). While highly pure (99.90%) and possessing 100% IACS electrical conductivity, Cu-ETP contains intentionally introduced oxygen (0.02% to 0.04%), present as

cuprous oxide (Cu_2O) inclusions intended to scavenge trace impurities like bismuth and

antimony⁴. If Cu-ETP is heated above $370^{\circ}C$ in a reducing atmosphere—such as the carbon-rich core of a traditional solid-fuel forge—interstitial hydrogen atoms aggressively diffuse

into the copper lattice. These atoms react violently with the internal Cu_2O inclusions according to the thermodynamic reaction:



The resulting water vapor cannot diffuse out of the dense face-centered cubic (FCC) metal matrix, generating localized internal steam pressures that exceed the tensile strength of the copper at elevated temperatures. This leads to intergranular fissuring, severe blistering, and a structural disintegration known as hydrogen embrittlement⁴.

Conversely, scrap plumbing pipes (Cu-DHP, UNS C12200) are explicitly manufactured to withstand deep-drawing, extensive soldering, and localized heating during installation. During refining, phosphorus is introduced into the melt, acting as a highly effective deoxidizer that reduces free oxygen to less than 0.001% and leaves a residual phosphorus content between

0.015% and 0.040%². Because it lacks internal Cu_2O inclusions, Cu-DHP is entirely immune

to hydrogen embrittlement². Furthermore, contamination from solder joints containing lead (Pb

) or bismuth (Bi) must be entirely excised before heating, as these elements liquefy at forge temperatures and aggressively penetrate copper grain boundaries, causing spontaneous

fracture known as liquid metal embrittlement or hot shortness⁴. For the traditional coppersmith crafting a seamless kettle from scavenged material, excised Cu-DHP is the mandatory starting material.

Property Specification	Cu-ETP (Electrical Wiring)	Cu-DHP (Plumbing Pipes)
UNS / EN Designation	C11000 / CW004A	C12200 / CW024A
Copper Purity	> 99.90%	> 99.90%
Oxygen Content	0.02% - 0.04% (200-400 ppm)	< 0.001%
Phosphorus Content	None	0.015% - 0.040%
Hydrogen Embrittlement	Highly Susceptible ($> 370^{\circ}\text{C}$)	Immune
Suitability for Forging	Unsuitable in reducing atmospheres	Optimal for aggressive thermal cycling

Thermal Processing, Annealing, and Blank Preparation

To begin the kettle-making process, a work-hardened Cu-DHP pipe must be slit longitudinally, unfolded, and mechanically flattened into a pure two-dimensional disc⁴. Because the pipe retains extreme residual stresses from its original industrial extrusion, forcing it flat at room temperature will induce longitudinal stress fractures. It must first be thermally annealed⁴.

Forge Architectures and Refractory Engineering

Annealing is executed in a traditional solid-fuel forge, typically a side-blast charcoal trench forge (JABOD) or a bottom-blast bituminous coal forge constructed from repurposed automotive brake drums⁴. These forges are capable of reaching temperatures well in excess of the 600°C to 800°C required for copper annealing⁴.

A critical component of forge construction is the refractory lining, which protects the structural housing and concentrates thermal energy. Artisans must avoid standard concrete or Plaster of Paris, as the high silica content is subject to quartz inversion—a violent crystallographic phase transition from alpha-quartz to beta-quartz occurring at exactly 573°C ⁴. This transition is

accompanied by a sudden 2% volumetric expansion that shears internal bonds, causing standard concrete to crumble into dust. Historical recipes utilizing a matrix of high-silica sand, fireclay, and organic temper (such as equine manure) allow for "carbon burn-out," leaving microscopic voids that absorb this expansion and provide exceptional insulation⁴.

The Thermodynamics of Dynamic Recrystallization

As the copper reaches a dull red luminescence within the neutral or reducing zone of the forge, the rigid, elongated grains formed during previous cold-working undergo complete dynamic recrystallization. The thermal energy overcomes the activation barrier required for atomic mobility, allowing the metal to nucleate into new, equiaxed, stress-free grains⁴. This dramatic microstructural evolution resets the dislocation density, significantly lowering the yield strength and restoring maximum plasticity⁴.

Concurrently, heating copper in an ambient atmosphere initiates rapid thermal oxidation following a parabolic rate law, indicating a diffusion-controlled mechanism⁴. The oxidation scale forms a bipartite structure: a primary inner layer of red cuprous oxide (Cu_2O) growing via the outward lattice diffusion of copper cations migrating through vacancies, and a secondary outer layer of black cupric oxide (CuO) that forms at the boundary between the Cu_2O and the atmosphere⁴.

Upon removal from the forge, the glowing copper is immediately quenched in ambient water. While quenching does not harden copper as it does high-carbon steel, the violent thermal shock causes the brittle black CuO scale to spall (peel) off violently due to differential thermal contraction⁴.

Flattening and Dimensional Recovery

Once annealed, the copper is gently flattened. Striking the metal directly with a hardened steel hammer introduces unwanted localized work-hardening; therefore, artisans utilize rawhide or wooden mallets against flat wooden stumps, or thermal clamping between heavy steel plates⁴. If the material requires cold-rolling to achieve a uniform thickness for the kettle blank, the artisan must manage springback during subsequent leveling. Springback ($\Delta\alpha$) is the elastic recovery of the metal following plastic deformation, directly proportional to the material's yield strength (σ_y) and inversely proportional to its Young's modulus of elasticity (E)⁴. The magnitude is estimated using the relationship:

$$\Delta\alpha \approx \left(\frac{\sigma_y \cdot t}{E \cdot R} \right) \times K$$

Where t is sheet thickness, R is bend radius, and K is a geometric process coefficient⁴. Because fully annealed copper possesses an exceptionally low yield strength (60-90 MPa), it

exhibits negligible springback (0.0° to 0.5°), allowing the artisan to achieve absolute flatness prior to cutting the circular blank².

Chemical Pickling Kinetics and Environmental Remediation

Despite the physical spalling of the outer cupric oxide scale during quenching, a tenacious, abrasive layer of red cuprous oxide remains chemically bonded to the substrate⁴. If the smith attempts to strike the metal with a highly polished raising hammer, these brittle oxide shards will be driven deep into the pure copper matrix, destroying the surface finish and initiating micro-tears⁴. The scale must be dissolved chemically through a process known as pickling⁴. Historically, European artisans and jewelers utilized highly caustic dilute sulfuric acid or sodium bisulfate ($NaHSO_4$), which operates at a highly aggressive pH of 1.0 to 2.0 and rapidly strips fire scale⁴. However, the disposal of such caustic heavy-metal solutions is strictly prohibited under Berlin's KrWG, as heavy metal copper ions are highly toxic to aquatic ecosystems and disrupt bacterial processing at municipal water treatment plants⁴.

Consequently, modern urban artisans have largely transitioned to citric acid ($C_6H_8O_7$), a weaker organic acid (pKa 3.1) that operates via an entirely different chemical mechanism: chelation⁴. The citrate anion actively bonds to cupric ions to form a highly stable, water-soluble coordination complex known as copper citrate⁴.

Experimental kinetic studies utilizing the rotating disc method reveal that the dissolution of copper oxides in citric acid is not limited by the chemical reaction rate at the surface, but by the diffusion of citrate ions through the hydrodynamic boundary layer, a phenomenon modeled by the Levich equation⁴. Because the activation energy for this process is remarkably low (calculated around 23 kJ/mol to 46.8 kJ/mol), the mechanism is strictly diffusion-controlled. Therefore, the artisan can exponentially increase the pickling speed by heating the bath to approximately $60^\circ C$ and introducing mechanical agitation to physically thin the boundary layer⁴.

Once the pickling bath reaches saturation—turning a deep, opaque blue—it must be neutralized with sodium bicarbonate ($NaHCO_3$) until effervescence ceases⁴. The toxic aqueous copper ions (Cu^{2+}) are then extracted via galvanic displacement (cementation). The artisan introduces a sacrificial steel matrix (e.g., steel wool) into the solution. The iron, being more anodic, dissolves into solution ($Fe \rightarrow Fe^{2+} + 2e^-$), while the copper ions are reduced and precipitate as solid elemental copper sludge ($Cu^{2+} + 2e^- \rightarrow Cu$)⁴. The extracted copper sludge can then be legally surrendered to a Berlin recycling facility, ensuring full compliance with environmental statutes⁴.

The Mechanics and Kinematics of Raising

With a fully annealed, chemically pristine, flat copper disc prepared, the coppersmith begins the profound geometric transformation. The objective is to transmute the two-dimensional disc into a three-dimensional cylindrical or bulbous kettle without cutting, seaming, stretching, or welding the material². This is achieved through "raising," a technique characterized by purely compressive plastic deformation.

Sinking vs. Raising: Stretching vs. Compression

It is critical to distinguish raising from sinking. Sinking involves hammering a sheet of metal downward into a concave depression (such as a dishing stump)². Sinking exclusively *stretches* the metal, forcing the surface area to expand while simultaneously thinning the cross-sectional wall thickness². While sinking is comparatively easy to master and suitable for shallow bowls, it cannot produce a deep, vertical-walled kettle, as the structural integrity of the walls would eventually fail due to excessive thinning³³.

Raising, conversely, is a highly controlled, complex operation of lateral compression². The smith strikes the exterior of the disc over a convex steel anvil, known as a raising stake². Each blow of the hammer forces the circumference of the disc to shrink while driving the displaced mass upward, progressively building the vertical walls of the vessel¹. When executed perfectly, a raised vessel will possess walls that are exactly the same thickness as—or slightly thicker than—the original flat disc²³.

The Setup and Blank Geometry

The artisan begins by determining the required diameter of the starting blank, which must account for the total surface area of the final kettle. Using a prick punch, the smith creates a sharp, permanent indent at the absolute center of the disc to prevent the center point from being lost during hammering¹. Using a compass, the smith scribes a baseline circle indicating the precise diameter of the kettle's flat bottom.

Beyond this baseline, a series of concentric circles, known as "rows," are drawn, spaced approximately one hammer-face width apart, extending to the outer edge¹. These concentric guide lines are imperative; they dictate the spiral progression of the hammer blows. The smith also marks a "start line" dissecting the rows, alongside directional arrows¹. These markers ensure the deformation remains radially symmetrical and that the vessel remains perfectly true by alternating the hammering direction (clockwise to counter-clockwise) upon completing each concentric round¹.

The Tooling: T-Stakes and Cross-Peen Hammers

The raising process requires highly specialized, polished steel tooling. The primary anvil is the raising T-stake (such as a hardened stainless steel Fretz R-1), a heavy steel arm extending horizontally with a specific convex radius that mimics the desired internal curve of the kettle². The hammer is a specialized cross-peen raising hammer (such as a 400-gram Peddinghaus 403)³³. Unlike standard flat-faced forging hammers used by blacksmiths, the raising hammer features two rectangular faces that are longer than they are wide, with a distinct, polished curvature². The elongated geometry of the hammer face ensures that the compressive force is

directed laterally across the circumference of the metal, forcing it to shrink, rather than spreading the mass longitudinally up the wall³³.

Angle Raising and Strike Kinematics

To begin, the flat disc is held against the T-stake at a precise angle—typically around 20 degrees off the horizontal axis of the stake¹. The defining mechanical requirement of angle raising is the establishment of an "air gap." The copper must *not* rest flush against the curvature of the stake directly beneath the hammer strike¹. If the metal is pinched directly between the hard steel hammer and the hard steel stake, the copper will be crushed, resulting in immediate, irreversible stretching and thinning of the vessel wall¹.

Instead, the artisan holds the metal so that the baseline rests securely on the stake, while the area being struck hovers in the air slightly above the steel surface¹. The hammer is struck straight down. The kinetic energy of the blow forces the copper to yield and fold downward through the air gap until it contacts the stake, absorbing the energy via plastic deformation¹. This action forces the metal to crimp inward and compress laterally, shrinking the circumference. The smith strikes sequentially along the drawn concentric rows, rotating the disc incrementally after every single blow¹. The hammer head must be kept strictly perpendicular to the stake; tilting the hammer backward (toward the smith) stretches the metal, while tilting it forward artificially shrinks the metal, introducing irregular stresses and hammer nicks that cannot be planished out later¹. To prevent the vessel from twisting anisotropically, the smith alters the direction of rotation upon completing each full round, ensuring isotropic stress distribution¹.

Crimp Raising: An Alternative Mechanism

While angle raising relies on the smith's rotational consistency and the air gap to manage the compressive flow, an alternative technique known as crimp raising mechanically forces the compression. In crimp raising, the flat disc is placed over a specialized grooved crimping stake on the *inside* surface of the vessel²³. A wooden, nylon, or delrin mallet is used to strike the exterior metal into the grooves, creating distinct, evenly spaced radial folds (crimps) around the circumference of the disc²³.

The piece is then transferred to a smooth raising stake. The smith uses a mallet to carefully compress the peaks of the crimped ridges down into the valleys²³. This action physically forces the metal to consume its own excess surface area, thickening the edge (upsetting) and driving the wall upward at a sharper angle²³. While some artisans prefer crimp raising for establishing extreme initial angles or heavy walled vessels, traditional angle raising remains the predominant method for achieving the smooth, sweeping bellies of a classic, thin-walled cooking kettle²³.

Crystallographic Texture Evolution and Plasticity

As the coppersmith forces the metal to compress and rise, the macroscopic change in the kettle's geometry is dictated by profound microscopic alterations within the crystalline lattice. Pure copper possesses a Face-Centered Cubic (FCC) atomic structure, which inherently contains 12 primary slip systems (combinations of close-packed $\{111\}$ planes and $\langle 110 \rangle$ directions)³⁴. This high number of active slip systems grants copper its legendary ductility,

allowing it to undergo severe plastic deformation without fracturing³⁴.

Deformation Mechanisms and Texture Components

During the intensive compressive cycles of raising, the initially random, equiaxed orientation of the annealed copper grains is systematically destroyed. As the material yields, the grains elongate, and the crystal lattices physically rotate toward preferred crystallographic orientations with respect to the applied stress tensors, developing a pronounced deformation texture³.

The evolution of texture in FCC metals under mechanical deformation is classically described by mathematical frameworks such as the Sachs model (which assumes stress equilibrium across all grains, leading to single slip systems) and the Taylor model (which assumes strain compatibility, requiring multiple intersecting slip systems to activate simultaneously)³⁷.

In severely cold-worked copper, this crystallographic rotation typically evolves into a complex combination of stable end-orientations. The most prominent texture components identified via X-ray diffraction (XRD) and electron backscattered diffraction (EBSD) are the Copper

$\{112\}\langle 111 \rangle$, the S-component $\{123\}\langle 634 \rangle$, and the Brass $\{110\}\langle 112 \rangle$ orientations⁸.

Furthermore, localized non-crystallographic deformation mechanisms, such as shear banding, can trigger aggressive localized lattice rotations that accommodate extreme plastic flow between adjacent structural phases³⁵.

These specific crystallographic alignments heavily influence the planar anisotropy of the metal. If the texture becomes too severe in a single direction, the copper will deform at different rates across its geometry, leading to uneven rim heights and structural weak points¹. The manual coppersmith subconsciously counteracts this macroscopic anisotropy through the rigid adherence to alternating the direction of their hammering rounds, essentially homogenizing the strain distribution¹.

Texture Component	Miller Indices Notation	Mechanism of Formation in FCC Copper
Copper	$\{112\}\langle 111 \rangle$	Dominant orientation arising from homogeneous dislocation slip during primary compressive deformation ⁸ .
S-Component	$\{123\}\langle 634 \rangle$	Prominent in high-strain plastic flow; relates to stable end-orientations of the lattice rotation ²⁴ .
Brass	$\{110\}\langle 112 \rangle$	Often induced by non-crystallographic shear

		banding, mechanical twinning, or severe localized stress at cryogenic to room temperatures ⁸ .
Cube	$\{001\}\langle 100 \rangle$	The dominant recrystallization texture formed statically <i>during</i> the thermal annealing cycles ²⁴ .

The Hollomon Power Law and Intermediate Annealing

As the crystallographic planes slide past one another to accommodate the changing geometry of the kettle, dislocations within the atomic lattice multiply exponentially, interact, and entangle⁴. These entangled dislocations act as physical barriers to further atomic slip. Consequently, the metal rapidly stiffens, requiring significantly higher hammer forces to achieve the same degree of deformation⁴. This behavior—strain hardening or work hardening—is mathematically quantified by the Hollomon equation:

$$\sigma = K \cdot \epsilon^n$$

Where σ is the true applied flow stress, K is the strength coefficient, ϵ is the true plastic strain, and n is the strain hardening exponent⁴.

Fully annealed pure copper possesses an exceptionally high strain hardening exponent (typically 0.44 to 0.54), indicating vast reserves of initial ductility⁴. However, this also dictates that its yield strength escalates violently during deformation. The yield strength of annealed Cu-DHP sits at a highly malleable 60-90 MPa². After just one or two full rounds of raising, the immense accumulation of dislocations causes the yield strength to spike to over 250 MPa, approaching its ultimate tensile strength of approximately 350 MPa⁴.

At this juncture, the acoustic profile of the metal changes dramatically; it will emit a distinct, high-pitched "ring" when struck, and the hammer will begin to bounce aggressively off the surface, returning the kinetic energy directly into the smith's arm². If the smith continues to hammer, the localized stress will exceed the ultimate tensile strength, leading to ductile fracture and catastrophic tearing of the vessel wall¹.

To proceed, the artisan must stop, clean the metal, and subject the vessel to an intermediate thermal annealing cycle (600°C to 800°C) to activate static recrystallization. This thermal injection allows the atoms to reorder into the Cube texture ($\{001\}\langle 100 \rangle$), resetting the dislocation density to near zero and restoring malleability². A deep, seamless kettle may require twenty or more complete, grueling cycles of raising, annealing, and pickling before the final

volumetric geometry is achieved².

Planishing: Microstructural Consolidation and Surface Geometry

Once the kettle has been raised to its final volumetric dimensions, it is functionally incomplete. The surface remains heavily corrugated, covered in the overlapping, faceted indentations left by the cross-peen raising hammer². Furthermore, because the vessel underwent a final annealing cycle to relieve stresses, the metal exists in a soft, dead-annealed state, rendering the kettle structurally weak and highly prone to denting during daily culinary use⁶. To finalize the vessel, the smith employs a highly specialized finishing technique known as "planishing"².

Planishing is not intended to alter the macro-geometry or move the mass of the metal; rather, it is a localized surface refinement technique designed to achieve two critical, simultaneous objectives: optical smoothing and profound structural work-hardening².

The operation utilizes a highly polished, double-sided planishing or collet hammer featuring one perfectly flat face and one slightly domed (convex) face⁴⁰. The kettle is placed over a polished, convex stake that perfectly matches the interior curvature of the vessel⁴⁰. Starting from the center base and working outward in a tightly overlapping, meticulous spiral, the smith delivers thousands of rapid, highly controlled, low-force blows⁴⁰.

Unlike raising, where an air gap is mandatory to allow compression, planishing requires the copper to be trapped perfectly flush between the hammer and the steel stake⁴⁰. The kinetic energy of the planishing hammer compresses the peaks of the previous hammer marks down into the valleys, physically homogenizing the surface geometry. The highly polished face of the hammer imparts its own mirror-like finish onto the copper, burnishing the surface to a gleam and removing all evidence of the aggressive forming tools⁶.

Microstructurally, this localized compression introduces a dense network of shallow dislocations strictly into the immediate surface layer of the copper matrix. This highly targeted strain hardening dramatically increases the localized yield strength of the copper⁶. By planishing the entire exterior, the smith essentially encases the kettle in a rigid, work-hardened exoskeleton, granting the thin-walled vessel immense structural integrity and resistance to deformation under the weight of boiling liquids⁶.

Food Safety, Verdigris, and the Metallurgy of Hand-Wiped Tinning

While a beautifully raised and planished copper kettle represents a triumph of physical metallurgy and plastic deformation, it remains inherently dangerous for culinary use in its raw state. Copper is a highly reactive transition metal, particularly vulnerable to weak organic acids such as acetic acid (vinegar) or citric acid found abundantly in foods⁴². Prolonged exposure to these culinary acids triggers the formation of copper(II) acetate, commonly known as verdigris⁴². Food contaminated with verdigris from an unlined copper vessel induces acute heavy metal toxicity, resulting in severe gastrointestinal distress, nausea, and vomiting⁴². To render the kettle food-safe and chemically inert, the interior must be hermetically sealed with a non-toxic,

non-reactive barrier. Since antiquity, coppersmiths have utilized elemental tin (Sn) for this purpose⁵. Modern artisans in Berlin rely on the traditional, highly skilled technique of "hand-wiped tinning" to apply this barrier, shunning modern electroplating for a thicker, more durable intermetallic bond⁴⁶.

Surface Preparation and Flux Chemistry

The intermetallic bonding of tin to a copper substrate requires absolute chemical purity; any residual oxides, grease, or organic contaminants will instantly repel the molten tin, causing it to bead and fail to wet the surface. The interior of the planished kettle is first scoured aggressively with fine abrasives (such as 4F pumice powder or steel wool) and weak acids to expose the bare, pink copper substrate⁴⁶.

To prevent the molten tin from adhering to the beautifully planished exterior, a thin mask of whiting—a paste made from garden lime or chalk—is painted over the outside of the vessel⁷. To prevent atmospheric oxidation of the interior during the requisite heating process, a chemical flux must be applied. The traditional, uncompromising flux for copper tinning is ammonium chloride (NH_4Cl), known historically as sal ammoniac⁴⁶. When heated, sal ammoniac dissociates into ammonia and hydrogen chloride gas, acting as a highly aggressive etching agent that actively scavenges oxygen from the copper surface⁴⁹. This reaction produces a transient layer of active metal chlorides that drastically lower the surface tension of the substrate, allowing the liquid tin to exhibit perfect wetting behavior⁵⁰.

The Thermodynamics of Wiping

Pure tin possesses a relatively low melting point of $232^{\circ}C$ ($450^{\circ}F$)⁵². The artisan places the flux-coated kettle over a disbursed, medium-heat source—such as a plumber's brazing torch or a banked forge—carefully bringing the mass of the copper up to roughly $250^{\circ}C$ to $280^{\circ}C$ ⁴⁶. Extreme thermal control is paramount; oxy-acetylene torches are strictly avoided, as localized temperatures exceeding $300^{\circ}C$ will incinerate the flux, aggressively oxidize the copper, and cause the tin to scorch and refuse to bond⁷.

Once the optimal temperature is reached, a solid ingot of 99.99% pure, food-grade block tin is touched to the interior. The thermal mass of the copper instantly melts the tin, pooling it at the bottom of the kettle⁷. Working with extreme rapidity before the vessel cools below $232^{\circ}C$, the smith utilizes a tightly wadded pad of thick cotton batting (moleskin) or fiberglass to physically wipe the liquid metal up the walls of the kettle⁷.

The wiping action distributes the molten tin into a smooth, even film across the entire interior geometry. The presence of faint, sweeping wipe marks in the final lining is a hallmark of artisanal quality, demonstrating the rapid, uninterrupted fluid dynamics managed by the tinner in a single pass⁷. Conversely, short, interrupted wipes or localized reheating damages the bond and leads to an inferior coating⁷.

Intermetallic Compound (IMC) Kinetics and Grain Growth

The bond between the tin lining and the copper kettle is not merely mechanical adhesion; it is a profound metallurgical phase transformation resulting in a true intermetallic bond⁵⁵. The moment the liquid tin contacts the fluxed, heated copper, diffusion kinetics are initiated.

The molten tin acts as a powerful solvent, rapidly dissolving a microscopic layer of the solid copper matrix⁵⁷. Driven by concentration gradients and thermal activation energy (calculated at approximately $84.43 \text{ kJ mol}^{-1}$ for the total IMC layer), the atomic species interdiffuse to form two distinct Intermetallic Compound (IMC) phases at the boundary layer⁵⁵.

1. **The η -phase (Cu_6Sn_5)**: This primary phase forms immediately adjacent to the bulk tin layer. It is characterized by an irregular, highly scalloped, needle-like growth front that projects far into the tin matrix, providing intense mechanical interdigitation (locking) that secures the lining to the kettle⁵⁵.
2. **The ϵ -phase (Cu_3Sn)**: A secondary, much thinner, and more planar phase that develops between the Cu_6Sn_5 layer and the bulk copper substrate⁵⁵.

Interface Layer	Chemical Formula	Morphology and Function
Substrate	Cu (Solid)	The bulk Cu-DHP copper vessel wall; structural support.
Inner IMC Phase	Cu_3Sn (ϵ -phase)	Thin, planar layer mediating diffusion between Cu and Cu_6Sn_5 ⁵⁵ .
Outer IMC Phase	Cu_6Sn_5 (η -phase)	Highly scalloped, irregular interface projecting into the tin; establishes the robust metallurgical bond ⁵⁵ .
Surface Coating	Sn (Pure)	The food-safe, pure tin culinary barrier ⁴² .

The formation of the IMC is vital for adhesion, but its growth kinetics must be meticulously controlled by the tinner's speed. Because the stoichiometric ratio of Cu_3Sn requires three copper atoms for every tin atom, copper is consumed at an accelerated rate⁵⁷. If the kettle is held at elevated temperatures for too long, this disparity in diffusion rates (known as the Kirkendall effect) leads to the formation of microscopic vacancies—Kirkendall voids—at the

copper/ Cu_3Sn boundary, severely degrading the structural integrity of the lining⁵⁶. Furthermore, both IMC layers are inherently brittle; excessive thermal aging causes overgrowth, limiting the kettle's ability to absorb thermal shock without the lining delaminating or fracturing during impact⁵⁵.

By wiping the tin rapidly and allowing the kettle to cool naturally, the smith limits the terminal crystal grain growth of the pure tin layer. Pure unalloyed tin, when hand-wiped over a copper substrate, naturally restricts its crystalline lattice organization to a maximum thickness of approximately 0.45 millimeters⁵⁴. The adept tinner relies on tactile and auditory feedback—sometimes noting the "tin shriek" as the primary matrix cures to its natural thickness limit—to guarantee uniform coverage⁵⁴. This specific, naturally regulated thickness ensures an optimal thermal mass for the transmission of culinary heat while providing a robust, non-toxic barrier that vastly outlasts the micron-thin layers produced by modern electroplating⁴².

Conclusion

The creation of a seamless copper kettle without the use of welding, brazing, or modern hydraulic presses stands as a monument to human ingenuity and the mastery of physical metallurgy. By operating within Berlin's strict environmental and legal frameworks (the KrWG, ElektroG, and § 326 StGB), the modern artisan legally extracts high-grade Cu-DHP from urban waste streams, deliberately avoiding the catastrophic hydrogen embrittlement risks associated with Cu-ETP electronic scrap.

Through the precise, rhythmic orchestration of angle raising and compressive hammer strikes over specialized steel stakes, the smith commands the crystallographic slip systems of the FCC copper lattice. They manipulate texture evolution and strain-hardening kinetics, relying on intermediate dynamic recrystallization in traditional solid-fuel forges to reset the Hollomon curve and prevent ductile fracture. Subsequent planishing consolidates the microstructural geometry into a rigid, work-hardened exoskeleton, granting the vessel immense durability.

Finally, the thermodynamic precision of hand-wiped tinning utilizing sal ammoniac flux ensures the creation of an intermetallic bond (Cu_6Sn_5 and Cu_3Sn) that is both structurally sound and toxicologically safe. Bolstered by institutional support from the Handwerkskammer Berlin and the enduring legacy of local master restorers, this traditional metallurgical synthesis elevates discarded industrial piping into a highly functional, enduring piece of culinary architecture, securing the craft's relevance in the 21st-century circular economy.

Works cited

1. The Raising of Metal, <https://metalrecipes.com/wp-content/uploads/2017/08/The-Raising-of-Metal-1.pdf>
2. Raising — The Hammer-Forming Technique for Hollow Vessels, <https://skyjems.ca/pages/encyclopedia-raising>
3. Interpretation of Copper Rolling Texture Components Development, <https://www.mdpi.com/2073-4352/15/12/1011>
4. 11 - Scrap Copper Cold-Rolling Methods.pdf

5. Coppersmithing (objects) - Heritage Crafts,
<https://heritagecrafts.org.uk/craft/coppersmithing-objects/>
6. planishing - Hammermarks - WordPress.com,
<https://hammermarks.wordpress.com/tag/planishing/>
7. Trial by Fire - Brooklyn Copper Cookware,
<https://brooklyncoppercookware.com/trial-by-fire/>
8. Crystallographic texture and microtexture of copper drawn at 295 K,
<https://www.scielo.br/j/rmat/a/wv9HkFhCMgCxwbp3dVMhh3B/?lang=en>
9. Wir beraten Sie gern - Handwerkskammer Berlin,
<https://www.hwk-berlin.de/artikel/wir-beraten-sie-gern-91,0,1267.html>
10. Ihr Weg zum Meistertitel - Handwerkskammer Berlin,
<https://www.hwk-berlin.de/artikel/ihr-weg-zum-meistertitel-91,0,1264.html>
11. Bonus in Höhe bis zu 6.000 Euro für den Meisterabschluss,
<https://www.hwk-berlin.de/artikel/bonus-in-hoehe-bis-zu-6-000-euro-fuer-den-meisterabschluss-91,0,801.html>
12. Meistervorbereitungskurse - Handwerkskammer Berlin,
<https://www.hwk-berlin.de/artikel/meistervorbereitungskurse-91,0,581.html>
13. Offene Werkstatt - Berlin - Rixdorfer Schmiede,
<https://www.feine-klingen.de/offene-werkstatt/>
14. Peter Trappen - Wikipedia, https://de.wikipedia.org/wiki/Peter_Trappen
15. Alte Schmiede Birkenwerder - Ihre Kunstschmiede in Berlin und,
<http://www.alte-schmiede-birkenwerder.de/>
16. Metallwerkstatt: Metallbau, Museumsexponate, Hands-On-Exponate,
<http://zyklus-design.de/>
17. Achim Kühn: Willkommen, <https://achimkuehn.de/>
18. Meisterbrief - Handwerkskammer Berlin,
<https://www.hwk-berlin.de/artikel/meisterbrief-91,0,376.html>
19. Vom Kupferblech über das Handwerk zur Kuppelfigur | 00961158,
<https://angele-shop.com/Vom-Kupferblech-ueber-das-Handwerk-zur-Kuppelfigur/00961158>
20. Coppersmithing Like You Have Never Seen: Seamless Art - YouTube,
<https://www.youtube.com/watch?v=Z5OSkHAKdSA>
21. COPPER: Raising VS Sinking - YouTube,
<https://www.youtube.com/watch?v=sXNZZRQNJhU>
22. Videos — All Things Hammered, <http://allthingshammered.com/videos>
23. Get to Better Know Your Hammer-Raising Hammers,
<https://hammermarks.wordpress.com/2008/10/17/get-to-better-know-your-hammer-raising-hammers/>
24. Evolution of Microstructure, Mechanical Properties and ... - MDPI,
<https://www.mdpi.com/2075-4701/16/9/989>
25. Stahlwerk Berlin - Schmiede, Bildhauer, Schmiedekurse, Messer,
<https://stahlwerk-berlin.de/>
26. unsere werkstatt - Berlin - Fittkau Metallgestaltung GmbH,
<https://www.fittkau-metallbau.de/index.php/de/leistungen-metallbau-schmiedekunst/werkstatt.html>

27. Good In A Pinch: The Physics Of Crimped Connections - Hackaday,
<https://hackaday.com/2017/02/09/good-in-a-pinch-the-physics-of-crimped-connections/>
28. Crimp vs Open Hand vs Drag: The Mechanical Differences Explained,
<https://www.maxclimbing.com/de/blogs/knowledge-hub-anatomy/crimp-vs-open-hand-vs-drag-the-mechanical-differences-explained>
29. Improper degree of compression in crimped connectors,
<https://semiconductor.altertechnology.com/material-processing/improper-degree-of-compression-in-crimped-connectors/>
30. Raising (metalworking) - Wikipedia,
[https://en.wikipedia.org/wiki/Raising_\(metalworking\)](https://en.wikipedia.org/wiki/Raising_(metalworking))
31. Raising silver crimping - Jewelry Discussion - Ganoksin Orchid,
<https://orchid.ganoksin.com/t/raising-silver-crimping/27276>
32. Forging a Traditional, Seamless Copper Wine Kettle from ... - YouTube,
<https://www.youtube.com/shorts/d8-h631trEI>
33. Forming bowls in copper - Ganoksin Orchid,
<https://orchid.ganoksin.com/t/forming-bowls-in-copper/69493>
34. Origins of Texture - DoITPoMS,
https://www.doitpoms.ac.uk/tlplib/crystallographic_texture/texture_origin.php
35. Texture and microstructure evolution during non-crystallographic,
<https://www.dierk-raabe.com/app/download/5796041242/Acta+Mater+2014+Texture+shear+bands+Cu-Ag+composite.pdf>
36. development of texture in copper by cold. rolling,
https://nvlpubs.nist.gov/nistpubs/jres/26/jresv26n5p385_A1b.pdf
37. Crystallographic texture - IMIM PAN,
https://www.imim.pl/files/SD/Power/POWER_Texture1_RCH.pdf
38. The cube texture component - Dierk Raabe,
<https://www.dierk-raabe.com/crystal-plasticity/the-cube-texture-component/>
39. Planishing Hammer, <https://skyjems.ca/pages/encyclopedia-planishing-hammer>
40. Planishing - DT Online, <https://wiki.dtonline.org/index.php/Planishing>
41. A Guide To Fretz Metal Working Hammers | The Bench - Cooksongold,
<https://www.cooksongold.com/blog/learn/how-to-work-with-fretz-metal-working-hammers/>
42. Double trouble - PMC - NIH, <https://pmc.ncbi.nlm.nih.gov/articles/PMC1479674/>
43. Concerns About Cookware Chemistry | Office for Science and Society,
<https://www.mcgill.ca/oss/article/health-and-nutrition/concerns-about-cookware-chemistry>
44. The chemistry of copper cookware,
<https://www.greekchemistinthekitchen.com/post/the-chemistry-of-copper-cookware>
45. Release behavior of metals from tin-lined copper cookware into food,
<https://pubmed.ncbi.nlm.nih.gov/32623684/>
46. Hand re-tinning copper cookware: Smart, Safe Tips - Finishing.com,
<https://www.finishing.com/255/53.shtml>
47. DIY Hand Wiped Tinning of Old Copper Pots/Pans - Instructables,
<https://www.instructables.com/DIY-Hand-Wiped-Tinning-of-Old-Copper-PotsPans-I>

[nst/](#)

48. Retinning copper process - East Coast Tinning,
<https://eastcoasttinning.com/retinning-process>
49. Soldering Tip Tinning with Sal Ammoniac,
<https://www.evilmadscientist.com/2014/tinning/>
50. Metal working flux to create a tin coating, galvanizing or soldering,
<https://basekim.com/en/metal-working/>
51. Challenges in Copper Chemical Machining by Transition Metal Salts,
<https://www.preprints.org/manuscript/202511.0149>
52. Tinner's Blog - Burning Question - Copper Tinner,
https://coppertinner.ca/blog/burning_question.html
53. Optimal Hot-Dipped Tinning Process Routine for the Fabrication of,
<https://pmc.ncbi.nlm.nih.gov/articles/PMC7085106/>
54. Tin's Terminal Grain Growth - Brooklyn Copper Cookware,
<https://brooklyncoppercookware.com/tins-terminal-grain-growth/>
55. Reaction diffusions of Cu₆Sn₅ and Cu₃Sn intermetallic compound,
https://www.researchgate.net/publication/298009307_Reaction_diffusions_of_Cu6Sn5_and_Cu3Sn_intermetallic_compound_in_the_couple_of_Sn-35Ag_eutectic_solder_and_copper_substrate
56. Dissolution in Service of the Copper Substrate of Solder Joints,
https://www.electronics.org/system/files/technical_resource/E40%26S37_03%20-%20Keith%20Sweatman.pdf
57. Intermetallics In Soldering - Indium Corporation,
<https://www.indium.com/blog/intermetallics-in-soldering/>
58. intermetallics formation and growth at the interface of tin-based,
https://tsapps.nist.gov/publication/get_pdf.cfm?pub_id=851327
59. The Intermetallic Layer - EPTAC,
https://www.eptac.com/hubfs/EPTAC_February2022/pdf/eptac_11_14_12.pdf
60. Intermetallic Growth on PCB - Heller Industries,
<https://hellerindustries.com/intermetallics-growth>