

High-Fired Ceramic Engineering and Utilitarian Tableware Production in the Glacial Basin of Berlin-Brandenburg: Regional Mineralogy, Kiln Pyrotechnology, and Vitrified Stoneware Praxis for Post-Industrial Subsistence

Historical Precedent and Regional Ceramic Traditions

The post-glacial lowlands of the North German Plain, encompassing the Berlin-Brandenburg basin, have sustained contiguous ceramic industries for over eight centuries. The regional pyrotechnological trajectory has been governed by the intimate spatial relationship between glacial sedimentology and navigable fluvial networks. The Upper Havel waterway system provided both raw alluvial and lacustrine clay deposits and a low-friction transportation corridor to the expanding urban center of Berlin, establishing the historic brickworks belt (*Ziegelgürtel*) centered on Zehdenick, Mildenberg, and Glindow¹. Simultaneously, specialized pottery settlements leveraged distinct regional mineral beds to synthesize domestic utilitarian wares and preservation vessels essential for rural food security⁵.

In the Margraviate of Brandenburg, the enclave of Görzke in the Hoher Fläming represents one of the oldest contiguous potting communities in Central Europe⁶. The local potter guild, officially chartered in 1706, expanded substantially following the influx of migrant journeymen from Silesia⁵. In 1746, Master Potter Ludwig founded a workshop that institutionalized the transfer of high-temperature stoneware traditions to Brandenburg soil, an operation maintained across multiple centuries⁶. In 1834, Eduard Heinitz migrated from Silesia to Görzke, introducing specialized sponge-decorating protocols (*Schwämmeltechnik*) and high-temperature brown slip-glazing methodologies (*Braungeschirr*)⁵.

The technical lineage of Görzke descends directly from the Silesian potting center of Bunzlau (Bolesławiec)⁵. The Bunzlau tradition distinguished itself across Europe throughout the eighteenth and nineteenth centuries by intentionally abandoning toxic lead-oxide glazes in favor of high-fired, non-toxic, feldspathic clay slip glazes (*Bunzlauer Lehmglasur*)¹⁰. The Bunzlau potters recognized that while lead oxide fluxes permitted an early vitreous melt at low earthenware temperatures (750°C to 900°C), the resulting surfaces degraded rapidly and leached neurotoxic cations when exposed to acidic food matrices⁵. By utilizing fusible alluvial surface loams rich in iron, feldspar, and alkaline earths, Bunzlau workshops produced impervious, durable culinary vessels fired between 1200°C and 1300°C that were inert against lactic acid, acetic acid, and alcoholic beverages⁶.

Region and Production Center	Geological Mineral Base	Operational Peak	Technical Character and Primary Product Lines
Zehdenick & Mildeberg (Oberhavel)	Glaciolacustrine varved clay (<i>Bänderton</i>)	1888–1991	Low-refractory illitic-calcareous clay; Hoffman ring-kiln terra cotta; porous earthenware bricks ¹ .
Glindow (Werder/Havel)	Saalian/Weichselian carbonate silt clay	1716–1945	High-carbonate lacustrine clay (35%–38% CaCO_3); yellow-firing structural terra cotta; narrow vitrification range ³ .
Görzke (Hoher Fläming)	Decalcified basin clay and Fläming loam	1706–Present	Bunzlau-style utilitarian stoneware; lead-free <i>Lehmglasur</i> ; fermentation crocks, jugs, bowls ⁵ .
Spreewald Drainage Basin	Alluvial lowland clays; oak forestry reserves	14th–20th Century	Salt-glazed acid-resistant stoneware crocks; dairy crocks and vegetable lacto-fermentation vessels ¹⁴ .
Berlin Institute	Standardized	1876–1893	<i>Chemisches</i>

(Hermann Seger)	German industrial clays		<i>Laboratorium für Tonindustrie</i> ; formulation of Seger formulas and pyrometric slump cones ¹⁷ .
-----------------	-------------------------	--	---

The preservation of agricultural harvests across the North German Plain relied on these non-porous ceramic containers. In the Spreewald wetland basin, settled by Dutch reclamation engineers and Sorbian agrarian communities in the fourteenth century, vegetable harvests—particularly pickling cucumbers (*Cucumis sativus*)—required anaerobic storage vessels to sustain seasonal lactic acid brining¹⁴. While industrial barrel operations utilized hydrated white oak casks (*Eichenfässer*), domestic fermentation and pantry storage depended on cylindrical stoneware crocks (*Gärtöpfe*) equipped with integrated liquid water-channels¹⁴. These vessels prevented oxidation, excluded airborne spores of wild molds and oxidative film yeasts (*Pichia* and *Candida*), and resisted structural degradation from low-pH brines¹⁴. The scientific foundation of this regional pyrotechnology was consolidated by Hermann August Seger (1839–1893) at the *Chemisches Laboratorium für Tonindustrie* in Berlin¹⁷. Seger evaluated the thermal and mineralogical behaviors of Brandenburg clays, systematized the role of amphoteric, basic, and acidic oxides in high-temperature glass synthesis, and invented normalized pyrometric slump cones (*Segerkegel*) in 1886¹⁷. This provided ceramicists with an empirical, non-electrical method to measure accumulated thermal work inside the kiln, establishing a standard for firing stoneware and compounding durable glazes²⁴.

Regional Geology, Mineralogy, and Prospecting of Glacial Clays

Glaciolacustrine Sedimentation and Stratigraphy

The geomorphology of the Berlin-Brandenburg basin is defined by the morphogenetic succession of the Pleistocene epoch, shaped by the repeated advances and retreats of the Fennoscandian ice sheet during the Saalian and Weichselian glaciations⁴. As stagnant ice lobes melted, meltwater accumulated behind terminal push-moraines and sandur outwash plains, creating proglacial lakes (*Eisstauseen*)⁴. In these low-energy lacustrine environments, suspended mineral particles settled rhythmically, forming deposits of glaciolacustrine varved clay (*Bänderton*)⁴.

The stratigraphy of the primary clay belts around Zehdenick and Glindow displays distinct seasonal laminations (varves)⁴. Each annual varve comprises two discrete units:

1. A summer layer: light-colored, coarse-textured, containing high proportions of fine quartz silt (2 to $60\ \mu\text{m}$) and fine sand deposited during periods of active, turbulent glacial melting⁴.
2. A winter layer: dark-colored, dense, plastic, composed of ultra-fine colloidal clay

platelets ($< 2 \mu\text{m}$) that settled through the water column under a frozen, calm lake surface⁴.

These glaciolacustrine beds range from 2 to 20 meters in thickness, typically buried beneath 1 to 4 meters of periglacial cover sand, aeolian Arenosols, or Weichselian ground moraine (*Geschiebemergel*)⁴.

Mineralogical Phases and the Calcium Carbonate Limiting Factor


Brandenburg clays are heterogeneous mineral complexes dominated by three-layer (2:1) phyllosilicates, non-clay silica, and carbonate fractions⁴. Illite is the dominant clay mineral, accompanied by subsidiary kaolinite, minor smectite, detrital quartz, potassium and plagioclase feldspars, and iron oxides⁴.

Mineral Phase Constituent	Zehdenick Varved Clay (Bänderton)	Glindow Lacustrine Silt (Ziegellemm)	Görzke / Fläming Basin Potting Clay
Illite (2:1 Non-expanding)	45% – 55%	30% – 40%	40% – 50%
Kaolinite (1:1 Refractory)	10% – 15%	5% – 10%	20% – 30%
Smectite / Montmorillonite	5% – 10%	5% – 8%	3% – 5%
Quartz (Free SiO_2 Silt)	20% – 25%	20% – 25%	15% – 20%
Feldspars (K/Na/Ca Silicates)	5% – 8%	4% – 6%	5% – 8%
Iron Oxides (Fe_2O_3 / FeO)	4% – 7%	3% – 5%	2% – 4%
Calcium Carbonate (CaCO_3)	2% – 6%	20% – 38%	< 1.5%

Illite imparts moderate plasticity while acting as a natural flux during high-temperature firing¹².

The inter-layer potassium (K^+) cations within the illite lattice dissociate at elevated temperatures, lowering the eutectic melting point of the surrounding alumina and silica¹². The fundamental constraint of clays across the Berlin region is the concentration of calcium carbonate ($CaCO_3$)⁴. Analyses conducted by Hermann Seger demonstrated that the lacustrine clays of Glindow contain between 35.7% (upper yellow weathered horizon) and 38.2% (lower gray unweathered horizon) calcium carbonate¹³. This high calcite content originated from pulverized Cretaceous limestone and chalk beds scoured from the Baltic basin by the Fennoscandian ice sheet⁴.

The presence of calcium carbonate introduces specific pyrochemical behaviors. Below 900°C, the material behaves like a conventional clay. Between 850°C and 950°C, calcium carbonate undergoes endothermic calcination, expelling carbon dioxide gas:



In an oxidizing atmosphere around 950°C to 1000°C, the newly liberated calcium oxide (CaO) acts as a flux that reacts with red ferric oxide (Fe_2O_3) to form yellow-firing calcium-iron-silicates, specifically gehlenite ($Ca_2Al_2SiO_7$) and anorthite ($CaAl_2Si_2O_8$)³. This pyrochemical reaction produced the yellow architectural brick characteristic of Potsdam and Berlin (*Glindower gelbe Handstrichziegel*)³.

However, if an artisan fires this high-lime Glindow clay to stoneware vitrification temperatures (1150°C to 1250°C), the excess CaO triggers a rapid eutectic collapse⁴. Rather than exhibiting a broad, gradual sintering interval, the body softens, melts, and slumps into a vesicular glass within a narrow 20°C window⁴. Therefore, **Glindow clays are unsuited for vitrified stoneware bodies and must be restricted to low-fire porous earthenware or used as high-temperature flux additions in slip glazes**⁴.

To produce impermeable vitrified stoneware capable of holding liquids indefinitely, the potter must harvest from the lower-carbonate beds of the northern Zehdenick belt (where $CaCO_3$ levels range from 2% to 6%) or locate decalcified, highly weathered basin clays from the Fläming hills around Görzke⁴.

Field Testing Protocols for Unrefined Raw Clays

Before committing human and animal labor to extracting bulk deposits, four diagnostic assays must be conducted on unrefined field samples:

1. **The Acid Carbonate Assay:** A 20-gram dry core sample is treated with 5 ml of concentrated organic acid, such as raw pyroligneous acid derived from wood distillation or 10% cider vinegar³³. Immediate, vigorous effervescence of carbon dioxide bubbles indicates a carbonate content exceeding 5% by mass. Such clays must be rejected for

stoneware production, as they will slump at high temperatures⁴. Samples showing no reaction or faint micro-bubbling indicate carbonate levels below 2%, confirming their thermal suitability for stoneware trials.

2. **The Plasticity and Cohesion Ribbon Assay (Atterberg Approximation):** Saturated clay is rolled on a smooth hardwood board into a thin cylinder 3 mm in diameter¹². The cylinder is carefully looped around an artisan's finger. Highly plastic illitic clays will bend into a tight circle without transversal cracking¹². If the cylinder shears, fractures, or crumbles before completing a loop, the clay contains excess non-plastic silt and quartz sand, requiring levigation and blunging before wheel work¹².
3. **The Linear Drying Shrinkage Bar:** Plastic clay is pressed into a 150 mm × 25 mm × 10 mm wooden mold. A line measuring exactly 100 mm is inscribed into the wet face using a steel rule³⁴. The bar is dried slowly at 20°C until bone-dry. The distance between the scribe marks is measured:

$$\text{Linear Drying Shrinkage (\%)} = \frac{100 \text{ mm} - L_{\text{dry}}}{100 \text{ mm}} \times 100$$

A shrinkage value between 5% and 8% indicates a balanced ceramic body³⁵. Shrinkage exceeding 9% indicates high smectite content, which will cause severe cracking during desiccation unless tempered with grog or sand¹².

4. **The Test-Tile Vitrification and Absorption Assay:** Disks 50 mm in diameter and 8 mm thick are thrown, dried, and placed inside the hottest zone of the wood kiln. Following a firing to high heat (above 1200°C), the

vitrified test disk is weighed dry (M_{dry}), boiled in water for two hours, wiped dry of surface water, and re-weighed (M_{wet})³⁶:

$$\text{Water Absorption (\%)} = \frac{M_{\text{wet}} - M_{\text{dry}}}{M_{\text{dry}}} \times 100$$

If the absorption value falls below 2.5%, the clay body has achieved stoneware vitrification³⁶. If the disk shows bloated blisters, deformation, or excessive glass slumping, the deposit contains excessive flux and cannot stand high heat⁴.

Diagnostic Assay	Field Method	Pass Criterion	Failure Mode and Remediation
Acid Carbonate Test	5 ml wood vinegar or concentrated	Zero effervescence	Vigorous foaming indicates high

	acetic acid on dry clay core ³³ .	($\text{CaCO}_3 < $).	calcite ($\text{CaCO}_3 > $). Reject for stoneware bodies; reserve for slip glaze flux ⁴ .
Ribbon Plasticity Test	Roll clay to 3 mm cylinder; bend into loop around finger ¹² .	Smooth loop forms without transverse fracture ¹² .	Cylinder crumbles at $>$ diameter. Low plasticity; requires prolonged slaking, levigation, or blending ¹² .
Linear Shrinkage Bar	Scribe 100 mm gauge length on green test bar; dry to bone-dry ³⁴ .	Linear drying shrinkage between 5.0% and 8.0% ³⁵ .	Shrinkage $>$. High smectite/fat clay. Body requires 15%–25% grog or quartz sand temper to avert cracking ¹² .
Thermal Vitrification Assay	Fire test tile to target heat work ($> $); measure water uptake ³⁶ .	Tile rings when tapped; water absorption $< $ ³⁶ .	Tile melts, bloats, slumps, or shatters. Clay over-fluxed. Adjust with refractory kaolinitic sand or down-rate to low fire ⁴ .

Raw Clay Harvesting, Processing, and Body Formulation

Extraction Logistics and Frost-Weathering (*Ausfrieren*)

Clay harvesting must take place in late autumn, before frost consolidates the upper soil profile. Spades and mattocks are used to strip away the upper Arenosol sand and any humic overburden (typically 0.5 to 1.2 meters thick) to expose the uncontaminated argillaceous strata³. The clay is extracted in manageable blocks along natural horizontal bedding planes. The excavated clay cannot be worked immediately. It must undergo winter frost-weathering (*Ausfrieren*), an essential mechanical beneficiation process documented across historic Central European ceramic guilds³. The raw clay blocks are spread across sloped, well-drained timber

platforms or compacted clay beds in layers 200 to 300 mm thick, exposed directly to freezing winter temperatures, snow, and thaw cycles.

The physical mechanics of frost-weathering rely on the phase change of capillary pore water:

1. As water freezes within the interstitial micro-voids between clay platelets, it expands by approximately 9% in volume.
2. This volumetric expansion generates internal tensile stresses that fracture dense shale aggregates and break down compacted laminations without requiring mechanical grinding machines.
3. Concurrently, repeated freeze-thaw cycles leach out water-soluble salts (such as calcium sulfates and alkali chlorides) and oxidize metallic iron sulfides (pyrite, FeS_2), which are washed away by meltwater, preventing subsequent sulfur-gas bloating and efflorescence during firing.

Slaking, Levigation, and Mechanical Sieving

Raw clay slakes effectively only when it has been completely dried to a bone-dry state prior to water introduction¹². When moist clay is submerged, the existing surface water film retards capillary suction¹². When bone-dry clay nuggets (broken to sizes under 30 mm) are dropped into water, capillary action draws the liquid deep into the internal pore network, compressing the trapped air until the capillary walls rupture, disintegrating the aggregate into a fine slurry within 24 to 48 hours¹².

Levigation (*Schlämmen*) separates fine, plastic clay platelets from coarse quartz sand, gravel, and unweathered limestone nodules without industrial milling¹². A stepped, three-basin wooden sluice system is established. The blunged slurry is introduced into Basin 1 (the grit

trap). Coarse pebbles, gravel, and heavy quartz grains ($> 0.5 \text{ mm}$) drop out within minutes according to Stokes' law:

$$v = \frac{2}{9} \frac{(\rho_p - \rho_f)gr^2}{\eta}$$

where v is settling velocity, ρ_p is particle density, ρ_f is fluid density, g is gravitational acceleration, r is particle radius, and η is dynamic viscosity.

The fluid slip is decanted over a weir into Basin 2, where fine sand and silt settle over 2 to 4 hours. The remaining suspended liquor, consisting of fine illite and kaolinite colloids alongside ultra-fine silica silt, flows through a final 60-mesh to 80-mesh screen (woven horsehair or scavenged fine bronze wire cloth) into Basin 3 (the collection vat)⁴⁰. The slurry is transferred to canvas-lined dewatering trenches or shallow timber drying boxes until it reaches a plastic, kneadable consistency (moisture content of 22% to 26%)⁴¹.

Tempering: Sand vs. Calcined Grog (*Schamotte*)

Unrefined glaciolacustrine clay displays high plasticity and fine particle packaging, resulting in

excessive drying shrinkage (8% to 12%) and high vulnerability to drying stress fractures¹². To stabilize the body, non-plastic inclusions (temper) must be mechanically wedged into the matrix¹².

Temper Classification	Grain Size Distribution	Functional Behavior and Thermomechanical Impact
Washed Quartz Sand (Arenosol)	40–80 Mesh (0.18 to 0.42 mm)	Common glacial aggregate; jagged, sub-angular particles. Reduces drying shrinkage; introduces high thermal shock risk at 573°C due to quartz inversion expansion ¹² .
Fine Grog (Schamotte, Fine)	60–100 Mesh (0.15 to 0.25 mm)	Crushed, pre-fired stoneware sherds; chemically identical to body; zero drying shrinkage; low thermal expansion; optimized for wheel-throwing dinner plates and fine rims ⁴¹ .
Coarse Grog (Schamotte, Coarse)	10–30 Mesh (0.60 to 2.00 mm)	Heavy pre-fired fragments; provides structural scaffolding against wall sag during throwing; essential for large fermentation crocks and refractory kiln bricks ³⁴ .

Grog (Schamotte) is prepared by collecting clean, unglazed stoneware or hard-fired earthenware potsherds, firing them in a kiln to at least 900°C to ensure complete dehydroxylation, and pulverizing them with an iron pestle in a heavy timber mortar box¹². The pulverized material is dry-sieved through graduated wire screens to isolate target fractions. Grog is vastly superior to raw quartz sand. Because grog has already undergone firing shrinkage and chemical transformation, it possesses a low coefficient of thermal expansion, bonds with the surrounding clay matrix, and eliminates the destructive volumetric expansion associated with the alpha-to-beta quartz inversion at 573°C¹².

Ceramic Body Application	Plastic Base Clay Fraction	Temper Additions (Dry Mass Basis)	Performance Characteristics
Vitrified Fine Tableware (Plates, Bowls, Jugs)	75% Levigated Zehdenick Illite-Kaolinite Clay	15% Fine Grog (<), 10% Washed Fine Sand (0.1 to 0.2 mm)	Smooth throwing feel; low drag on hands; linear drying shrinkage 6.5%; fires dense and ringing at 1220°C ³⁹ .
Fermentation Crocks & Storage Vessels (<i>Gärtöpfe</i>)	65% Weathered Zehdenick or Fläming Clay	20% Coarse Grog (0.5 to 1.5 mm), 15% Fine Grog (<)	High green strength; resists wall sagging during vertical pulling; drying shrinkage 5.0%; thermal shock resistant ³⁴ .
High-Alumina Kiln Refractory Cob & Bricks	40% Coarse Local Sandy Clay	40% Coarse Grog (1.0 to 3.0 mm), 20% Chopped Straw/Chaff	Refractory; withstands direct flame impingement to 1300°C; low mechanical spalling; high insulative void space ¹⁵ .

Bacterial Aging and Souring (*Mauken*)

Once blended and wedged, the plastic clay is stored in cool, sunless conditions (such as a subterranean cellar) for a minimum of 30 to 90 days before forming³⁸. This aging process—known historically as *Mauken*—induces anaerobic bacterial proliferation within the moist clay matrix³⁸. Epiphytic bacteria metabolize residual organic matter, producing gelatinous humic and alginic acids.

These biochemical exudates act as natural colloidal deflocculants and plasticizers, breaking down clay mineral aggregates into individual microscopic platelets¹². The accumulation of colloidal gels increases moisture retention, enhances the green workability of the body, and allows the potter to throw thin-walled tableware profiles without premature structural collapse¹².

Mechanical Fabrication of a Human-Powered Potter's Kick Wheel

Throwing thin-walled tableware and heavy fermentation vessels requires continuous,

vibration-free angular momentum⁶. Reciprocating treadle wheels introduce cyclical lateral jolts to the spindle, creating uneven wall thicknesses in thrown cylinders. A heavy, direct-axis rotational kick wheel provides smooth, continuous torque.

Mechanical Component	Salvaged Material Source	Dimensions, Masses, and Working Tolerances
Structural Frame	Salvaged Oak or Pine Structural Timber	100 mm × 100 mm squared balks; mortise-and-tenon joints pinned with dried oak trunnels; 1200 mm long × 800 mm wide.
Central Vertical Shaft	Scavenged Steel Axle or Wagon Drive Shaft	Cold-rolled mild steel; Ø 30–35 mm solid round; length 950 mm; turned to a 60° conical point at base.
Lower Thrust Bearing	Hardened Tool Steel Cup & Punch	High-carbon punch seated in oak cross-member; filled with animal tallow or graphite grease; axial runout < ³³ .
Upper Collar Bearing	Lignum Vitae, Hard Oak, or Bronze Bushing	Split-block pillow design with through-bolts for wear adjustment; soaked in hot linseed oil/tallow; radial tolerance < ¹² .
Inertia Flywheel	Cast Concrete or Iron-Weighted Timber Ring	Mass: 45 to 60 kg; diameter: 800 mm; thickness: 80 mm; dynamically balanced to eliminate vibration at 150 RPM.
Potter’s Wheel Head	Dense Hardwood (Hornbeam, Beech, Oak)	Turned wooden disc; Ø 300 mm; 40 mm thick; treated with boiled linseed oil; trued

		on spindle using hand chisels ¹² .
Ergonomic Workstation	Split Softwood Timber	Sloped bench seat 450 mm above ground; distance to wheel center 400 mm; foot-reach arc clearance around flywheel 120 mm.

Dynamic Physics of the Flywheel

The operational efficiency of a kick wheel is determined by its moment of inertia (I). For a solid, uniform cylindrical flywheel of mass M and radius R :

$$I = \frac{1}{2}MR^2$$

For an 800 mm diameter flywheel ($R = 0.4 \text{ m}$) cast from dense concrete mixed with scrap iron punchings to achieve a mass of 55 kg:

$$I = 0.5 \times 55 \text{ kg} \times (0.4 \text{ m})^2 = 4.4 \text{ kg} \cdot \text{m}^2$$

The kinetic energy (E_k) stored at an operational rotational velocity of 120 RPM ($\omega = 12.57 \text{ rad/s}$) is:

$$E_k = \frac{1}{2}I\omega^2 = 0.5 \times 4.4 \text{ kg} \cdot \text{m}^2 \times (12.57 \text{ rad/s})^2 \approx 347.6 \text{ J}$$

This stored rotational energy provides sufficient angular momentum to throw an 8 kg clay cylinder for a 10-liter fermentation crock without requiring the potter to kick continuously during critical two-handed upward pulling passes⁶. The foot kicks the beveled perimeter of the flywheel smoothly, maintaining rotational speed through inertia while both hands shape the clay⁶.

Forming Protocols for Utilitarian Tableware and Fermentation Vessels

Every vessel intended for culinary service or anaerobic food preservation must be thrown,

turned, and assembled with precise shrinkage compensation. Because regional illite-kaolinite clays exhibit an average total linear shrinkage of 12% to 15% (combining plastic-to-dry shrinkage and firing sintering shrinkage), thrown dimensions must be enlarged by a factor of 1.14 to 1.18³⁵.

Vessel Typology	Clay Mass (Plastic)	Green Dimensions	Final Fired Dimensions	Functional Design Mandates
Dinner Plate (Fine Dining)	1.4 kg (Fine grog body)	Ø 285 mm, H 32 mm	Ø 245 mm, H 28 mm	Flat bottom; broad undercut foot-ring; rim angled 25° upward to retain sauces ¹² .
Soup / Stew Bowl	0.8 kg (Fine grog body)	Ø 185 mm, H 85 mm	Ø 160 mm, H 72 mm (Cap: 650 ml)	Parabolic curve; thickened rim bead to resist chipping ¹² .
Beverage Jug / Pitcher	1.8 kg (Fine grog body)	Ø 150 mm, H 260 mm	Ø 130 mm, H 225 mm (Cap: 1.8 L)	Pulled strap handle; sharp, anti-drip pulled spout lip.
5-Liter Fermentation Crock	4.2 kg (Medium grog body)	Ø 230 mm, H 310 mm	Ø 200 mm, H 265 mm (Cap: 5.0 L)	Deep water-seal gutter; paired lug handles; straight walls ²⁰ .
10-Liter Fermentation Crock	7.5 kg (Medium grog body)	Ø 295 mm, H 410 mm	Ø 255 mm, H 350 mm (Cap: 10.0 L)	Reinforced base; 50 mm water channel; paired split stones ²⁰ .
Fitted	1.6 kg (Medium	Ø 225 mm,	Ø 195 mm,	Inverted dome;

Water-Seal Lid (10L)	grog body)	Flange 45 mm	Flange 38 mm	deep flange clears water channel bottom ²¹ .
-------------------------	------------	--------------	--------------	--

Engineering the Anaerobic Fermentation Crock (*Gärtopf mit Wasserrinne*)

The vegetable fermentation crock is a specialized vessel. To maintain the obligate anaerobic environment required for spontaneous lactic acid fermentation—suppressing oxidative yeasts

(*kahm*) and aerobic molds while allowing biogenic carbon dioxide (CO_2) to escape—the rim must incorporate an integrated, concentric water channel (*Wasserrinne*)¹⁴.

The physical geometry of the rim consists of an inner cylinder wall and an outer concentric wall that form a continuous, flat-bottomed gutter. The lid is shaped as an inverted shallow dome with a downward vertical flange. When the flange rests inside the gutter and water is added, an airtight liquid seal is created²¹. Biogenic carbon dioxide generated by lactic acid bacteria builds positive pressure inside the vessel, bubbles outward through the water seal, and exits to the atmosphere¹⁴. Atmospheric oxygen cannot enter, maintaining an anaerobic state¹⁴.

The step-by-step production protocol for a 10-liter crock comprises seven phases:

1. **Centering and Opening:** Center 7.5 kg of de-aired medium-grog stoneware body onto a bat pinned to the wheel head³⁴. Open the mass to an internal base thickness of 15 mm³⁴. Compress the floor laterally using an oak kidney rib under heavy downward pressure to align phyllosilicate platelets and eliminate internal stress cracks (*S-cracks*).
2. **Pulling the Cylinder:** Draw the mass upward into a straight, vertical-walled cylinder across 4 to 5 deliberate passes. Maintain wall thickness at 12 mm throughout the lower and middle sections, tapering to 10 mm at the upper third. Establish an internal green diameter of 255 mm and height of 390 mm.
3. **Throwing the Integrated Water-Gutter:** The top 50 mm of the rim is not trimmed flat; instead, a thick collar of clay is formed at the terminal edge. Using the index finger supported by a rounded wooden tool, split this collar down the center to form a deep vertical groove. Open and expand this groove using a profile-turned wooden template into a flat-bottomed U-shaped channel measuring 30 mm wide and 45 mm deep²¹.
4. **Calibrating Rim Height Differential:** The inner lip of the water gutter must be thrown 5 to 8 mm lower than the outer lip. This differential is critical: if pressure fluctuations or vigorous gas evolution cause the water level in the channel to rise, excess liquid spills safely down the exterior of the crock rather than flooding inward into the vegetable brine, preserving the brine's precise salinity²¹.
5. **Forming Handles:** Pull two thick, oval-section strap handles from a separate wedge of the same clay body. Securely lute them to opposing sides of the upper cylinder body below the channel collar using cross-hatch scoring and clay slip²¹. Smooth the handle junctions with leather tools to eliminate crevices where food or bacteria could lodge.
6. **Throwing the Fitted Lid:** The lid is thrown upside-down as a shallow, flared bowl. The

outer edge terminates in a downward-projecting vertical flange measuring 45 mm in green depth. The outer diameter of this flange is turned to clear the internal walls of the crock's water-gutter by exactly 6 mm on all sides, accommodating firing shrinkage variations⁴⁴. Once leather-hard, the lid is inverted onto a chuck; a wide, hollow button knob is thrown directly onto the crown to provide a positive grip⁴⁴.

7. **Forming Split Weighting Stones (*Beschwerungssteine*):** The submerged vegetable pack must be held under the surface of the anaerobic brine by dense ceramic weights¹⁴. Roll a slab of coarse-grogged clay to an even thickness of 22 mm. Cut a circular disk with an outside diameter 25 mm smaller than the inside diameter of the fired crock⁴⁴. Pierce two 20 mm finger-holes through the body to facilitate retrieval from the brine. Cut the disc cleanly in half across its diameter to form a paired semi-circular set. Fire these stones unglazed to vitrification (1250°C) to ensure they are non-absorbent and chemically inert in lactic acid³⁴.

Controlled Desiccation and Sand-Bed Drying Schedules

The sandy soils of the Berlin-Brandenburg region (Arenosols) provide an abundant mineral medium for drying ceramic ware: pure, fine-grained quartz sand¹². Non-uniform evaporation of mechanical pore water generates differential capillary shrinkage, which is the primary cause of warped plate bases, out-of-round crock rims, and radial bottom cracks (*S-cracks*)¹².

Desiccation progresses through three distinct physical phases:

- Phase 1 (Saturated Plastic Body, 22% to 26% moisture content): A continuous hydrodynamic liquid film envelopes every clay platelet, providing high plastic mobility¹².
- Phase 2 (Critical Plastic Limit / Leather-Hard, 12% to 14% moisture content): Clay platelets contact one another; the capillary liquid meniscus retreats into internal micro-pores; volumetric drying shrinkage ceases entirely.
- Phase 3 (Bone-Dry Greenware, $< 3\%$ moisture content): Interstitial mechanical pore water has completely evaporated; only chemically bound hydroxyls remain within the phyllosilicate crystal lattice¹².

Sand-Bed Drying Technique

Flatware (dinner plates, platters) and broad-bottomed fermentation vessels cannot be dried directly on impermeable wooden boards or stone surfaces. As the vessel shrinks, the friction between the clay base and the stationary bench arrests lateral movement, placing the drying base in high tensile stress while the upper rim shrinks unhindered, resulting in severe bottom cracks¹².

To eliminate this friction, flatware and crocks are set upon a 15 to 25 mm bed of dry, washed,

fine-sieved quartz sand (0.2 to 0.4 mm grain size) spread over wooden drying shelves¹².

The spherical sand grains act as micro-ball bearings: as the clay base contracts, the sand grains roll beneath it, permitting friction-free, uniform lateral contraction.

Drying Phase	Duration	Ambient Temperature	Relative Humidity	Microclimate Management and Handling Protocols
Phase I: Slow Consolidation	48 to 72 Hours	16°C – 19°C	85% – 90%	Zero air drafts; vessels covered with damp linen cloth; slow, uniform evaporation ¹² .
Phase II: Leather-Hard Trimming	24 to 36 Hours	18°C – 22°C	70% – 75%	Linen removed; vessels inverted onto rim; foot rings turned with forged iron hoop tools ¹² .
Phase III: Equalization	4 to 6 Days	20°C – 24°C	50% – 60%	Gentle ambient cross-ventilation; resting on sand beds until light gray and rigid ¹² .
Phase IV: Pre-Kiln Desiccation	24 to 48 Hours	35°C – 45°C	< 30%	Stacked on warm timber decking directly above the cooling kiln to drive off residual pore moisture.


Non-Industrial Glaze Chemistry: Formulations and Pyrochemical Reactions

Tableware utilized for acidic culinary preparations (pickles, sauerkraut, vinegars, wine, dressed


salads) must present a vitrified, chemically non-reactive contact surface¹². Three non-industrial glaze systems can be achieved using indigenous regional materials: high-temperature wood-ash glazes, native clay slip glazes (*Lehmglasuren*), and atmospheric salt vapor glazes¹¹. Lead-based formulations must be systematically refused¹¹.

The Toxicological Imperative: Absolute Refusal of Lead Glazes

Low-fired lead earthenware glazes—utilized historically throughout Central Europe due to their low melting point (700°C to 850°C) and high gloss—rely on lead(II) oxide (PbO) as the primary fluxing agent¹². Litharge (PbO) or red lead (Pb_3O_4) reacts with silica (SiO_2) to form an easily fusible lead silicate glass:



The toxicological consequence of lead glazes in food-contact wares is severe¹². Lead silicate glasses are chemically unstable when exposed to organic food acids¹². Hydronium ions (H_3O^+) present in lactic acid ($\text{p}K_a = 3.86$), acetic acid ($\text{p}K_a = 4.76$), or citric acid attack the lead silicate network through an ion-exchange reaction:



The neurotoxic divalent lead cation (Pb^{2+}) leaches directly into the food matrix¹². Ingestion of food stored or served in lead-glazed earthenware causes chronic saturnism: neurodegenerative breakdown, motor dysfunction, abdominal colic, renal failure, anemia, and cognitive degradation¹².

Official food-safety directives (e.g., German Federal Institute for Risk Assessment / BfR; EU

Directive 84/500/EEC) impose a release limit of less than 4.0 mg/L for general ceramic containers and 1.5 mg/L for vessels intended for long-term storage⁴⁷. Artisanal wood-fired lead glazes frequently leach between 50 mg/L and 500 mg/L of Pb^{2+} under standard 4% acetic acid extraction assays, exceeding safe limits by orders of magnitude⁴⁷.

Consequently, lead formulations must be permanently prohibited.

High-Temperature Wood-Ash Glazes (*Holzscheglasuren*)

Wood combustion ash is an abundant non-industrial source of basic fluxing oxides, primarily calcium oxide (CaO), potassium oxide (K_2O), and magnesium oxide (MgO)⁴⁹.

Chemical Oxide	Mass Percentage in Washed Ash	Functional Role in Vitreous Melt
Calcium Oxide (CaO)	35% – 45%	Primary high-temperature basic alkaline earth flux (active above 1150°C) ⁴⁹ .
Potassium Oxide (K_2O)	5% – 12%	Alkaline flux; lowers initial sintering temperature; promotes gloss ⁴⁹ .
Silicon Dioxide (SiO_2)	15% – 25%	Primary acidic glass-former ⁴⁹ .
Aluminum Oxide (Al_2O_3)	4% – 8%	Refractory amphoteric stabilizer; prevents excessive glaze running ⁴⁹ .
Magnesium Oxide (MgO)	3% – 7%	High-temperature flux; produces a soft, satin-matte surface ⁴⁹ .
Ferric Oxide (Fe_2O_3)	1% – 3%	Colorant; yields olive-greens and celadons in reduction atmospheres ⁵⁰ .
Phosphorus Pentoxide (P_2O_5)	3% – 6%	Secondary glass-former; promotes opalescence and micro-phase liquid separation.

Raw wood ash contains high concentrations of soluble alkaline hydroxides and carbonates (potassium carbonate, K_2CO_3 , and sodium carbonate, Na_2CO_3)⁴⁹. If unwashed ash is utilized:

1. The caustic lye liquor ($\text{pH} > 12$) damages the potter's skin during glaze application⁴⁰.
2. The soluble alkalis deflocculate the clay slip, causing crawling, pinholing, or flaking during glaze drying⁴⁹.
3. The alkalis soak into porous greenware or bisqueware, causing efflorescence and uneven melting.

To wash the ash, mix raw ash with clean rainwater in a wooden barrel at a ratio of 1 part ash to 4 parts water⁴⁰. Stir vigorously, let the heavy mineral fraction settle for 10 minutes, and decant

the slurry through a 40-mesh screen into a second barrel to eliminate unburned charcoal, gravel, and nails⁴⁰. Allow the fine ash to settle for 48 hours. Siphon off the caustic amber-colored supernatant liquid (which can be reserved for lye soap production). Refill the barrel with fresh water, stir, settle, and siphon. Repeat this washing cycle three times until the water registers a near-neutral pH ($\text{pH} < 8.5$). Dry the settled ash sludge to a damp powder and pass through an 80-mesh sieve⁴⁰.

Ash alone does not contain sufficient silica (SiO_2) or alumina (Al_2O_3) to form a stable glass without running down the vessel walls⁴⁹. It must be compounded in a balanced triaxial formula:

Raw Material Component	Mass Percentage	Sege Unity Formula Role
Washed Hardwood Ash (Beech/Oak)	35%	Primary basic flux supplier (RO group: $\text{CaO}, \text{MgO}, \text{K}_2\text{C}$) ⁴¹ .
Crushed Feldspathic Granite or Glacial Silt	35%	Intermediate flux and alumina/silica donor ($\text{R}_2\text{O}, \text{Al}_2\text{O}_3, 6\text{SiO}_2$) ⁴¹ .
Levigated Local Clay (Zehdenick Illite)	15%	Alumina donor (stabilizer) and suspension binder ⁴¹ .
Fine Quartz Sand (Arenosol Outwash)	15%	Acidic glass-former (RO_2 group: SiO_2) ⁴⁰ .

When fired to 1250°C under a reducing wood atmosphere, this glaze fuses into a smooth, impervious olive-green to celadon glass with complete chemical resistance against food acids⁵⁰.

Indigenous Clay Slip Glazes (*Lehmglasuren* / Bunzlauer Braunzeug)

The hallmark of the regional Bunzlau and Görzke stoneware tradition is the high-fired slip glaze (*Lehmglasur*)⁵. This technique avoids complex mineral mining by utilizing fusible, iron-rich surface loams as the glaze vehicle¹⁰.

Unlike the underlying refractory stoneware body, which resists melting up to 1300°C, the slip clay is selected specifically for its natural content of fluxes: iron oxide (6% to $10\% \text{Fe}_2\text{O}_3$), potassium/sodium oxides (3% to 5%), and fine calcium/magnesium carbonates (5% to 10%)¹¹. The glaciolacustrine clays of the middle Havel basin or the upper horizons of

the Görzke deposits fulfill these criteria⁵.


Raw Material Component	Mass Percentage	Processing and Functional Contribution
Fusible Local Iron Clay (Glindow/Görzke)	75%	Fine-levigated through 100-mesh; acts as primary matrix, colorant, and flux donor ¹¹ .
Washed Hardwood Ash	15%	Boosts $\text{CaO}/\text{K}_2\text{C}$ to lower melting point and ensure complete melt at 1240°C ⁴¹ .
Finely Pulverized Quartz Flour	10%	Adjusts the SiO_2 : ratio to produce a glassy, non-crazing surface ⁵¹ .

The slip is blunged with water to a creamy viscosity (specific gravity 1.40 to 1.45 kg/L)¹¹. It is applied directly onto bone-dry greenware or low-bisqued ware by dipping or pouring¹¹. During the peak firing phase at 1250°C , the iron oxide acts as a powerful flux under reducing conditions (FeO), fusing the slip into a deep chestnut-brown or mirror-black impermeable glass that bonds into the underlying stoneware body without crazing or flaking¹¹.


Atmospheric Salt Vapor Glazing (*Salzbrand*)

Originating in the Rhineland during the twelfth century and practiced across Central Europe, salt glazing represents an atmospheric pyrochemical technique wherein the glaze is synthesized *in situ* at peak kiln temperature¹².

When the wood-fired kiln reaches the vitrification threshold of the silica-rich stoneware body (1220°C to 1260°C), coarse rock salt (sodium chloride, NaCl) is introduced directly into the active combustion chambers over the burning embers¹². At these temperatures, solid salt vaporizes rapidly. In the presence of water vapor from wood combustion, the sodium chloride dissociates:




The reactive sodium oxide (Na_2O) vapor drafts through the setting chamber, attacking exposed quartz and aluminosilicates on the vessel surfaces:



This reaction produces an integrated sodium aluminosilicate glass skin with high hardness, acid resistance, and a dimpled "orange-peel" surface texture caused by volatile micro-bubbles escaping during vitrification¹².

The chemical byproduct of the salt-glaze reaction is anhydrous hydrogen chloride gas (HCl)¹². Upon exiting the chimney into the atmosphere, HCl reacts with ambient humidity to form dense aerosol clouds of hydrochloric acid:



Hazard Parameter	Physiological and Environmental Consequence	Operational Protocols and Mitigations
Hydrogen Chloride Exhaust	Acute pulmonary edema; respiratory burns; severe eye irritation.	Kiln must be sited downwind, at least 200 m from dwellings and livestock. Operators must remain upwind and wear damp linen respirators ¹² .
Hydrochloric Acid Fallout	Foliar necrosis in crops; acidification of surface water; pine needle loss.	Salt firings scheduled only under brisk, dispersed wind conditions; never during still, humid, or thermal-inversion weather.
Refractory Attack & Slagging	Rapid melting of common clay, mortar, and low-fire bricks in the kiln structure.	Kiln interior, setting shelves, and chimney flues must be constructed from high-alumina, low-calcium firebrick and refractory cob ¹⁵ .

Kiln Pyrotechnology: Structural Design,

Aerodynamics, and Refractory Engineering

To fire ceramics without fossil fuels or electricity, the potter must build thermodynamic structures capable of concentrating wood combustion energy beyond 1200°C while resisting cyclic thermal shock³³.

An open pit fire or clamp kiln achieves temperatures between 650°C and 850°C¹². It exhibits highly irregular heat distribution and an uncontrolled, smoky reduction atmosphere, producing porous, non-vitrified cooking vessels and terra cotta¹². A cylindrical updraught kiln reaches 950°C to 1050°C with moderate heat uniformity, making it suitable for low-fire domestic earthenware and bisque firings⁴.

For impermeable, fully vitrified stoneware, the potter must construct a horizontal cross-draught kiln, historically represented by the *Kasseler Langofen* (Kassel Long Kiln)¹⁵. This design achieves temperatures between 1200°C and 1300°C, provides even soaking across the setting beds, and permits precise atmospheric control for reduction, oxidation, and salt glazing⁶.

The Kasseler Cross-Draught Kiln (*Kasseler Langofen*)

The *Kasseler Langofen* consists of a horizontal, barrel-vaulted chamber situated between a deep primary firebox at the front and a tall chimney stack at the rear¹⁵.

Flames originate in the primary firebox, rise over a refractory firebridge wall (*Feuerbrücke*), sweep horizontally through the stacked pottery in the ware chamber, pass through collection ports at the base of the rear wall, and exit through the chimney stack¹⁵. This horizontal cross-draught path forces the thermal energy to soak through the ware beds before escaping, achieving high fuel efficiency¹⁵.

The natural draft of a kiln stack (ΔP) is governed by the chimney height (H) and the density differential between cold ambient air (ρ_{ambient}) and buoyant exhaust gases (ρ_{exhaust})¹⁶:

$$\Delta P = H \cdot g \cdot (\rho_{\text{ambient}} - \rho_{\text{exhaust}})$$

where $g = 9.81 \text{ m/s}^2$, and gas density is inversely proportional to absolute temperature (T_{Kelvin}).

To maintain steady draft against the frictional resistance of the packed ware chamber without pulling excess cold air into the combustion zone, four proportional rules must be maintained:

- Chimney Height (H): A minimum of 5.0 to 6.0 meters measured from the flue floor to the top of the stack¹⁶.
- Chimney Flue Cross-Sectional Area: Formulated at 20% to 25% of the total cross-sectional area of the setting chamber. For a setting chamber measuring

1.0 m wide $\times$ 1.1 m high (cross-sectional area $\approx 1.1 \text{ m}^2$), the internal chimney flue cross-section must be:

$$A_{\text{flue}} \approx 1.1 \text{ m}^2 \times 0.22 = 0.242 \text{ m}^2 \implies 490 \text{ mm} \times 490 \text{ mm}$$

- Firebox Sizing: The internal volume of the firebox must equal 40% to 50% of the ware chamber volume¹⁵. For a 2.0 m^3 setting chamber, the firebox must provide an effective combustion volume of 0.8 to 1.0 m^3 .
- Firebridge Wall (*Feuerbrücke*): Constructed between the firebox and the ware chamber, rising to 60% to 65% of the ceiling height¹⁵. This wall directs the flames into the crown of the vault before they pass horizontally through the pottery, preventing direct flame impingement and localized hot spots¹⁵.

Structural Kiln Layer	Material Composition and Compounding	Thickness	Thermophysical and Structural Role
Hot-Face Interior Lining	High-alumina salvaged firebrick (<i>Schamotte</i>) or dense low-calcium brick ⁴³ .	115 mm (Half-brick width)	Direct flame contact; refractory to 1350°C; low spalling; mortared with 50% kaolin / 50% grog slip ²⁸ .
Intermediate Thermal Mass	Sandy regional clay mixed with 50% coarse grog ⁴³ .	100 mm	Structural backing; absorbs lateral vault expansion thrust; bridges hot face to insulation ⁴³ .
Exterior Insulating Cob	Earthen cob composite: 30% clay, 40% sand, 30% chopped straw (<i>Lehm-Stroh</i>) ⁴³ .	150–200 mm	Low thermal conductivity; entrapped air voids limit outer skin temperature below 70°C ⁴³ .

Foundation Thermal Break	Compacted gravel base topped with dry-laid brick hearth ³³ .	300 mm	Prevents subterranean moisture migration into the kiln floor; arrests ground heat sinking ³³ .
--------------------------	---	--------	---

Wood Firing Protocols, Pyrometry, and Atmospheric Control

Wood combustion firing transforms green clay into vitrified ceramic through a series of temperature-dependent physical and mineralogical reactions¹².

Between 20°C and 150°C, mechanical pore water evaporates endothermically, requiring slow heating and open dampers to avoid explosive steam expansion¹². Between 450°C and 650°C, chemically bound hydroxyl ions are expelled from the phyllosilicate lattice (dehydroxylation),

converting kaolinite into metakaolin ($\text{Al}_2\text{O}_3 \cdot 2\text{SiO}_2$) and permanently destroying plasticity¹².

At exactly 573°C, crystalline quartz undergoes the alpha-to-beta quartz inversion, expanding volumetrically by 1.5%¹². The kiln temperature must be held steady through this threshold to prevent thermal shock fractures¹².

Between 700°C and 900°C, residual carbonaceous matter and pyritic sulfur burn out under oxidizing conditions¹². Between 1000°C and 1150°C, low-fire sintering begins as alkali fluxes melt¹². Between 1200°C and 1280°C, full vitrification takes place: extensive liquid phase

sintering closes the pore network, and acicular mullite crystals ($\text{Al}_6\text{Si}_2\text{O}_{13}$) grow to form an impermeable, mechanically durable matrix¹².

Firing Schedule for a 2.0 m³ Kasseler Kiln

The fuel used across the North German Plain is Scots Pine (*Pinus sylvestris*, German: *Gemeine Kiefer*), supplemented by dense hardwoods (birch, oak) during the final high-temperature soaking phase³³. Pine burns with a long, luminous, resinous flame that carries heat through the dense setting of a cross-draught kiln³³.

Elapsed Time	Internal Temperature	Heating Rate	Atmosphere & Draft	Stoking Methodology and Fuel Selection
Hours 0–6	20°C to 150°C	~20°C/hr	High excess air; damper	Small kindling fire on ash pit floor; thick split

			fully open	pine logs (>) pre-warming ³³ .
Hours 6–12	150°C to 500°C	~60°C/hr	Strongly oxidizing; draft clear	Medium split pine (50 mm); active combustion; firebox door cracked open to admit primary air.
Hours 12–14	500°C to 650°C	~50°C/hr	Neutral; hold steady at 573°C	Careful feeding through 573°C quartz inversion; steady ember bed; no thermal spikes ¹² .
Hours 14–20	650°C to 1050°C	~65°C/hr	Neutral to light reduction	Heavy stoking cycles every 12–15 minutes; ember bed built to 300 mm depth.
Hours 20–24	1050°C to 1200°C	~40°C/hr	Active cyclic reduction (CO =)	Split pine (30–40 mm); firebox closed for 8 mins after stoking (reduction), cleared for 4 mins ³³ .
Hours 24–27	1200°C to 1260°C	~20°C/hr	Strong reduction / salt	Split dry pine and oak slabs;

			vapor	salt introduced at hour 26 if salt-glazing ¹² .
Hour 28	1260°C Peak Soak	Zero temperature rise	Sealed atmosphere	Final 60-minute soak; all air intakes, dampers, and spy-holes sealed with clay-sand mortar.
Cooling (36–48 hrs)	1260°C down to 80°C	Passive descent	Hermetic seal	Kiln remains sealed for two full days; premature opening causes catastrophic dunting fractures!

Pyrometric Evaluation Without Electronic Instrumentation

In a post-industrial setting, electronic thermocouples and digital pyrometers are unavailable. The firing crew must measure accumulated heat-work using optical incandescence, draw rings (*Brennproben*), and self-formulated pyrometric slump cones (*Seegerkegel*)¹⁷.

Optical incandescence provides continuous visual monitoring through spy-holes:

- Incipient Dark Red (500°C–550°C): Ware is barely visible in darkness; quartz inversion threshold.
- Dark Cherry Red (700°C–800°C): Carbon burn-off is underway; metakaolin formation¹².
- Bright Cherry Red (850°C–950°C): Calcite decomposition; low earthenware maturation⁴.
- Orange to Salmon (1000°C–1080°C): Earthenware sintering; upper limit for high-carbonate Glindow clays⁴.
- Light Orange to Straw Yellow (1100°C–1180°C): Incipient stoneware sintering; ash glazes begin to melt³⁶.
- Brilliant Straw Yellow (1200°C–1250°C): Full stoneware vitrification; slip glazes fuse into glass¹⁰.
- Incandescent White ($> 1300^{\circ}\text{C}$): Severe risk of structural collapse and overfiring⁵⁷.

Draw rings (*Brennproben*) provide direct physical verification during the firing⁶⁴. A series of

small, donut-shaped rings thrown from the body clay and coated with glaze are set adjacent to the spy-hole⁶⁴. During the high-fire phase, an iron rod with a hooked end is inserted to extract a ring⁶⁴. The ring is dropped into an iron bucket to cool quickly, allowing the master potter to inspect:

1. Vitrification and glass fusion: has the slip or ash glaze melted into a smooth, non-gritty layer?
2. Bubble clearance: has outgassing ceased, or does the surface exhibit boiling pinholes?
3. Body densification: the fracture surface is examined with a loupe to confirm vitrification.

Self-formulated pyrometric slump cones (*Segeberkegel*) provide standardized thermal measurement¹⁷. The potter compounds 60 mm high, three-sided truncated pyramids from local minerals²⁴. These cones deform plastically and bend when the required heat-work (temperature and time) is achieved²⁴:

Equivalent Cone	Nominal Slump Temp	Raw Mineral Compounding Formulation (Dry Mass Basis)
Cone 04 (Bisque/Earthenware)	1060°C	50% Glindow Calcareous Clay, 30% Quartz Sand, 20% Hardwood Ash ³² .
Cone 6 (Early Stoneware)	1220°C	40% Feldspathic Granite Silt, 30% Zehdenick Illite Clay, 20% Quartz Sand, 10% Hardwood Ash ⁴¹ .
Cone 9 (Stoneware Climax)	1280°C	35% Pure Kaolin/Fläming Ball Clay, 35% Feldspathic Granite, 25% Quartz Sand, 5% Hardwood Ash ⁴¹ .

A standard cone pack consists of three cones mounted side-by-side in a clay strip, angled at 8° from vertical:

- The Guide Cone (Cone 6): Bends first, alerting the crew that the kiln is within 40°C of peak heat⁶⁶.
- The Target Cone (Cone 9): When its tip bends over to touch the mounting plaque, heat-work is complete and firing ceases²⁶.
- The Guard Cone (Cone 10): Remains upright; if it deforms, the kiln has overfired, risking vessel collapse⁶⁶.

Vitrified Stoneware vs. Porous Earthenware: Food

Safety, Porosity, and Hygiene

For culinary service and long-term food preservation, the physical distinction between earthenware (*Irdenware*) and stoneware (*Steinzeug*) is fundamental³⁴.

Physical Property	Low-Fired Earthenware (900°C–1050°C)	Vitrified Stoneware (1200°C–1280°C)
Fired Bulk Density	1.8 to 2.1 g/cm ³	2.3 to 2.5 g/cm ³
Water Absorption (Porosity)	8.0% to 18.0% (Capillary permeable) ⁶⁷	0.5% to 2.5% (Impermeable vitreous body) ³⁶
Microstructural Sintering	Particle bonding; open interstitial pore network ³⁶ .	Vitreous liquid phase fill; interlocking mullite needles ($\text{Al}_6\text{Si}_2\text{O}_{13}$) ³⁶ .
Modulus of Rupture (Strength)	30 to 50 MPa (Prone to chipping and impact fracture)	70 to 110 MPa (High impact resistance; metallic ring) ³⁹ .
Acid and Brine Resistance	Degrades in low-pH organic acids (lactic, acetic) ¹² .	Chemically inert against boiling organic and mineral acids ¹¹ .

The Physical and Biological Hazards of Porous Earthenware

In vegetable lacto-fermentation (sauerkraut, brined pickles), the brine is characterized by lactic acid (pH 3.2 to 3.8), acetic acid, and 2.5% to 3.0% sodium chloride (NaCl)¹⁴.

If porous earthenware is used for fermentation or dairy storage:

- Capillary Brine Seepage:** The continuous open pore network draws acidic brine deep into the vessel wall via capillary suction. The brine wicks to the exterior surface, where water evaporates and leaves behind sodium chloride and calcium sulfate crystals (efflorescence). This sub-surface crystallization generates crystallization pressure ($> 50 \text{ MPa}$) inside the pores, spalling the clay surface and flaking off interior glazes.
- Glaze Crazing and Pathogen Colonization:** Because earthenware bodies possess a lower coefficient of thermal expansion than simple siliceous glazes, the glaze crazes, forming networks of fine cracks¹². Pathogenic bacteria (*Escherichia coli*, *Listeria monocytogenes*), bacterial spores, and spoilage fungi lodge within these fissures, protected from mechanical washing¹².
- Biofilm Entrapment and Lipid Rancidity:** Trapped milk fats from dairy service or

vegetable oils soak into the open ceramic pores and oxidize, producing rancid off-flavors that taint subsequent preparations¹². These sub-surface biofilms resist chemical and hot-water sanitization¹².

4. **Mycotoxin Accumulation:** Saturated, porous ceramic walls provide a hospitable substrate for fungal mycelia (such as *Aspergillus* and *Penicillium* species). These molds can synthesize carcinogenic mycotoxins (e.g., aflatoxins, ochratoxin A, patulin) that leach into stored foodstuffs.

Vitrified stoneware fired to 1250°C eliminates open capillary pores, keeping water absorption below 2.5% (and below 1.0% when coated with a slip or salt glaze)³⁶. The body behaves like granite: non-absorbent, hygienic, capable of scalding washouts with boiling water and lye, and chemically unreactive with organic acids⁶. **Tableware and fermentation crocks intended for food preservation must be fired to stoneware vitrification¹¹.**

Ceramic Pathology: Structural Failure Modes, Diagnostics, and Remediation


High-temperature ceramic production using unrefined wild clays presents distinct thermomechanical and mineralogical failure modes¹².

Structural Failure Mode	Visual and Tactile Morphology	Underlying Physical / Chemical Mechanism	Preventive Remediation Protocol
S-Cracks & Base Checking	S-shaped or radial fissures across bottom of plates and crocks ³⁴ .	Differential capillary drying shrinkage; uncompressed floor; base friction ¹² .	Compress wheel-thrown base firmly with wooden rib; dry flatware on sand beds; slow drying under linen ¹² .
Cooling Dunts (Thermal Shock)	Razor-sharp, clean tensile cracks through body and glaze ¹² .	Rapid cooling through 573°C quartz inversion or 220°C cristobalite shift ¹² .	Keep kiln sealed hermetically until internal temperature falls below 80°C; do not crack dampers early ¹² .
Glaze Crawling & Beading	Glaze pulls back into isolated islands,	High glaze drying shrinkage (excess	Wash wood ash thoroughly to


	exposing bare clay beneath ⁴⁹ .	raw clay); unwashed ash; dusty bisqueware ⁴⁹ .	remove soluble lye; calcine part of the glaze clay; clean bisqueware ⁴⁰ .
Lime Popping (<i>Kalkspatzen</i>)	Conical flakes spall off vessel surfaces days post-fire, revealing white core ³⁴ .	Post-fire hydration of calcined lime nodules ($\text{CaO} + \text{H}_2\text{O} \rightarrow$) with 300% volume expansion.	Wet-sieve raw clay through 80-mesh screen; or cold-water quench hot pots at 100°C draw ⁴⁰ .
Core Bloating & Vesiculation	Blisters and swellings on thick walls; internal black vesicular glass ⁴ .	Trapped carbon/sulfur gases expanding after surface pores have vitrified ⁴ .	Fire slowly between 700°C–900°C under oxidizing conditions before closing dampers ⁴ .

Elimination of Lime Popping (*Kalktreiben*)

Given the high calcium carbonate content of Brandenburg drift clays, *Kalktreiben* is a frequent cause of structural failure⁴. When coarse chalk or limestone fragments ($> 0.5 \text{ mm}$) remain in the clay body, they calcine during firing to calcium oxide (CaO)³:



After firing, as the vessel sits in an ambient environment, moisture vapor from the air diffuses into the ceramic. The embedded CaO nodules hydrate into calcium hydroxide (Ca(OH)_2):



This hydration reaction involves a **300% volumetric expansion**. Because the surrounding ceramic matrix is rigid, this localized expansion generates internal shear stresses, blowing conical flakes of ceramic (*Kalkspatzen*) off the vessel wall³⁴.

Two non-industrial protocols prevent lime popping:

1. **Mechanical Levigation and 80-Mesh Sieving:** Passing the raw clay slurry through an 80-mesh ($177 \mu\text{m}$) screen eliminates large limestone grains⁴⁰. Calcite particles smaller

than $150\ \mu\text{m}$ do not exert sufficient localized force to crack the ceramic wall upon hydration; instead, they dissolve into the surrounding glass matrix as microscopic fluxes⁴⁹.

2. **Cold Water Quenching:** Upon opening the kiln while the ware is still hot (around 100°C), vessels can be dipped into a vat of cold water. Rapid hydration while the clay matrix is under slight thermal expansion allows micro-lime nodules to dissolve without fracturing the surrounding ceramic.

Quantitative Labor, Fuel, and Operational Budgets

Transitioning from an individual homestead of four persons to an agrarian community of 300 individuals requires scaling from small, intermittent batches to seasonal production campaigns aligned with regional agricultural rhythms.

Vessel Typology and Application	Household Units (4 Persons)	Total Clay Mass (Dry)	Throwing & Turning Labor	Total Labor (Harvest to Fire)
Wide Dinner Plates (Fine Dining)	8 units	11.2 kg	4.0 hrs	12 hrs
Deep Soup / Stew Bowls	8 units	6.4 kg	2.5 hrs	8 hrs
Service Platters & Large Bowls	4 units	6.0 kg	2.5 hrs	6 hrs
Drinking Pitchers & Water Jugs	4 units	7.2 kg	3.0 hrs	9 hrs
Table Cups / Beakers	8 units	3.2 kg	2.0 hrs	6 hrs
10-Liter Fermentation Crocks (Sauerkraut)	2 units (with lids/stones)	15.0 kg	5.0 hrs	16 hrs ¹⁴

5-Liter Fermentation Crocks (Pickles)	2 units (with lids/stones)	8.4 kg	3.5 hrs	11 hrs ¹⁴
Lidded Storage Jars (Pantry Stores)	6 units	15.0 kg	4.5 hrs	14 hrs
TOTAL HOUSEHOLD REQUISITE	42 vessels	72.4 kg Dry Clay	27.0 hrs	82.0 Labor Hours

Community Production Scaling (300 Persons)

For an agrarian micro-community of 300 persons, ceramic containers are necessary for both daily food service and seasonal harvest preservation.

Production Category for Community of 300	Target Quantity	Total Dry Clay Mass Required	Kiln Volume Equivalents
Individual Table Settings (Plates, Bowls, Cups)	1,200 units	1,250 kg	5 Firing Loads (2.0 m ³ Kiln)
Communal Platters, Pitchers, and Serving Bowls	250 units	450 kg	2 Firing Loads
15- to 20-Liter Bulk Sauerkraut Crocks	80 units	960 kg	2 Firing Loads
10-Liter Brine Pickle and Root Vegetable Crocks	120 units	900 kg	2 Firing Loads
Lidded Bulk Storage Jars (Lard, Grains, Dried Pulses)	200 units	800 kg	1 Firing Load

TOTAL COMMUNITY INVENTORY	1,850 ceramic vessels	4,360 kg (4.36 metric tons)	12 Firing Loads (2.0 m ³ Kiln)
---------------------------------	--------------------------	--------------------------------	---

Quantitative Fuel Physics and Wood Consumption

The fuel requirements for firing high-temperature stoneware in a 2.0 m³ Kasseler cross-draught kiln depend on the lower heating value (LHV) of regional Scots Pine (*Pinus sylvestris*)³³.

Air-dried pine seasoned for 12 months in the Brandenburg climate achieves an equilibrium moisture content of 15%, providing an energy density of:

$$LHV \approx 4.32 \text{ kWh/kg} \quad (15.55 \text{ MJ/kg})$$

One stacked cubic meter (*Raummeter* or stere, abbreviated ^{rm}) of split pine firewood weighs approximately 420 kg/^{rm} at 15% moisture content³³. The total chemical thermal energy per *Raummeter* is:

$$E_{\text{stere}} = 420 \text{ kg} \times 15.55 \text{ MJ/kg} \approx 6,530 \text{ MJ} \quad (1,814 \text{ kWh})$$

A 28-hour firing of a 2.0 m³ Kasseler kiln to Cone 9 (1260°C)—accounting for heat absorbed by the refractory masonry (2,200 kg of firebrick and cob), water vaporization enthalpy, flue gas draft losses, and external conduction—consumes between **3.5 and 4.5 Raummeter (stere)** of seasoned pine wood¹⁵.

Firing Phase	Duration	Wood Volume (rm)	Fuel Mass & Stoking Frequency
1. Water Smoking (20°C–150°C)	6.0 hrs	0.5 rm (210 kg)	Large slow-burning split logs; 1 stoke every 30 min ³³ .
2. Low Fire	8.0 hrs	0.8 rm (336 kg)	Medium split pine (50 mm); 1 stoke

(150°C–650°C)			every 15 min.
3. High Ramp (650°C–1150°C)	6.0 hrs	1.0 rm (420 kg)	Fine split pine; primary ember bed; 1 stoke every 10 min.
4. Vitrification Climax (1150°C–1260°C)	8.0 hrs	1.7 rm (714 kg)	Split dry pine and oak slabs; continuous stoking every 4 to 6 min ⁵⁷ .
TOTAL PER KILN RUN	28.0 Hours	4.0 rm (1,680 kg)	Yields ~180 to 220 tableware pieces OR ~16 to 20 large fermentation crocks.

To complete the community-scale inventory of 1,850 vessels, the pottery requires **11 to 12 kiln firings**, consuming a total fuel volume of **44 to 48 Raummeter** of split pine firewood³³. Within the regional silvicultural context, this volume can be harvested sustainably from 1.0 to 1.5 hectares of Scots pine coppice-with-standards woodland, an established annual yield on the Arenosols of Brandenburg³³.

Seasonal Operational Phase	Allocated Labor Hours	Execution Window in Agricultural Calendar
Clay Prospecting and Bulk Extraction	120 hrs	Late Autumn (October–November, prior to ground freezing) ³ .
Clay Frost-Weathering, Slaking & Sieving	160 hrs	Early Spring (March–April, post-thaw) ¹² .
Grog Preparation, Sand Sieving & Wedging	100 hrs	Spring (April–May) ¹² .
Wheel Throwing, Handle Pulling & Trimming	280 hrs	Late Spring / Early Summer (May–June) ⁶ .

Sand-Bed Desiccation Management	60 hrs	Summer (June–July, ambient sun/wind drying) ¹² .
Glaze Compounding (Ash Washing, Slip Blending)	80 hrs	Mid-Summer (July) ⁴⁰ .
Fuelwood Felling, Splitting & Stacking	100 hrs	Winter / Early Spring (Integrated with forestry tasks) ³³ .
Kiln Loading, Firing (12 Runs) & Maintenance	80 hrs	Late Summer / Early Autumn (August–September, pre-harvest) ⁵⁷ .
TOTAL ANNUAL POTTERY LABOR	980 Person-Hours	Equivalent to ~0.5 full-time specialized labor allocation across the community.

Regional Ceramic Integration

The long-term cultural and nutritional stability of an agrarian settlement operating without industrial inputs requires the conversion of surrounding geological and biological resources into functional material culture¹². In the Berlin-Brandenburg basin, agricultural soil ratings are low (25 to 40 points on the *Ackerwertzahl* scale), yet the post-glacial geology provides raw mineral assets: workable illite-kaolinite clays in the varved beds of Zehdenick, pure quartz sands for body tempering and friction-free drying beds, and resilient Scots pine forests that yield high thermal energy⁴.

By adapting the regional technical traditions of Bunzlau, Görzke, and the Spreewald—rejecting unstable, low-temperature lead glazes in favor of high-fired native clay slips (*Lehmglasuren*), washed wood-ash glasses, and atmospheric salt vapors—an expanding agrarian community secures an unbroken chain of food safety and culinary culture⁶.

The resulting domestic table and communal kitchen are furnished not with porous, contaminating earthenware, but with fully vitrified stoneware: chemically inert, impermeable to organic acids, and engineered to endure generations of culinary service and lactic acid food preservation¹².

Works cited

1. Ziegeleipark Mildenberg - Wikipedia, https://de.wikipedia.org/wiki/Ziegeleipark_Mildenberg
2. Zehdenicker Tonstichlandschaft – 9-km-Runde durch 60, <https://brandenburgblog.de/natur/zehdenicker-tonstichlandschaft-wanderung/>

3. Ziegeleien - Petzow, <https://petzow-online.de/ziegeleien/>
4. Untitled - LBGR Brandenburg, https://lbgr.brandenburg.de/sixcms/media.php/9/BGB-1_95_Hoeding_105-112.pdf
5. Geschichte der Töpferei Heinitz in Görzke, <http://www.toepferei-heinitz.de/geschichte.html>
6. Startseite - Töpferei P & P Ludwig, <https://toepferei-ludwig.de/>
7. Töpferort Görzke - Startseite, <http://www.toepferort-goerzke.de/>
8. Töpferei Ludwig seit 1746 - Peter Ludwig - Töpferort Görzke, <http://www.toepferort-goerzke.de/verzeichnis/visitenkarte.php?mandat=16299>
9. Töpferei Peter Ludwig, Fläming, Görzke - Reiseland Brandenburg, <https://www.reiseland-brandenburg.de/poi/flaeming/handwerk-und-manufaktur/n/toepferei-peter-ludwig/>
10. Lehmglasur, Braungeschirr - CERAMICA CH, <https://ceramica-ch.ch/glossary/braungeschirr/>
11. Lehmglasur - keramiko.de, <https://keramiko.de/lexikon/lehmglasur/>
12. 116 Crafting Civilized Dining Experiences.pdf
13. Die nutzbaren Gesteine Deutschlands - Kaolin, Ton, Sand, Kies, http://www.horsthartwig.de/die_nutzbaren_gesteine_deutschlands_lagerstaetten_dienemann_1928.pdf
14. 114 Traditional Fermented Pickle Recipe.pdf
15. Der Kasseler Ofen - Die Geschichte der Töpferei Langerwehe, <https://www.toepferei-langerwehe.de/wir-ueber-uns/der-kasseler-ofen.html>
16. Schornstein - Welche Größe ist richtig? | kamdi24-Technikratgeber, <https://www.kamdi24.de/technikratgeber/technik-tipps-und-tricks/allgemeines-zu-kaminen-und-oefen/hoehe-und-durchmesser-des-schornsteins>
17. Tonindustrie-Zeitung - Deutsche Digitale Bibliothek, <https://www.deutsche-digitale-bibliothek.de/item/IOQG5TX4JPQVPBWA6SLSGBXW2Q36LFOE>
18. Seger, August Hermann - Deutsche Biographie, <https://www.deutsche-biographie.de/gnd172742137.html>
19. Segerkegel :: Ofen- und Keramikmuseum Velten, <https://brandenburg.museum-digital.de/object/4838>
20. Gärtöpfe - MS-Steinzeug, <https://www.ms-steinzeug.com/de/gaertoepfe/>
21. Steingut-Gärtopf 10 l mit Wasserrinne und Deckel - Browin, <https://browin.de/shop/Produkt/771410/steingut-gartopf-10-l-mit-wasserrinne-und-deckel>
22. 93 Vegetable Lacto-Fermentation Process.pdf
23. Segerformel - Keramik Art Craft, <https://keramikartcraft.info/?encyclopedia=segerformel>
24. Segerkegel - Lexikon der Chemie - Spektrum der Wissenschaft, <https://www.spektrum.de/lexikon/chemie/segerkegel/8353>
25. Kegel oder Ringe - was ist genauer? - kalkspatz e.V. - Keramik-Forum, <https://www.kalkspatzforum.de/viewtopic.php?t=3529>
26. Segerkegel R 9, 1255 °C - Keramikbedarf-online.de, <https://shop.keramikbedarf-online.de/Segerkegel-R-9-1255-OC/6-64-9>

27. Bänderton - Chemie.de, <https://www.chemie.de/lexikon/B%C3%A4nderton.html>
28. Bänderton - Wikipedia, <https://de.wikipedia.org/wiki/B%C3%A4nderton>
29. 2025 - Ton - Geo-Naturpark Frau-Holle-Land, <https://www.naturparkfrauholle.land/geologie/gestein-des-jahres/2025-ton>
30. Tonmineralogie - Dr. Krakow Rohstoffe, <https://www.dr-krakow-labor.de/tonmineralogie>
31. Tonminerale geben den Ton an – Teil III - tonbergbau.blog, <https://www.tonbergbau.blog/tonminerale-geben-den-ton-an-teil-iii/>
32. Ziegeleien im Raum Brandenburg a. H. – BeetzSee, Plauer See, http://www.horsthartwig.de/ziegeleien_regionen_brandenburg_opti.pdf
33. 3 - Traditional Blacksmith Charcoal Clamp Guide.pdf
34. Das Material Ton | Atelier Hoda, <http://www.atelierhoda.at/das-material-ton/>
35. Wie viele Tage sollte Ton vor dem Brennen trocknen?, <https://xn--tpfern-wxa.shop/blogs/news/wie-viele-tage-sollte-ton-vor-dem-brennen-trocknen>
36. Wasserdichte Keramik - keramiko.de, <https://keramiko.de/lexikon/wasserdichte-keramik/>
37. Brenntemperatur von Ton erkennen? - kalkspatz e.V. - Keramik-Forum, <https://www.kalkspatzforum.de/viewtopic.php?t=8840>
38. Infos Rund um Ton – Keramikbedarf Zinser, <https://www.keramikbedarf-zinser.de/infos-rund-um-ton/>
39. Unterschied Steinzeug, Steingut, Teracotta & Porzellan, <https://keramik-kartell.de/ton/steinzeug-steingut-teracotta-und-porzellan/>
40. How to Make a Wood Ash Glaze - Pots and Paint, <http://potsandpaint.blogspot.com/2013/10/how-to-make-wood-ash-glaze.html>
41. Clays and Ash Glazes - John Ayling Pottery, <http://johnaylingpottery.co.uk/new-page>
42. Hilfe bei Querschnittsberechnung. - kaminofen-forum.de, <https://www.kaminofen-forum.de/community/technische-fragen-zu-kaminen-und-%C3%B6fen/hilfe-bei-querschnittsberechnung/>
43. 20 Wood-Fired Masonry Oven Architecture.pdf
44. Das Original der KERAZO Gärtopf, <https://kerazo.de/Gaertopf>
45. Mini-Gärtopf mit Wasserrinne gerade Form 1–3 Liter braun, <https://www.purenature.de/gaertopf-mit-wasserrinne>
46. Nachhaltige Gärtöpfe: Die 5 besten Modelle im Vergleich - GrünLotse, <https://gruenlotse.de/nachhaltige-gaertoepfe-test/>
47. Produkte: Bedarfsgegenstände mit Lebensmittelkontakt, https://www.lgl.bayern.de/produkte/bedarfsgegenstaende/bg_lebensmittelkontakt/ue_2011_gluehweintassen.htm
48. Postfach 2754 - D-32717 Detmold - CVUA-OWL, <https://cvua-owl.de/files/75/Allgemein/322/Postille-Nr-224-Oktober-2020.pdf>
49. Wood Ash Glaze - Digitalfire.com, <https://digitalfire.com/glossary/wood+ash+glaze>
50. An August Wood Firing! About Ash Glazes. - Peter's Pottery, <https://opopots.blogspot.com/2019/08/an-august-wood-firing-about-ash-glazes>

[html](#)

51. Ash in glazes - Callum Forbes,
<https://callumforbes.co.uk/2024/06/08/ash-in-glazes/>
52. How To Start Making My Own Wood Ash Glaze - Forums,
<https://community.ceramicartsdaily.org/topic/16006-how-to-start-making-my-own-wood-ash-glaze/>
53. 52. How to Make Pottery Ash Glazes from Pitfire Ashes - YouTube,
https://www.youtube.com/watch?v=j3_tiC7xQS4
54. Die Glasur in der Keramik - Hyner Berlin,
<https://www.hyner.berlin/magazin/glasur-in-der-keramik>
55. Full text of "Keramische Rundschau" - Internet Archive,
https://archive.org/stream/keramischerundsc2419unse/keramischerundsc2419unse_djvu.txt
56. Schornsteinberechnung für den Schornsteinzug,
<https://schornstein-fachhandel.de/blog/die-schornsteinberechnung-etwas-mathematik-fuer-waermeeffizienz-und-umwelt>
57. Holzbrand im Kasseler Ofen 2013 - Kathrin Najorka Keramik,
<http://kathrinnajorka.blogspot.com/2013/02/kasseler-holzofenbrand-2013.html>
58. Holzbrandofen - keramiko.de, <https://keramiko.de/lexikon/holzbrandofen/>
59. Kasseler Langofen - Rhein-Voreifel-Touristik,
<https://www.rhein-voreifel-touristik.de/poi/kasseler-langofen>
60. Full text of "Keramische Rundschau" - Internet Archive,
https://archive.org/stream/keramischerundsc2119unse/keramischerundsc2119unse_djvu.txt
61. Wie die Berechnung eines Schornsteins funktioniert,
<https://heimwerkerheld.de/Wie-die-Berechnung-eines-Schornsteins-funktioniert>
62. Schornsteinberechnung - Ofenseite,
<https://www.ofenseite.com/schornsteinberechnung>
63. Full text of "Keramische Rundschau" - Internet Archive,
https://archive.org/stream/keramischerundsc3019unse/keramischerundsc3019unse_djvu.txt
64. Brennen mit Kohle und Holz - Keramikwerkstatt Waldenburg,
<https://www.keramik-tauscher.de/brennen-mit-kohle-und-holz>
65. Segerkegel - Wikipedia, <https://de.wikipedia.org/wiki/Segerkegel>
66. Werte pyrometrischer Kegel: Die vollständige Kegeltabelle & alles,
<https://xn--tpfern-wxa.shop/blogs/news/werte-pyrometrischer-kegel-die-vollstaendige-kegeltabelle-alles-was-du-als-topfer-wissen-musst>
67. Datenblatt Ton aus der Tongrube Stulln - ZECH Umwelt GmbH,
https://www.zech-umwelt.com/fileadmin/zechumwelt/bilder/Downloads/Datenblatt_Tongrube_Stulln.pdf
68. Way to make glaze from natural material found outside? Ashes,
https://www.reddit.com/r/Ceramics/comments/9p3sct/way_to_make_glaze_from_natural_material_found/