

Exhaustive Analysis of Glass Salinometers: Fluid Mechanics, Metrology, Fabrication, and Baumé Scale Calibration in Hypersaline Environments

The accurate quantification of liquid density represents a foundational requirement across diverse industrial and scientific disciplines, ranging from chlor-alkali chemical processing and zero liquid discharge (ZLD) systems to oceanography and food manufacturing¹. Among the oldest and most universally applied instruments for this purpose is the hydrometer—a glass apparatus that operates on the fundamental principles of fluid statics. When specifically calibrated to measure the density, specific gravity, or mass fraction of sodium chloride (NaCl) solutions, the instrument is formally designated as a salinometer or salimeter. Despite its empirical origins in the eighteenth century, the modern glass salinometer is a highly regulated metrological instrument, governed by stringent international standards (including ASTM, ISO, and DIN specifications) and calibrated utilizing sophisticated hydrostatic weighing techniques³. This report delivers an exhaustive technical analysis of the glass salinometer. It dissects the fundamental physics of buoyancy, fluid statics, and metacentric stability that govern the instrument's orientation and operation. Furthermore, it details the materials science and precise fabrication methodologies required to construct high-accuracy glass hydrometers, addressing the ongoing transition away from toxic lead ballast due to global environmental directives such as RoHS and REACH. The report thoroughly examines the historical and mathematical framework of the Baumé scale—the primary empirical unit utilized for brine concentration—and explores the complex thermodynamic modeling of hypersaline environments. Finally, it provides a comprehensive overview of modern calibration protocols, specifically detailing Cuckow's method of hydrostatic weighing as standardized by the National Institute of Standards and Technology (NIST) and the International Organization of Legal Metrology (OIML).

The Industrial Context of Hypersaline Metrology

The necessity for precision salinometers is driven by the severe chemical and physical properties of saturated brines. Sodium chloride serves as a foundational pillar of the global inorganic chemical industry, primarily functioning as a highly purified feedstock for the chlor-alkali sector, which generates chlorine gas and sodium hydroxide via the electrolysis of saturated brines¹. The extraction and purification of these brines—whether from the solar evaporation of seawater, the subterranean solution mining of geological halite deposits, or the management of seawater reverse osmosis (SWRO) reject streams—demand rigorous density monitoring¹.

In solar evaporation operations, immense volumes of water are progressively vaporized in interconnected shallow ponds to drive the brine toward supersaturation¹. Standard seawater

enters the system at approximately 3.5% salinity (a specific gravity of ~ 1.025)¹. As evaporation progresses, the brine concentrates, forcing the sequential fractional crystallization of specific compounds dictated strictly by thermodynamic solubility products. Hydrometers are deployed continually to monitor these phase transitions, ensuring that the brine is advanced to subsequent crystallization ponds at precisely the correct density thresholds to prevent the contamination of the final halite yield with calcium sulfate (gypsum) or highly soluble magnesium and potassium salts¹.

Similarly, in solution mining, unsaturated water is injected into subterranean halite domes to create cavities of saturated brine. The density of the extracted fluid must be continuously monitored to calculate the exact dissolution kinetics and prevent catastrophic geomechanical failure or subsidence of the cavern roof¹. Across all these operations, the salinometer serves as the primary diagnostic tool, translating complex fluid thermodynamics into instantaneous, actionable density measurements.

Fundamental Fluid Statics and the Physics of Hydrometry

The operational mechanics of a glass salinometer are governed entirely by hydrostatics. The instrument acts as an unconstrained floating body, and its behavior is dictated by the equilibrium between gravitational forces, hydrostatic pressure, and the geometry of fluid displacement.

Archimedes' Principle and Buoyant Force Integration

Archimedes' principle postulates that a solid body suspended or floating in a fluid experiences a net upward force exactly equal to the weight of the fluid displaced by the submerged portion of the object¹². For a salinometer floating in hydrostatic equilibrium, the downward gravitational force acting on the total mass of the instrument is perfectly counterbalanced by the upward buoyant force⁶.

The derivation of this buoyant force is fundamentally rooted in the pressure gradient of the fluid. The pressure at any given depth within an incompressible fluid increases linearly due to gravity. The net pressure force in the vertical direction on an infinitesimally thin cylindrical

cross-section of area dA and height l is obtained by integrating the pressure differential over the fully submerged volume. The total buoyant force (F_B) is mathematically expressed as:

$$F_B = \rho_{fluid} g V_{submerged}$$

Where ρ_{fluid} represents the density of the displaced liquid, g is the local acceleration due to gravity, and $V_{submerged}$ is the exact volume of the hydrometer beneath the liquid surface⁷.

Because the mass (m) of the hydrometer remains an absolute constant, the product of the

fluid density and the submerged volume must also remain constant to satisfy the equilibrium condition ($m = \rho_{fluid} V_{submerged}$)⁷. Consequently, when the instrument is placed in a high-density liquid—such as concentrated sodium chloride brine—it must displace a smaller volume of fluid to generate the requisite buoyant force to support its weight, causing the instrument to float higher in the fluid column¹². Conversely, in lower-density liquids, it displaces a larger volume and sinks deeper. The narrow, uniform stem of the hydrometer is volumetrically calibrated to translate these slight variations in displacement depth into a highly sensitive, readable density scale¹².

Metacentric Stability and Hydrostatic Equilibrium

A critical, non-negotiable design requirement for any precise hydrometer is that it must float perfectly upright; any angular deviation (known as heel or trim) alters the intersection geometry of the liquid meniscus on the cylindrical stem, introducing severe optical reading errors and invalidating the measurement⁵. The vertical stability of an unconstrained floating body is determined exclusively by the spatial relationship between its center of gravity (G), its center of buoyancy (B), and the metacenter (M)¹⁶.

The center of gravity (G) is the centroid of the instrument's mass, the point through which the total downward weight acts¹⁶. The center of buoyancy (B) is the geometric centroid of the displaced fluid volume, through which the upward buoyant force acts⁷. When a hydrometer is perfectly vertical, both G and B lie perfectly aligned on the same vertical axis. If the hydrometer is subjected to an external force and tilts by a small angle θ , the submerged geometry changes asymmetrically. This causes the center of buoyancy to shift laterally to a new position, B' ¹⁷.

The vertical line drawn upward from this new center of buoyancy (B') intersects the original vertical axis at a critical point known as the metacenter (M). For the hydrometer to be statically stable and autonomously return to an upright position, it must possess a positive righting moment. This condition is strictly satisfied only when the metacenter is located vertically above the center of gravity¹⁸. The distance between the center of gravity and the metacenter is defined as the metacentric height (GM), calculated via the equation:

$$GM = KB + BM - KG$$

Where KB is the height of the center of buoyancy above the lowest extreme of the bulb (the

keel), BM is the metacentric radius, and KG is the height of the center of gravity above the keel²². The metacentric radius (BM) represents the distance from the center of buoyancy to the metacenter and is entirely dependent on the geometry of the waterplane area. It is calculated as $BM = I/V_{submerged}$, where I is the second moment of area (transverse moment of inertia) of the waterplane about the centerline axis¹⁸.

Stability Variable	Naval Architecture Definition	Hydrometer Design Implication
I (Waterplane Inertia)	$\frac{\pi D^4}{64}$ for a circular plane.	Exceptionally small due to the narrow stem diameter (D).
BM (Metacentric Radius)	$I/V_{submerged}$	Negligible, as I is infinitesimal relative to the total displaced volume (V).
KG (Center of Gravity)	Height of mass centroid.	Must be artificially forced downward using ultra-dense ballast to ensure $KG < KB$.
GM (Metacentric Height)	Restoring stiffness margin.	Must be robustly positive to guarantee a strong righting moment.

17

Because a hydrometer relies on an extremely narrow stem to achieve high volumetric sensitivity, the waterplane area—and thus the second moment of area (I)—is virtually zero²¹. Consequently, the metacentric radius (BM) provides almost no geometric stability²⁵. To mathematically guarantee that $GM > 0$, the center of gravity (KG) must be driven fundamentally lower than the center of buoyancy (KB)¹⁷.

This absolute physical requirement dictates the classic, ubiquitous anatomy of a salinometer: a large, hollow upper bulb designed to maximize volume and raise the center of buoyancy, combined with a dense, heavy ballast concentrated at the extreme lower tip to drastically depress the center of gravity¹². When these conditions are met, any angular displacement generates a restoring righting arm ($GZ = GM \sin \theta$) and a corresponding righting moment ($MR = W \times GZ$) that forces the instrument immediately back to a vertical equilibrium¹⁷.

Interfacial Thermodynamics: Surface Tension in NaCl Brines

While Archimedes' principle governs ideal buoyancy, real-world hydrometry is profoundly influenced by the thermodynamics of liquid-gas-solid interfaces. When the glass stem of the salinometer pierces the liquid surface, adhesive forces between the glass silicates and the liquid molecules overcome the cohesive forces within the liquid, drawing the fluid up the stem and creating a meniscus²⁶.

The Capillary Downward Force

This meniscus exerts an additional, continuous downward force on the hydrometer, effectively pulling the instrument deeper into the liquid. If uncorrected, this forces the apparent density reading to be systematically lower than the true density⁶. The magnitude of this downward capillary force (F_γ) is governed by the surface tension coefficient of the liquid (γ), the circumference of the stem (πD), and the contact angle (θ) between the liquid and the glass surface, expressed as:

$$F_\gamma = \gamma \pi D \cos \theta$$

The constant interplay of these forces means that a hydrometer does not solely measure density; it measures a composite equilibrium of fluid density, surface tension, and contact angle⁶. For high-accuracy metrological applications, users must rigorously clean the glass stem with appropriate solvents (such as ethanol or acetone) to eradicate hydrophobic organic contaminants, thereby maintaining a uniform, highly predictable contact angle that ideally approaches 0° (where $\cos \theta \approx 1$)⁶.

Surface Excess and NaCl Solute Behavior

The ultimate accuracy of a salinometer is inextricably linked to the physical chemistry of the brine itself. Pure water at 20°C exhibits a surface tension of approximately 72.8 mN/m ³². However, the introduction of sodium chloride fundamentally alters the interfacial properties of the solvent. Sodium chloride is a strong electrolyte; upon dissolution, it dissociates completely

into Na^+ and Cl^- ions⁸.

According to the Gibbs adsorption isotherm, solutes that decrease surface tension (such as surfactants, alcohols, or short-chain organic acids) spontaneously accumulate at the liquid-gas interface to minimize the free energy of the system. Conversely, inorganic salts like sodium

chloride systematically *increase* surface tension³³. Because Na^+ and Cl^- ions are strongly hydrated by polar water dipoles, they are energetically repelled from the hydrophobic liquid-air interface, creating a microscopic region of negative surface excess³⁴. The resulting depletion of ions near the surface strengthens the hydrogen-bonding network of the uppermost interfacial water molecules, increasing the cohesive rigidity of the surface³⁴.

As the concentration of NaCl increases toward saturation, the surface tension rises in a nearly linear fashion. In a fully saturated sodium chloride brine ($> 26\%$ concentration by mass), the surface tension climbs from water's baseline of 72.8 mN/m to approximately 82 to 84 mN/m at room temperature⁸.

This 14% increase in surface tension significantly amplifies the downward capillary pull on the hydrometer stem compared to a calibration performed in pure water. If a salinometer is calibrated generically for water (72.8 mN/m) without mathematically accounting for the 84 mN/m reality of saturated brine, the instrument will sink too deeply, systematically underestimating the Baumé reading or specific gravity. Consequently, precision salinometers must have their scale matrices mathematically shifted by the manufacturer to permanently compensate for this elevated surface tension profile⁶.

To standardize these corrections across the chemical industry, the German Institute for Standardization (DIN), in specification DIN 12791, establishes strict surface tension categories for density hydrometers:

- **Class L (Low Surface Tension):** Designed for liquids with surface tensions between 15 and 35 mN/m (e.g., volatile hydrocarbons, alcohols, ketones). These instruments are visually identified by a **Yellow** colored ring³.
- **Class M (Medium Surface Tension):** Designed for liquids between 35 and 55 mN/m . Instruments are marked with a **Red** ring³.
- **Class H (High Surface Tension):** Designed for liquids above 55 mN/m , encompassing pure water, aqueous solutions, and highly concentrated brines. Instruments are marked with a **Blue** ring³.

A salinometer explicitly manufactured for aqueous sodium chloride must be calibrated as a Class H instrument. Utilizing a mismatched hydrometer category in an industrial setting

fundamentally compromises the traceability of the density measurement²⁸.

Materials Science and Fabrication Protocols

The manufacturing of a precision glass salinometer requires a highly controlled integration of advanced glass blowing, metallurgical ballasting, thermodynamic stress relief, and meticulous metrological scaling. The instrument must maintain rigid dimensional stability across varying thermal gradients and resist the highly corrosive nature of hot, concentrated sodium chloride brines¹.

Glass Formulation, Forming, and ISO Standards

Industrial salinometers are predominantly fabricated from high-grade borosilicate glass or specialized, high-purity soda-lime glass. Borosilicate is favored for critical precision instruments due to its low coefficient of thermal expansion, high mechanical yield strength, and exceptional hydrolytic resistance, which prevents the continuous leaching of sodium ions into the sample fluid over time⁴⁰. According to international construction standards such as ISO 387 and OIML R 44, the glass must be entirely transparent, symmetric, and utterly free of striae, internal air bubbles, or localized stress defects that could interfere with reading the scale or compromise structural integrity under hydrostatic pressure⁵. Furthermore, the chosen glass must possess a consistent coefficient of cubical thermal expansion, mandated by ISO 387 as

$(25 \pm 2) \times 10^{-6} \text{ }^{\circ}\text{C}^{-1}$, ensuring predictable volumetric changes when deployed in hot brines⁵.

The raw materials—predominantly silica sand (SiO_2), soda ash (Na_2CO_3), limestone (CaCO_3), and boron trioxide (B_2O_3)—are homogenized and introduced into a continuous high-temperature furnace operating at approximately $1,550^{\circ}\text{C}$ to achieve a pristine melt⁴⁴. The fabrication of the hydrometer blank begins with a drawn glass tube⁴². Utilizing automated machine glass-blowing for volume production or manual artisanal techniques for specialized instruments, the tube is uniformly heated in a specialized rotary flame. Once the glass

transitions past its glass-transition temperature (T_g) and reaches a malleable state, the craftsmen or automated lathes introduce localized internal air pressure while synchronously rotating the tube⁴². This process forms the wide, precisely dimensioned buoyancy bulb and the perfectly cylindrical, narrow stem⁴².

The geometry must be flawlessly symmetrical about the main vertical axis; ISO 387 specifies a maximum permissible deviation of 1.5° from the vertical axis when floating⁵. Furthermore, there can be no abrupt changes in cross-section—such as sharp ledges between the bulb and stem—that could trap unwanted micro-bubbles of air when submerged, which would artificially increase the buoyant force and introduce gross positive errors⁵.

Toxic Ballasting and RoHS/REACH Regulatory Compliance

As established by metacentric stability requirements, the extreme base of the salinometer

must contain dense ballast to force the center of gravity below the center of buoyancy¹².

Historically, elemental mercury or lead shot (dense spheres of Pb) encapsulated in a binding wax or resin were universally employed to achieve this low center of gravity⁵.

However, modern hydrometer fabrication is heavily dictated by stringent global environmental and occupational health regulations. Mercury has been explicitly and universally banned for use as a loading material in hydrometers by international standards (such as ISO 387) due to its extreme neurotoxicity, potential for environmental bioaccumulation, and high vapor pressure upon glass fracture⁵.

Lead, while traditionally permitted and still prevalent in older instruments, is currently subjected to aggressive restriction under the European Union's Restriction of Hazardous Substances (RoHS) Directive (2011/65/EU) and the Registration, Evaluation, Authorisation and Restriction of Chemicals (REACH) regulation⁴⁶. The RoHS Directive broadly restricts lead concentrations in

electrical and electronic equipment (EEE) to a maximum of 0.1% (1000 ppm) by weight in any homogenous material⁴⁷. While simple mechanical glass hydrometers are not intrinsically electronic, modern digital densitometers and automated hydrometer reading systems fall squarely under these directives. Even for purely analog instruments, global supply chain harmonization and the REACH classification of massive lead as a Substance of Very High Concern (SVHC)—formally designated as toxic to reproduction (Repr. 1A; H360FD) and highly toxic to aquatic life (Aquatic Chronic 1; H410)—are forcing manufacturers to eliminate lead ballast entirely⁴⁷.

Where lead is still utilized, manufacturers rely on temporary RoHS exemptions (such as Exemption 6(a) for lead as an alloying element in steel and aluminum), many of which are slated to expire or undergo strict review by June 2027⁴⁷. To future-proof their instruments and ensure unhindered global export, premium hydrometer manufacturers have largely transitioned to non-toxic, high-density alternatives. The most prevalent substitutes currently deployed include:

1. **Bismuth-Rich Alloys:** Bismuth shares a similarly high density with lead (9.78 g/cm^3) but lacks its severe reproductive and neurological toxicity, making it an excellent drop-in replacement for shot ballast, albeit at a moderately higher raw material cost⁴⁹.
2. **Stainless Steel Shot:** Corrosion-resistant steel spheres provide sufficient mass to lower the center of gravity while offering complete, unassailable compliance with global environmental regulations⁴⁷.

Restricted Substance	Regulatory Framework	Maximum Allowable Limit	Toxicity / Environmental Hazard	Preferred Modern Replacement
Mercury (Hg)	ISO 387, RoHS	0.1% (1000 ppm)	Severe neurotoxin, high vapor	Bismuth Alloys, Steel Shot

			pressure.	
Lead (<i>Pb</i>)	RoHS, REACH SVHC	0.1% (1000 ppm)*	Repr. 1A (H360FD), Aquatic Chronic 1 (H410).	Bismuth Alloys, Steel Shot
Hexavalent Chromium	RoHS	0.1% (1000 ppm)	Carcinogen, mutagen.	Non-chromate surface passivations

*Subject to temporary exemptions (e.g., Exemption 6(a)II valid until 2027)⁵.

The chosen ballast is meticulously poured into the lowest section of the bulb. To prevent the shot from shifting during transit or operational use—which would dynamically alter the center

of gravity (*KG*), induce an asymmetrical list, and ruin the vertical calibration—the ballast is permanently fixed in place. This is achieved using a specialized cement, a thermosetting resin, or a dense sealing wax⁵. OIML and ISO standards mandate that this binding agent must

possess a high melting point, guaranteed not to soften or flow at temperatures up to 80°C , ensuring absolute internal stability even during high-temperature calibration protocols or when measuring boiling brines⁵.

Annealing and Internal Stress Relief

During the extreme thermal gradients of the glass blowing and sealing processes, the rapid cooling of the glass exterior relative to its insulated interior induces severe internal mechanical stresses. If left untreated, these residual stresses render the salinometer exceptionally brittle, highly susceptible to thermal shock, and prone to spontaneous, catastrophic fracture upon physical impact or immersion in hot industrial brine⁵³.

To eradicate this residual stress, the newly formed glass bodies are subjected to a rigorous annealing process⁴². The uncalibrated salinometers are transported into a continuous annealing lehr (a specialized, elongated tunnel furnace), where they are uniformly heated to their specific

annealing point—approximately 550°C to 600°C for standard borosilicate glass⁵⁴. At this critical temperature plateau, the internal silicate network becomes sufficiently mobile to allow localized stresses to completely dissipate and relax through viscous flow⁴².

Following complete stress relief, the ambient temperature in the lehr is reduced at a strictly controlled, exceptionally slow cooling rate until the glass passes its strain point (approximately 515°C). Once safely below the strain point, the glass can be cooled more rapidly to room

temperature without reintroducing permanent thermomechanical stress⁴². This thermal processing guarantees maximum physical solidity, allowing the fragile instrument to withstand decades of rigorous handling in hostile industrial environments⁴⁴.

Scale Integration and Precision Sealing

Following annealing, ballasting, and comprehensive structural inspection, the instrument undergoes metrological scaling. The density, specific gravity, or Baumé scale is printed on a high-quality, dimensionally stable medium. Standard specifications mandate the use of specialized bond and ledger paper—such as those defined by ASTM D3290—that fundamentally resists discoloration, charring, or dimensional distortion when subjected to

elevated temperatures (70°C and beyond) inside the sealed glass tube⁵.

The printing of the scale lines themselves is strictly governed by standards like ISO 387 and OIML R 44 to prevent parallax errors. The graduation lines must be distinct, permanent, and of a uniform thickness not exceeding one-fifth of the distance between two consecutive short lines⁵.

The paper scale is tightly rolled and inserted into the hollow stem. The precise vertical positioning of this scale is the most critical step in the instrument's fabrication. Using master calibration liquids of known specific gravity (or highly precise air-buoyancy extrapolation models), the manufacturer determines the exact, sub-millimeter height at which the paper scale must rest to yield accurate density readings against the liquid meniscus⁶.

Once perfectly aligned, the scale is permanently affixed to the interior wall of the stem to prevent any slippage. Because a loose scale renders the instrument entirely useless, international standards demand that appropriate mechanical or visual means be incorporated to ensure that any accidental displacement of the scale is instantly apparent to the operator. This is typically achieved via a thin, permanent glass-etching mark or a fused red alignment line on the glass exterior that perfectly matches a corresponding reference datum line printed on the paper scale⁵. Finally, the extreme top of the glass stem is hermetically sealed via high-temperature flame fusion, locking the scale in a dry, isolated environment and completing the fabrication process¹².

The Baumé Scale and Hypersaline Density Metrology

While contemporary laboratory densitometers frequently output specific gravity or density directly in SI units (kg/m^3), the global industrial production of sodium chloride

overwhelmingly utilizes the empirical Baumé scale ($^{\circ}\text{Bé}$) to monitor brine concentration and control crystallization kinetics¹.

Historical Context and Framework

The Baumé scale was conceptualized and developed in 1768 by the French pharmacist and chemist Antoine Baumé. In an era predating precise analytical balances and universally standardized metric units, Baumé required a robust, easily reproducible method to measure the relative density of various industrial liquids, particularly corrosive acids, syrups, and brines¹. Recognizing that liquids fundamentally lighter than water required a different measurement

logic than those heavier than water, Baumé established two distinct, non-overlapping hydrometer scales:

1. **The "Light" Scale:** Designed exclusively for liquids less dense than water (e.g., alcohols, ammonia, hydrocarbons). On this scale, the density of a specific, empirically mixed 10% solution of NaCl originally defined the 0°Bé point, while the density of pure water was arbitrarily anchored at 10°Bé ¹⁵. The graduation numbers increase as the liquid's density decreases.
2. **The "Heavy" Scale:** Designed for liquids denser than water, such as sulfuric acid, heavy syrups, and concentrated sodium chloride brines. On this scale, 0°Bé precisely corresponds to the density of pure water, while 15°Bé originally corresponded to the density of a 15% solution of sodium chloride by mass¹. The graduation numbers increase directly as the liquid's density increases⁵⁹.

Because sodium chloride brines possess specific gravities ranging from 1.000 (fresh water) up to approximately 1.200 (fully saturated brine at $\sim 26.4\%$ mass fraction), the chlor-alkali and salt extraction industries rely exclusively on the Baumé Heavy Scale¹. A standard heavy salinometer is graduated with the lowest values (e.g., 0°Bé) positioned near the top of the stem and higher values (e.g., 25°Bé) situated near the bottom¹². As the brine becomes denser and heavier, Archimedes' principle dictates that the instrument must float higher, thereby exposing the larger numerical values lower down on the stem to the liquid meniscus¹².

Mathematical Translation to Specific Gravity

Over the centuries, the original empirical, salt-solution definitions of the Baumé scale proved insufficiently precise for the rigorous demands of modern chemical engineering and thermodynamic modeling. Consequently, the scale was formalized into strict mathematical relationships linking degrees Baumé ($^{\circ}\text{Bé}$) directly to Specific Gravity (SG). Specific gravity is a dimensionless ratio comparing the absolute density of a substance to the absolute density of a reference fluid (universally, pure water) at a explicitly specified temperature¹². For the **Heavy Baumé Scale** (liquids denser than water), the universally accepted conversion formula—standardized at the reference temperature of 60°F (15.56°C)—is defined as:

$$SG = \frac{145}{145 - ^{\circ}\text{Bé}}$$

Conversely, calculating the Baumé reading from a known specific gravity is expressed as:

$$^{\circ}\text{Bé} = 145 - \left(\frac{145}{SG} \right)$$

1

(Note: While the exact mathematical constant ¹⁴⁵ is the absolute standard in the United States and within ASTM frameworks, some legacy European metrological frameworks historically utilized slight variations such as ^{144.3} or ^{146.78}. However, ¹⁴⁵ is overwhelmingly adopted for all modern industrial brine extraction tables).

This mathematical conversion allows chemical engineers to instantly translate a rapid, in-situ salinometer reading into a precise specific gravity. From the specific gravity, the true mass fraction of sodium chloride can be derived using established thermodynamic phase tables. For instance, standard ocean seawater possesses a specific gravity of approximately ^{1.025}, which corresponds to roughly ^{3.5°Bé}¹. As solar evaporation progresses in a commercial saltworks, the brine transitions through critical thermodynamic stages dictated almost entirely by density. Hydrometers actively guide this process: calcium carbonate precipitates out of solution below ^{12°Bé}, calcium sulfate (gypsum) reaches saturation and precipitates between ^{12°Bé} and ^{25°Bé}, and the target sodium chloride (halite) crystallizes exclusively within a narrow density window between ^{25°Bé} and ^{29.5°Bé}¹.

Operational Stage	Baumé Reading (°Be´)	Specific Gravity (60°F)	Approx. Salinity Mass Fraction	Primary Mineral Precipitate
Oceanic Intake	3.5	~ 1.025	3.5%	None
Carbonate Stage	3.5 to 12.0	1.025 to 1.090	3.5% to 14.0%	Calcite / Aragonite ($CaCO_3$)
Sulfate Stage	12.0 to 25.0	1.090 to 1.208	14.0% to 29.0%	Gypsum ($CaSO_4 \cdot 2H_2O$)

Halite Stage	25.0 to 29.5	1.208 to 1.255	29.0% to 32.5	Halite (Sodium Chloride, NaCl)
Bitterns Stage	> 29.5	> 1.255	> 32.5%	Epsomite, Carnallite, Bischofite

1

Thermodynamic Modeling and Pitzer Equations

The reliance on precise density measurements via salinometers is fundamentally tied to the complex physical chemistry of hypersaline environments. In dilute solutions, standard thermodynamic models (such as the Debye-Hückel theory or Davies equations) are sufficient to predict mineral solubility, as they assume ion-ion interactions are negligible¹. However, these models fail catastrophically in hypersaline, crystallizing brines where the ionic strength exceeds 5 mol/kg¹.

In such dense solutions—those registering above 20° Bé on a salinometer—massive electrostatic interactions, short-range intermolecular forces, and complex ion pairing heavily depress the activity of water and the activity coefficients of the dissolved salts¹. To accurately predict phase equilibria and scale formation during thermal evaporation or solution mining, engineers rely on the semi-empirical Pitzer equations¹. The Pitzer model calculates the mean ionic activity coefficient by accounting for specific binary and ternary ionic interactions, utilizing empirically derived parameters that are directly correlated to the fluid's density and specific gravity¹. Without hyper-accurate specific gravity data provided by calibrated hydrometers, these advanced thermodynamic models cannot accurately compute the Saturation Index (SI), leading to unpredictable crystallization and catastrophic scaling in Multi-Effect Evaporator (MEE) tubes¹.

Temperature Corrections and Oceanographic Equations of State

Because the volume of any liquid expands with increasing temperature, its density—and therefore its specific gravity and apparent Baumé reading—decreases inversely. Consequently, hydrometers are exceptionally temperature-sensitive instruments⁶³. Under contemporary international metrology standards (such as ISO 387 and DIN 12791), laboratory density hydrometers are predominantly calibrated at a strict reference temperature of 20°C⁵. However, legacy industrial scales—particularly the Baumé scale governed by American Society for Testing and Materials (ASTM) specifications like ASTM E100 and E126—are strictly calibrated at 60°F (15.56°C) for both the sample liquid and the reference water (denoted as 60/60°F)⁶⁴.

If a chemical plant operator tests a hot brine drawn directly from a forced-circulation crystallizer at 80°C using a salinometer calibrated for 20°C , the thermal expansion of the liquid renders it significantly less dense than it would be at room temperature. This causes the hydrometer to sink too deeply, yielding an erroneously low concentration reading⁶³. To mitigate this thermodynamic reality, precision salinometers frequently feature built-in integral liquid-in-glass thermometers enclosed inside the buoyancy bulb (known as thermohydrometers)³. The operator simultaneously records the Baumé reading at the meniscus and the internal fluid temperature. The operator then applies a rigid temperature correction factor derived from standardized thermodynamic tables (such as ASTM D1250) to mathematically normalize the apparent reading back to the true reference density at 60°F ⁶³. In oceanographic contexts, the relationship between specific gravity, temperature, and salinity is so critical that it is governed by universally adopted thermodynamic equations of state. Historically, oceanographers relied on the Equation of State of Seawater 1980 (EOS-80), which calculated density based on Practical Salinity (S_P)⁷¹. However, EOS-80 was entirely superseded in 2010 by the Thermodynamic Equation of Seawater (TEOS-10)⁷¹. TEOS-10 utilizes a comprehensive Gibbs thermodynamic potential function to evaluate density based on Absolute Salinity (S_A , measured in g/kg), which accounts for non-ionic dissolved solids and regional variations in isotopic composition⁷¹. While TEOS-10 is primarily scaled for oceanic seawater, the rigorous thermodynamic principles regarding non-linear density increases driven by ionic mass apply conceptually to the hypersaline brines monitored by industrial salinometers⁷¹.

Metrological Calibration: Cuckow's Method of Hydrostatic Weighing

To achieve the stringent metrological traceability required for industrial quality control, environmental compliance, and pharmaceutical validation, glass salinometers must undergo rigorous, certified calibration⁴.

Historically, hydrometer calibration relied entirely on the direct comparison method. This involved floating a highly certified reference standard hydrometer alongside an uncalibrated test hydrometer in a series of temperature-controlled baths containing hazardous, highly toxic liquids (such as concentrated sulfuric acids or volatile hydrocarbons) and visually comparing the meniscus intersections across the scales²⁸. This method was excessively labor-intensive, subjected technicians to severe chemical hazards, and introduced massive human optical errors²⁸.

To eliminate the necessity for dangerous chemical baths, massively reduce manual labor, and drastically improve measurement uncertainty, National Metrology Institutes (NMIs)—including the United States NIST, Mexico's CENAM, and South Africa's NMISA—have universally adopted automated hydrostatic weighing based on Cuckow's Method²⁸.

The Mechanics and Mathematics of Cuckow's Method

Cuckow's method elegantly and mathematically decouples the calibration process from the necessity of using multiple liquids that match the hydrometer's full density range. Instead, it utilizes a single, highly stable, well-characterized reference liquid with a precisely known density and surface tension to calibrate the entire scale of the instrument via apparent mass substitutions³⁰.

At NIST and other leading NMIs, the reference liquid of choice is n-tridecane ($C_{13}H_{28}$)⁶. Tridecane is selected for its exceptional long-term density stability, extremely low vapor pressure, and very low surface tension (27 mN/m). This low surface tension guarantees a low, highly consistent contact angle against the glass stem, virtually eliminating capillary reading errors²⁸. Other institutes successfully utilize ultra-pure distilled water (998 kg/m^3), although its inherently high surface tension (72 mN/m) slightly complicates meniscus force calculations⁷⁸.

The calibration sequence involves placing the hydrometer into three distinct thermodynamic states, generating a system of three force-balance equations³⁰.

Step 1: Weighing in Air The perfectly clean, completely dry salinometer is suspended via an invisible wire from an analytical mass comparator balance of extreme precision (boasting a resolution of 0.1 mg or better) and weighed in ambient air⁷⁷. The balance reading in air (R_a) accounts for the absolute mass of the hydrometer (m) minus the buoyant force of the displaced air acting on the total volume of the hydrometer. This total volume is partitioned into V (the volume below the target scale mark) and v (the volume of the stem above the mark):

$$R_a = m - (V + v)\rho_a$$

Where ρ_a is the density of the air, calculated dynamically using the CIPM-2007 environmental models based on real-time laboratory temperature, barometric pressure, and relative humidity data⁹.

Step 2: Free Floating Equilibrium (The Theoretical State) The second equation represents the theoretical state where the hydrometer floats freely in a hypothetical industrial liquid of density ρ_L , with the liquid surface perfectly aligned with the target scale mark. In this state, the net force is zero. The downward forces (instrument mass plus the capillary pull of surface tension) are perfectly balanced by the upward buoyant forces (the industrial liquid displaced by volume V , plus the air displaced by the exposed stem volume v)⁶:

$$0 = m + \frac{\gamma_x \pi D}{g} - V \rho_L - v \rho_a$$

Where γ_x is the specific surface tension of the intended target liquid (e.g., concentrated NaCl brine), D is the precise diameter of the stem, and g is the local acceleration due to gravity³⁰.

Step 3: Hydrostatic Weighing in the Reference Liquid The hydrometer remains suspended from the analytical balance overhead but is partially lowered down into a temperature-controlled bath containing the single reference liquid (e.g., tridecane) of absolute

known density (ρ_s)²⁸. Advanced, fully automated calibration rigs utilize sophisticated Machine Vision Systems (MVS)—incorporating CCD cameras, sub-pixel edge detection algorithms, laser light sheets, and precision stepper motors—to optically detect the liquid meniscus and perfectly align it with the target scale mark on the stem, achieving positioning accuracies better than $10 \mu\text{m}$ ⁷⁸. The balance reading recorded in this suspended, partially immersed state (R_s) is formulated as:

$$R_s = m + \frac{\gamma_s \pi D}{g} - V \rho_s - v \rho_{a2}$$

Where γ_s is the established surface tension of the reference liquid (tridecane or water), and ρ_{a2} accounts for any slight variations in air density during the second weighing³⁰.

The NIST Data Reduction Equation and Uncertainty Budgets

By algebraically manipulating and combining these three force-balance equations to eliminate the unknown, difficult-to-measure volumetric terms (V and v), metrologists isolate the true fluid density (ρ_L) corresponding to the specific scale mark. Incorporating the volumetric thermal expansion coefficient of the glass (β), the comprehensive data reduction equation (derived and utilized by NIST in publication SP 250-78) calculates the density correction⁶:

$$\rho_L = \frac{\rho_s - \rho_a}{1 - \frac{R_s - \frac{\gamma_s \pi D}{g}}{R_a}} [1 + \beta(T - T_{ref})] + \text{Surface Tension Corrections}$$

(Note: The full expansion utilized by national laboratories involves exceptionally complex correction factors accounting for the contact angle ($\cos \theta$), the balance calibration coefficient (α), and vertical gravity gradients, which are omitted here for brevity but are absolutely critical for primary-level metrology)⁶.

This methodology allows a single tank of tridecane to calibrate a salinometer across its entire operational range—from 0°Bé to 30°Bé —simply by vertically jogging the liquid bath to align with 10%, 50%, and 90% of the printed scale⁶. This derives a highly accurate, multi-point calibration curve without ever exposing the delicate instrument to actual concentrated, corrosive brine⁹.

The total expanded uncertainty of this calibration is heavily scrutinized. OIML R 44 establishes strict accuracy classes for hydrometers based on their scale spacing and maximum permissible errors⁴³. Class I instruments possess the smallest maximum permissible errors (typically half a scale interval), while Class II and III instruments allow for errors up to a full scale interval⁴³.

The uncertainty budget for a Cuckow calibration encompasses several critical contributors:

1. **Mass Measurement (m):** Uncertainty in the balance resolution, linearity, and the density of the reference mass standards used to calibrate the balance⁹.
2. **Reference Liquid Density (ρ_s):** Errors originating from temperature fluctuations in the bath and the fundamental uncertainty of the liquid's equation of state (e.g., Tanaka equation for pure water)⁹.
3. **Dimensional Measurements (D):** Caliper uncertainty when measuring the stem diameter, which directly dictates the magnitude of the calculated capillary force⁷⁷.
4. **Environmental Variables (ρ_a):** Fluctuations in atmospheric buoyancy caused by ambient temperature and barometric pressure variations during the weighing cycle⁹.

By aggressively controlling these parameters, state-of-the-art Cuckow systems achieve an expanded uncertainty (coverage factor $k = 2$) of 100 parts in 10^6 (0.0001 g/ml) or better, comfortably exceeding the requirements for high-precision industrial density measurement⁶.

Conclusion

The glass salinometer stands as an enduring testament to the immense utility of classical physics within modern chemical engineering and metrology. By flawlessly leveraging Archimedes' principle, precise volumetric modeling, and severe metacentric weight distribution, this purely analog instrument provides instantaneous, highly reliable measurements of brine concentration without requiring electrical power, complex analytical titration, or fragile digital transducers.

However, the apparent visual simplicity of the instrument entirely belies the immense

metallurgical, thermodynamic, and metrological sophistication required for its fabrication and deployment. The seamless integration of the empirical Baumé scale allows for the direct, continuous monitoring of fractional crystallization stages in solar saltworks and solution mining. Yet, ensuring the unwavering fidelity of that scale demands rigorous adherence to international manufacturing standards (ISO 387, ASTM E100, OIML R 44). As global environmental regulations (RoHS, REACH) rightfully force the abandonment of traditional toxic lead and mercury ballast, the manufacturing industry must persistently innovate with bismuth-rich alloys and stainless steel, ensuring the requisite low center of gravity is maintained without compromising ecological safety.

Ultimately, through the deployment of Cuckow's method of automated hydrostatic weighing, modern metrologists can isolate and mathematically neutralize the subtle, interfering forces of surface tension and atmospheric buoyancy. This comprehensive synthesis of glass science, naval architecture, fluid statics, and rigorous uncertainty budgeting ensures that these historical instruments continue to meet the exacting, parts-per-million accuracy requirements demanded by the modern industrial landscape.

Works cited

1. 68 Sodium Chloride Extraction Methods.pdf
2. Ship Stability: 120 Vital Facts for Safer Vessel Operations, <https://www.marinepublic.com/blogs/training/429185-ship-stability-120-vital-facts-for-safer-vessel-operations>
3. Precision Hydrometers Catalogue | PDF | Thermometer - Scribd, <https://www.scribd.com/document/754575253/09-Hydrometer-model>
4. ASTM E126 Inspection, Calibration, and Verification of ... - MaTestLab, <https://matestlabs.com/test-standards/astm-e126/>
5. SIST-ISO-387-1995.pdf - iTeh Standards, <https://cdn.standards.iteh.ai/samples/4371/625b9bf64fc343588c5bc06e2ef824d2/SIST-ISO-387-1995.pdf>
6. NIST Calibration Services for Hydrometers, <https://www.nist.gov/document/25078pdf>
7. Buoyant Force and Center of Buoyancy, https://engineering.purdue.edu/~wassgren/teaching/ME30800/NotesAndReading/BuoyantForce_Reading.pdf
8. Sodium chloride - Wikipedia, https://en.wikipedia.org/wiki/Sodium_chloride
9. The uncertainty evaluation for the hydrometer calibration at NMISA, http://www.nla.org.za/webfiles/conferences/2018/Proceedings/Manuscripts/Tuesday,%209%20October%202018/T205%20-%20The%20uncertainty%20evaluation%20for%20the%20hydrometer%20calibration%20at%20NMISA_peer%20reviewed.pdf
10. Hydrometer Physics Problems - Density & Specific Gravity, <https://www.youtube.com/watch?v=xx8dOAwRFs4>
11. 14.4 Archimedes' Principle and Buoyancy - OpenStax, <https://openstax.org/books/university-physics-volume-1/pages/14-4-archimedes-principle-and-buoyancy>

[principle-and-buoyancy](#)

12. Hydrometer - Wikipedia, <https://en.wikipedia.org/wiki/Hydrometer>
13. Archimedes' Principle and Flotation Concepts | PDF - Scribd, <https://www.scribd.com/presentation/977908721/33-Sinking-and-Floating>
14. Archimedes' Principle | Physics - Lumen Learning, <https://courses.lumenlearning.com/suny-physics/chapter/11-7-archimedes-principle/>
15. Hydrometers - user information | Brannan, https://www.brannan.co.uk/knowledge_base/hydrometers-user-information/
16. Buoyancy - Wikipedia, <https://en.wikipedia.org/wiki/Buoyancy>
17. Buoyancy and Stability of Floating Bodies | PDF - Scribd, <https://www.scribd.com/document/421685659/doc-doc>
18. What Is Metacentric Height (GM)? Formula, Calculator & IMO Minimum, <https://metacad.io/en/knowledge/metacentric-height-gm/>
19. Conducting a Stability Test (Lightweight Survey and Inclining, <https://www.normadoc.com/media/file/5d/66/ecfe17a24fe02efbfeb7d846405d.pdf>
20. Buoyancy and stability, <https://cns.gatech.edu/~predrag/courses/PHYS-4421-13/Lautrup/buoyancy.pdf>
21. Metacentric Height Calculator | Reuven Engineering Tools, <https://reuven.tools/tools/metacentric-height/>
22. Tethys - Energy Systems Research Unit, https://www.esru.strath.ac.uk/EandE/Web_sites/15-16/TETHYS/hydrostatics.html
23. Buoyancy Flotation Metacentric Interactive Calculator, <https://www.firgelliauto.com/blogs/calculators/buoyancy-flotation-metacentric-calculator>
24. Metacentric Height (GM) Calculator | Nautical Solver, <https://nauticalsolver.com/calculators/stability/gm/gm.php>
25. Naval architecture - Metacentric Stability, Buoyancy ... - Britannica, <https://www.britannica.com/technology/naval-architecture/Metacentric-stability>
26. Contact Angle Measurements and Wettability, <https://www.nanoscience.com/techniques/tensiometry/contact-angle-measurements-and-wettability/>
27. Contact Angle and Surface Tension Measurement - NanoQAM, https://nanoqam.ca/wiki/lib/exe/fetch.php?media=contact_angle_and_surface_tension.pdf
28. Hydrometer calibration by hydrostatic weighing with automated, https://tsapps.nist.gov/publication/get_pdf.cfm?pub_id=830999
29. Hydrometer Calibration by Hydrostatic Weighing With Automated, <https://www.nist.gov/publications/hydrometer-calibration-hydrostatic-weighing-automated-liquid-surface-positioning>
30. Cuckow Method for Hydrometer Calibration | PDF - Scribd, <https://www.scribd.com/document/118224761/07-Hydrometers-Calibration-Cuckow-s-Method-Claude-Jacques>
31. sensors - Semantic Scholar,

- <https://pdfs.semanticscholar.org/6773/8dc27fc9d9a3590f4e3b740a798eb4dbfa46.pdf>
32. Surface tension values of some common test liquids for surface,
<https://www.surface-tension.de/>
 33. Surface Tensions in NaCl–Water–Air Systems from MD Simulations,
https://www.researchgate.net/publication/5951167_Surface_Tensions_in_NaCl-Water-Air_Systems_from_MD_Simulations
 34. Species Surface Distribution and Surface Tension of Aqueous,
<https://pmc.ncbi.nlm.nih.gov/articles/PMC9144742/>
 35. Microfluidic studies of Salt Precipitation: Influence of Brine ... - arXiv,
<https://arxiv.org/html/2507.20638v1>
 36. Surface Tension and Surface Thermodynamics of Aqueous,
<https://pubs.acs.org/jceaax/article/70/12/4901/3739544/Surface-Tension-and-Surface-Thermodynamics-of>
 37. Precision Hydrometer L20-170 Range 1.700-1.720 g cm³,
<https://www.andalaninstrument.com/product/precision-hydrometer-l20-p629611.aspx>
 38. Precision Hydrometers and Refractometers,
https://www.sanecal.com/kr/product/product_down.php?idx=3701&download=1
 39. ASTM Hydrometer Calibration Standards | PDF | Density - Scribd,
<https://www.scribd.com/document/933833366/E126-keqp5606>
 40. Complete 8-Step Process From Raw Glass to Certified Labware,
<https://medilabexports.com/laboratory-glassware-manufacturing-process/>
 41. Laboratory Grade Hydrometers | DWK Life Sciences,
<https://www.dwk.com/na/laboratory-products/measuring-devices/hydrometers>
 42. Borosilicate glass manufacturing process,
<https://www.easterglass.com/-borosilicate-glass-manufacturing-process>
 43. OIML R 44: Alcoholometry Instruments | PDF - Scribd,
<https://www.scribd.com/doc/236930011/R044-e85>
 44. The stages of glass manufacturing - Verallia,
<https://www.verallia.com/en/stages-of-glass-manufacturing/>
 45. Forming of Sheet Glass, Tubing, and Hollowware (Lecture 24, Glass,
<https://www.youtube.com/watch?v=TffCHb826A0>
 46. RoHS Directive - Environment - European Commission,
https://environment.ec.europa.eu/topics/waste-and-recycling/rohs-directive_en
 47. RoHS & REACH: A 2025 Update - American Galvanizers Association,
<https://galvanizeit.org/knowledgebase/article/rohs-reach>
 48. RoHS Exemption: Industry Initiative Approaching Goal,
<https://www.lasercomponents.com/en/photonics-portal/news/rohs-exemption-in-industry-initiative-approaching-goal/>
 49. Lead metal massives (bismuth-rich grade) Substance,
<http://ila-reach.org/wp-content/uploads/2025/08/Lead-metal-bismuth-rich-grade-v2.pdf>
 50. RoHS Directive: Use of lead - AVS Römer,
<https://www.avs-roemer.de/en/about-us/news/detail/rohs-directive-use-of-lead>

51. EU Updates RoHS Directive with Revised Lead Exemption Clauses,
<https://www.cirs-group.com/en/chemicals/eu-updates-rohs-directive-with-revised-lead-exemption-clauses>
52. EU updates lead exemptions under RoHS directive - TÜV SÜD,
<https://www.tuvsud.com/en/knowledge-hub/technical-updates/consumer-products-and-retail-essentials/eu-comprehensive-updates-to-lead-exemptions-under-rohs-directive>
53. Glass Annealing Process Explained | PDF - Scribd,
<https://www.scribd.com/document/613841416/ANNEALING-PROCESS-OF-GLASS>
54. There Are 4 Stages Of The Glass Annealing Process,
<https://wowglassware.com/there-are-4-stages-of-the-glass-annealing-process/>
55. How to Anneal Borosilicate Glass: Temperatures, Cycles & Kiln Guide,
<https://www.boromastery.com/annealing-guide>
56. Borosilicate Glass Annealing Chart - Northstar Glassworks,
<https://northstarglass.com/annealing/>
57. ASTM Hydrometers1 - pdfcoffee.com,
<https://pdfcoffee.com/download/astm-e100-19-4-pdf-free.html>
58. Baumé scale - Wikipedia, https://en.wikipedia.org/wiki/Baum%C3%A9_scale
59. Taking Density With Hydrometers,
<https://sakeassociation.org/wiki/taking-density-with-hydrometers/>
60. Hydrometer | Definition, Types & Uses - Lesson - Study.com,
<https://study.com/academy/lesson/hydrometer-definition-scales-uses.html>
61. Archimedes' Principle – Introductory Physics for the Health and Life,
<https://openbooks.lib.msu.edu/collegephysics1/chapter/archimedes-principle-2/>
62. Sodium-Chloride-Brine-Table (2) copy - Industrial Water Solutions,
<https://industrialh2osolutions.com/wp-content/uploads/2019/04/Sodium-Chloride-Brine-Table.pdf?x23718>
63. Instructions – Dichte Aräometer Baumé ... - Geco-Gering,
<https://www.geco-gering.de/en/instructions/>
64. Kimble Hydrometers,
<https://d3h4jppqn0j59k.cloudfront.net/pub/media/mageplaza/resource/pdf/KIMBLE-Hydrometers.pdf>
65. Density-hydrometer DIN 12 791 without thermometer on request,
<https://www.geco-gering.de/en/products/density-hydrometer-din-12-791-without-thermometer/>
66. Density determination - Faust Laborbedarf AG,
<https://faust.ch/en/Product-groups/Analytical-measurement-and-testing/Density-determination/>
67. HYDROMETERS - ResearchGate,
https://www.researchgate.net/profile/Sundara-Kumar-V/post/Relative_density_is_a_dimensionless_quantity_and_its_measurable_on_which_scale_is_hydrometer_calibrated/attachment/5e83133b498d5000016e4764/AS%3A875087146262531%401585648442993/download/hydrometers.pdf
68. Hydrometers | Fisher Scientific,
<https://www.fishersci.com/us/en/browse/90220369/hydrometers>

69. Hydrometers | Boeco Germany,
<https://www.boeco.com/density-temperature-and-time-measurement/hydrometers&pr=31>
70. Precision Hydrometers - Ludwig Schneider - PDF Catalogs,
<https://pdf.medicalexpo.com/pdf/ludwig-schneider/precision-hydrometers/112722-179605.html>
71. TEOS-10 - Wikipedia, <https://en.wikipedia.org/wiki/TEOS-10>
72. TEOS-10 - Wikipedia, <https://de.wikipedia.org/wiki/TEOS-10>
73. Calculation and Use of Thermodynamic Properties,
https://www.scor-int.org/Publications/Thermodynamic_TEOS-10_Manual_GOSHIP_19Aug09.pdf
74. TEOS-10: Thermodynamic Equation Of Seawater - 2010,
<https://www.iow.de/teos-10-2284.html>
75. TEOS-10 EXCEL - Implementation of the Thermodynamic Equation,
<https://os.copernicus.org/preprints/os-2022-2/os-2022-2-manuscript-version3.pdf>
76. (PDF) SIM Guidelines on the calibration of hydrometers - Cuckow,
https://www.researchgate.net/publication/335311433_SIM_Guidelines_on_the_calibration_of_hydrometers_-_Cuckow_method
77. The proposed improvements of the hydrometer calibration system,
https://events.saip.org.za/event/91/attachments/2266/3055/SAIP2017_350-354.pdf
78. Hydrometer calibration by hydrostatic weighing with automated,
https://www.researchgate.net/publication/231156172_Hydrometer_calibration_by_hydrostatic_weighing_with_automated_liquid_surface_positioning
79. Automated Hydrometer Calibration System | PDF | Density - Scribd,
<https://www.scribd.com/document/653324714/The-Automatization-of-Alignment-System-for-Calibration-of-Hydrometers>
80. Newly Established Hydrometer Calibration Set Up at UM - IMEKO,
<https://www.imeko.org/publications/tc3-2001/IMEKO-TC3-2001-037.pdf>
81. Hydrometers Calibrations - BIPM,
<https://www.bipm.org/documents/20126/48150785/AFRIMETS.M.D-S4.pdf/68d5c641-df5c-a020-85ac-d88213799ee2>
82. (PDF) Calibration of hydrometers - ResearchGate,
https://www.researchgate.net/publication/231085501_Calibration_of_hydrometers
83. Hydrometer Calibration Uncertainty at NMISA | PDF - Scribd,
<https://www.scribd.com/document/439294247/T205-Uncertainty-analysis-for-hydrometer-calibration-at-NMISA>