

Engineering the Traditional Wooden Wedge Press: Mechanical Physics, Material Selection, and Oil Extraction Dynamics

Introduction and Historical Lineage of Mechanical Oil Expression

The extraction of vegetable and seed oils through mechanical expression represents one of the oldest, most economically significant, and mechanically demanding biochemical engineering processes in human history. Prior to the advent of modern hydraulic presses, high-pressure screw expellers, and volatile solvent extraction protocols, the heavy-duty wooden wedge press served as the primary industrial apparatus for achieving the immense pressures required to rupture organic cellular matrices. Archaeological excavations from the Indus Valley Civilization reveal that oleaginous materials such as sesame, rapeseed, and mustard seed were being processed as early as 2000 BCE, with evidence of early pressing mechanisms dating back nearly 5,000 years¹. The linguistic and archaeological records suggest that these early methods relied heavily on mortar-and-pestle arrangements, known regionally as the *ghani* or *chekku*, which utilized animal traction to slowly grind and press the seeds¹.

As the demand for cooking fuels, dietary lipids, and industrial lubricants expanded, so too did the scale and mechanical sophistication of extraction technologies. During the zenith of the Roman Empire, the development of the *mola olearia* and the *trapetum* introduced a factory-style methodology for processing olive paste. These systems utilized massive cylindrical or conical grindstones rotating within a fixed basin, followed by the application of towering wooden lever presses weighted by heavy stone counterweights or actuated by perpendicular wooden screws⁴. While these lever presses represented a significant leap in scale, their maximum pressure output was inherently limited by the mass of the counterweights and the tensile limits of the wooden screws. Traditional stone pressing in this era could extract up to twenty percent more oil than the primitive wooden presses used by less technologically advanced communities, establishing oil as a commodity so valuable it frequently served as regional currency and tribute⁵.

The paradigm shifted definitively with the perfection of the wooden wedge press. Historical evidence points to the use of highly evolved Chinese wedge presses over 1,500 years ago, a design that relied entirely on human kinetic energy and the mechanical advantage of the inclined plane⁶. By the seventeenth and eighteenth centuries, European mechanical engineers adapted these principles into the formidable "Dutch oil mill." These pre-industrial behemoths were driven by massive waterwheels—often measuring 17.5 feet in diameter and yielding up to six horsepower at a rotational speed of 7.5 revolutions per minute—which transferred power

through complex cam shafts to lift towering wooden stamping poles⁸. The Dutch wedge press transformed relatively low-velocity, high-mass vertical kinetic energy into catastrophic horizontal compressive forces, fundamentally revolutionizing the efficiency of linseed and hemp oil production⁸.

Designing a functional, heavy-duty wooden wedge press in the modern era requires a rigorous synthesis of classical mechanics, tribology, extraction thermodynamics, and orthotropic material science. The immense lateral forces generated within the press body demand uncompromising structural timber design, specifically regarding compression perpendicular to the grain and the longitudinal shear capacity of the selected hardwood. Furthermore, because the internal working surfaces of the press are perpetually saturated with highly lubricative vegetable oil, the tribological properties of the timber interfaces rigidly dictate the geometric limitations of the wedge itself. This exhaustive report details the mechanical physics governing the wedge system, the extraction kinetics of the seed cake, the structural verification parameters mandated by modern timber engineering standards such as Eurocode 5, and the metallurgical-equivalent selection criteria for the optimal hardwood species.

Thermomechanical Pretreatment and Extraction Kinetics

The mechanical efficiency of a wedge press is fundamentally intertwined with the biochemical state of the organic material being processed. Oilseeds are complex cellular structures wherein the lipid fractions are securely bound within semi-permeable cell walls composed of cellulose, hemicellulose, and pectin. To achieve an optimal extraction yield, the raw oilseeds must undergo a rigorous sequence of thermal and mechanical pretreatments designed to systematically degrade this cellular architecture before any mechanical pressure is applied¹⁰. The preparatory phase begins with the careful selection, cleaning, and grading of the raw seeds to remove stones, chaff, and damaged kernels, which would otherwise absorb expressed oil or damage the pressing equipment³. The seeds are subsequently subjected to atmospheric drying for one to two days to reduce their internal moisture content. Controlling the moisture content is a critical thermodynamic parameter; excessive moisture causes severe foaming during the pressing stage and acts as an incompressible fluid cushion that absorbs mechanical energy without contributing to cellular rupture, thereby dramatically lowering the final oil yield³. Following desiccation, the seeds are mechanically cracked or flaked. This physical size reduction drastically increases the surface area-to-volume ratio of the material and initiates the physical tearing of the cell walls¹⁰. However, mechanical flaking alone is insufficient to release the full lipid payload. The flaked seeds must be subjected to precise thermal conditioning, typically through roasting or steaming. Elevating the temperature of the seed mass accomplishes several vital rheological and structural objectives. First, the thermal energy denatures the structural proteins within the cell walls, transforming the previously pliable cellular matrix into a highly brittle structure that readily shatters under subsequent compressive strain¹⁴. Second, the applied heat causes the trace internal moisture trapped within the cells to vaporize and expand, creating internal pneumatic pressure that further degrades the intracellular framework¹⁵.

Most crucially, heating the seeds significantly alters the fluid dynamics of the extracted oil. According to the principles of fluid mechanics, the kinematic viscosity of vegetable oils decreases exponentially with an increase in temperature. A lower viscosity allows the lipid fraction to flow rapidly and efficiently through the tortuous, microscopic capillary network of the compressed fibrous seed cake¹⁵. In a cold-pressing operation—defined strictly by maintaining the processing temperature below 40 to 45 degrees Celsius—the structural integrity of the heat-sensitive polyphenols, antioxidants, vitamins, and essential fatty acids is preserved, yielding a biochemically superior product¹. However, the high viscosity of the cold oil and the surviving elasticity of the cell walls result in a drastically reduced extraction yield¹. To balance commercial yield with nutritional retention, modern pressing operations tailor the hot-pressing temperature precisely to the specific botanical profile of the crop.

Oilseed Crop	Recommended Pressing Temperature Range	Primary Processing Objective and Biochemical Constraints
Coconut	60°C – 80°C	Low-temperature pressing is mandatory to preserve the highly volatile aromatic compounds and prevent the degradation of the delicate coconut fragrance ¹⁷ .
Soybean	110°C – 140°C	High heat is required to maximize yield and effectively neutralize the undesirable "beany" flavor profile inherent to raw soybeans ¹⁷ .
Peanut	120°C – 150°C	This temperature band balances optimal lipid extraction with the Maillard reactions necessary to develop the characteristic roasted nutty aroma ¹⁷ .
Sesame	120°C – 130°C	Provides an optimal equilibrium between structural cellular

		breakdown for high yield and the preservation of sesame's distinct flavor notes ¹⁷ .
Palm Fruit	130°C – 140°C	Extreme temperatures are necessary to liquefy the dense, semi-solid fats locked within the fibrous pulp of the palm fruit ¹⁷ .
Rapeseed / Canola	90°C – 110°C	Elevated temperatures lower viscosity, but overheating causes severe protein denaturation and negatively impacts the quality of the residual meal ¹⁸ .

Once the seeds are properly roasted and their lipid viscosity minimized, the material is prepared for the wedge press. In traditional operations, the hot, crushed seeds are tightly packed into specialized filtration envelopes. Historically, these consisted of tightly woven woolen or canvas bags, which were subsequently wrapped in heavy, leather-backed horsehair mats. This composite wrapping acts as an ultra-high-pressure filtration membrane; it permits the low-viscosity oil to percolate outward while providing immense tensile strength to prevent the pulverized seed cake from extruding or blowing out under the catastrophic internal pressures generated by the wedge⁸.

Architectural Geometry and Operational Cycle of the Wedge Mill

The structural backbone of the traditional wedge press is an monolithic timber component known as the main beam or base log. The physical dimensions of this timber must be vast to accommodate the internal hardware and survive the continuous outward radial pressures. Historical blueprints of 18th-century Dutch oil mills dictate the use of massive base logs measuring up to nine feet in length and twenty-seven inches square in cross-section⁸.

A deep, rectangular cavity, referred to as the trough, is mortised directly into the longitudinal center of this beam. The precision of this mortise is critical, as its vertical end-grain shoulders serve as the ultimate abutments against which the entire compressive force of the system is brought to bear. The physical components are loaded into this trough in a strict geometric sequence designed to maximize energy transfer and facilitate extraction⁸.

Positioned at the extreme ends of the trough, bearing directly against the mortise shoulders, are the seed packets housed within their horsehair mats. Adjacent to these packets, heavy iron

plates are inserted. In sophisticated historical setups, these iron plates were pre-heated in a dedicated furnace prior to assembly; their thermal mass served to maintain the elevated temperature of the seed cake throughout the lengthy pressing cycle, actively combating the cooling of the oil and the subsequent rise in viscosity⁸.

The central void of the trough is subsequently packed with a highly specific arrangement of solid timber components. Thick, solid blocks of end-grain hardwood, known as spacer blocks, are inserted to consume the excess volume and act as rigid force-transmission mediums⁸. The active mechanical components consist of two distinct wedges. The primary active component is the pressing wedge, or driving wedge, which is oriented with its acute point facing downward. The secondary component is the releasing wedge, an inverted wedge oriented with its wide base facing downward.

The operational cycle relies on alternating kinetic impacts. Heavy wooden stamping poles, suspended vertically above the press, are utilized as kinetic projectiles. The press operator engages the lifting mechanism—historically a cam rotating on a waterwheel-driven main shaft—which repeatedly raises the primary stamping pole and allows it to free-fall onto the broad upper face of the downward-pointing pressing wedge⁸. As the pressing wedge is driven deeper into the trough, its inclined planes force the spacer blocks laterally outward. This lateral displacement violently compresses the seed bags against the iron plates and the immovable mortise shoulders⁸.

Modern industrial hydraulic and continuous screw presses operate by applying pressures ranging from 30 to 60 Megapascals (MPa) to the seed cake¹⁹. While the traditional wooden wedge press cannot match these peak dynamic pressures, it achieves comparable cellular rupture through the application of sustained static strain and prolonged dwell time. Following a sequence of forty to sixty heavy blows from the stamper, the pressing wedge is driven deeply into the trough, establishing a massive internal pressure gradient⁸. Because the wedge is mechanically self-locking, it remains permanently wedged in position without requiring continuous external force. The seed cake is held under this extreme compressive strain for several minutes, providing the necessary dwell time for the viscous oil to overcome the capillary resistance of the compressed fibers, exit the filtration bags, and trickle down into the collector pans situated beneath the main beam⁸.

As the oil evacuates the matrix, the volumetric footprint of the seed cake physically shrinks, resulting in a gradual drop in internal pressure. The operator responds by re-engaging the primary stamper, driving the wedge further down to restore peak pressure, and repeating the cycle until the oil yield ceases. Once extraction is complete, the immense stored elastic energy within the compressed wooden blocks and the residual seed cake must be safely dissipated. The operator engages a secondary stamping pole positioned above the inverted releasing wedge. Striking the releasing wedge downward instantly collapses its effective horizontal width, breaking the mechanical lock, relieving the tremendous static pressure within the trough, and allowing the operator to safely disassemble the components and extract the dense, solid discs of defatted press cake⁸.

Classical Mechanics and Kinematics of the Wedge

System

To engineer this apparatus effectively, one must quantify the conversion of vertical kinetic energy into horizontal compressive force. A wedge is fundamentally a mobile, double-inclined plane. It bypasses the limitations of direct human or animal strength by trading a large vertical displacement for a minuscule, yet exponentially more powerful, horizontal displacement⁸.

The physics governing the operation begin with the generation of kinetic energy by the falling stamper. The energy delivered to the top of the wedge is dictated by the law of conservation of energy, where the gravitational potential energy of the raised stamper is entirely converted into kinetic energy (E_k) at the exact moment of impact²³:

$$E_k = m \cdot g \cdot h$$

In this equation, m represents the mass of the stamper in kilograms, g is the standard acceleration due to gravity (9.81 m/s^2), and h is the drop height in meters. For an industrial-scale traditional press utilizing a 150-kilogram oak stamper dropped from a cam-lifted height of 1.2 meters, the kinetic energy generated per strike is approximately 1,765 Joules.

Upon striking the wedge, this kinetic energy performs physical work. The work-energy theorem states that Work is equal to the average force (F_{avg}) multiplied by the distance (d) over which that force is applied²³:

$$F_{avg} = \frac{E_k}{d}$$

During the initial stages of pressing, the seed cake is relatively fluffy and compressible, resulting in a large vertical displacement (d) of the wedge per blow and a correspondingly low average impact force. However, as the seed cake reaches terminal density, the system becomes highly inelastic. The downward displacement (d) per blow shrinks to microscopic fractions of a millimeter. Consequently, the instantaneous average vertical force (F_{avg}) spikes exponentially, translating the 1,765 Joules of kinetic energy into hundreds of kilonewtons of transient vertical driving force.

This vertical force must then be redirected laterally. The theoretical mechanical advantage (MA) of an idealized, frictionless wedge is determined solely by its geometry, specifically the ratio of its penetration length to its maximum width²⁵. An acute wedge with a long length and a

narrow width provides a massive theoretical multiplier. However, in applied statics, frictional forces entirely dominate the mechanical reality of the press²².

The actual lateral output force (W) applied to the seed cake by the vertical input force (P) delivered by the stamper is governed by the simultaneous static equilibrium of the wedge and the adjacent spacer blocks. Assuming a symmetrical wedge defined by a half-angle α , and assuming a uniform coefficient of static friction μ_s across all interacting wooden surfaces, the complex relationship is defined by the following equilibrium equation derived from the resolution of normal and frictional vectors²²:

$$P = W \left[\frac{2\mu_s \cos \alpha + (1 - \mu_s^2) \sin \alpha}{\cos \alpha - 2\mu_s \sin \alpha} \right]$$

This mathematical relationship reveals that the horizontal compressive force W is highly sensitive to both the wedge angle α and the coefficient of friction μ_s . To maximize W for a given stamper impact P , the press engineer must utilize the narrowest possible wedge angle. A narrower angle geometrically forces the denominator of the equation to shrink, exponentially increasing the lateral force multiplier, thereby achieving the extreme internal pressures required to rupture the oilseed cell walls¹¹.

Tribological Dynamics and Boundary Lubrication

While a highly acute wedge angle maximizes crushing force, it introduces the most critical failure mode in wedge press engineering: the loss of the self-locking condition. When the stamper is lifted by the cam mechanism to prepare for the next blow, the vertical driving force P drops to zero. Simultaneously, the intensely compressed seed cake acts as a massive mechanical spring, exerting immense reactive lateral pressure against the spacer blocks, which in turn attempt to squeeze the driving wedge upward and violently eject it from the press²¹. The only force preventing this catastrophic ejection is static friction. According to Coulomb's

Law of Dry Friction, the maximum static frictional force F resisting motion is the product of the coefficient of static friction μ_s and the normal force N pressing the surfaces together²². The fundamental physics of wedges dictate a critical parameter known as the angle of friction ϕ , which represents the steepest angle at which the resultant of the normal and friction forces can act relative to the surface normal²². The angle of friction is mathematically defined as:

$$\phi = \tan^{-1}(\mu_s)$$

For the wedge press to safely function, it must be inherently "self-locking." This condition dictates that the frictional forces alone must be sufficient to counteract the reactive lateral ejection forces without requiring any external vertical holding pressure. For a wedge to be self-locking, the angle of friction ϕ must strictly exceed the geometric half-angle α of the wedge²²:

$$\alpha < \phi$$

If the wedge angle α is engineered to be larger than the friction angle ϕ , the wedge will instantly and violently shoot upward out of the trough upon the removal of the stamper, resulting in a total loss of extraction pressure and presenting a lethal kinetic hazard to the press operators²⁷.

In general structural timber engineering, meeting the self-locking criteria is relatively simple because dry wood possesses a high coefficient of friction. For example, the static friction coefficient (μ_s) for clean, dry oak sliding on oak parallel to the grain is highly resistive, measured empirically at 0.62³¹.

$$\phi_{dry} = \tan^{-1}(0.62) \approx 31.8^\circ$$

Under dry conditions, a wedge with a half-angle of up to 30 degrees would remain securely locked. However, an oil press presents a fundamentally altered tribological environment. As the cell walls of the seeds rupture and the lipid fractions are expressed, the vegetable oil permanently saturates every wooden surface within the trough. Vegetable and seed oils possess low surface energies and act as highly efficient boundary lubricants³⁴.

Tribological laboratory studies evaluating the friction dynamics of wood coated with natural vegetable oils demonstrate a catastrophic drop in frictional resistance. The static friction coefficient for heavily oil-impregnated wood drops from 0.62 down to a range of 0.35 to 0.39³⁴. Recalculating the self-locking condition for the lubricated state reveals the severe geometric constraints imposed on the press designer:

$$\phi_{lubricated} = \tan^{-1}(0.35) \approx 19.2^\circ$$

Therefore, to ensure absolute, fail-safe self-locking functionality in a perpetually oil-saturated environment, the wedge half-angle α must never exceed 19 degrees. To provide a rigorous engineering margin of safety against the dynamic shockwaves and vibrations induced by the stamping poles, the wedge half-angle is typically restricted to an acute 10 to 12 degrees (resulting in a total wedge taper of 20 to 24 degrees)³⁰. This highly acute geometry guarantees that the press remains locked under maximum strain, but it also necessitates the use of exceptionally long wedges to achieve the required total lateral displacement.

Orthotropic Timber Engineering and Eurocode 5 Verification

The immense lateral forces generated by the 10-degree wedge place extreme mechanical demands on the wooden body of the main beam. Wood is a profoundly orthotropic material, possessing mechanical properties that differ drastically along three mutually perpendicular axes: the longitudinal axis (parallel to the grain), the radial axis, and the tangential axis (perpendicular to the grain)³⁸. To guarantee the structural survivability of the press, its geometry and material selection must be rigorously verified against modern timber engineering standards, specifically the protocols outlined in Eurocode 5 (EN 1995-1-1)⁴⁰.

Verification of Compression Perpendicular to the Grain ($f_{c,90,k}$)

The primary and most frequent mode of catastrophic failure in a heavy-duty wedge press is localized crushing perpendicular to the grain. As the wedge descends, it drives the spacer blocks laterally outward. This lateral force is transmitted directly into the vertical side walls of the mortised trough. When timber is subjected to intense compression perpendicular to the grain, the microscopic, tubular cell walls—primarily the tracheids and vessels—undergo severe plastic buckling and eventually collapse entirely, offering a fraction of the load-bearing resistance observed when the timber is loaded parallel to the grain⁴⁰.

Eurocode 5 strictly governs this failure mode, dictating that the design compressive stress ($\sigma_{c,90,d}$) acting on the mortise walls must not exceed the design compressive strength of the timber ($f_{c,90,d}$), modified by a critical enhancement factor known as $k_{c,90}$ ⁴².

$$\sigma_{c,90,d} \leq k_{c,90} \cdot f_{c,90,d}$$

The $k_{c,90}$ parameter is introduced to account for the specific load configuration, the geometric risk of splitting, and the degree of acceptable compressive deformation before ultimate failure⁴⁰. In the specific geometry of the oil press, the lateral force acts as a concentrated block load against the continuous inner face of the main beam. Because the highly stressed timber fibers directly beneath the spacer blocks are flanked by unstressed, continuous fibers along the remainder of the beam, these adjacent fibers act as tension

members, providing a reinforcing phenomenon commonly referred to as the "rope effect"⁴⁰.

This phenomenon artificially increases the effective contact area (A_{ef}) and permits the use of a $k_{c,90}$ multiplier greater than 1.0—typically up to 1.5 for hardwoods resting on continuous supports, provided the overhang lengths are sufficient⁴⁰.

Despite this mathematical enhancement, the baseline characteristic compressive strength perpendicular to the grain ($f_{c,90,k}$) for standard construction softwoods, such as structural spruce or pine, is dangerously low, hovering between 2.0 and 2.7 MPa⁴⁹. Because the internal lateral pressure exerted by the compacted seed cake routinely exceeds 15 MPa to achieve fluid expression, attempting to construct the main beam of the press from softwood will result in the immediate, catastrophic crushing of the mortise shoulders⁵¹. Therefore, the utilization of an ultra-high-density hardwood is an absolute structural necessity. Hardwoods inherently exhibit $f_{c,90,k}$ values approximately three times higher than their softwood counterparts due to their densely packed cellular matrices, significantly thicker secondary cell walls, and higher ratios of structural lignin⁴⁰.

Shear Capacity ($f_{v,k}$) and Fracture Mechanics

Beyond localized crushing, the outward lateral expansion of the wedge places the entire length of the main beam under extreme longitudinal shear stress. Structurally, the mortised trough acts as a massive, deep notch in the center of the beam. According to the structural mechanics detailed in Eurocode 5 (Section 6.5.2), notches induce severe, localized stress concentrations that serve as the focal points for rapid crack propagation and devastating cleavage failures along the grain lines⁴³.

When the spacer blocks push laterally against the end-grain shoulders of the trough, the force attempts to shear a massive rectangular block of wood directly out of the center of the beam.

The design must verify that the induced design shear stress (τ_d) remains below the timber's design shear strength ($f_{v,d}$), heavily modified by the notch reduction factor (k_v) to account for the stress concentration at the internal corners⁴⁷.

$$\tau_d \leq k_v \cdot f_{v,d}$$

Furthermore, this lateral force exerts a wedge-splitting action that attempts to pry the beam apart longitudinally. In advanced orthotropic fracture mechanics, the structural integrity of the beam relies entirely on the material's resistance to Mode I fracture, quantified by the *energy release rate* required to initiate and propagate a crack through the anisotropic cellular structure⁵⁶. To counter these immense shear and splitting forces, historical Dutch press designers intentionally utilized massive excess cross-sectional timber areas extending far behind the mortise trough. To further elevate the energy release rate threshold, the outer

dimensions of the wooden beam were frequently bound in heavy, shrink-fitted wrought-iron hoops. These hoops provided active structural confinement, drastically increasing the timber's resistance to tension perpendicular to the grain⁴⁵.

Cyclic Impact Fatigue and Hysteretic Degradation

A defining characteristic of the traditional wedge press is that the immense loads are not applied smoothly or statically; they are generated through violent, repeated kinetic impacts. The continuous pounding of the heavy stamping poles introduces profound cyclic fatigue into the cellular matrix of the timber. While wood exhibits remarkable resilience to low-cycle fatigue, the repeated application of extreme high-strain impact loads causes the gradual, insidious accumulation of microscopic fractures within the fiber walls⁵⁹.

When timber is subjected to cyclic compression parallel to the grain—a stress state experienced continuously by both the wooden stamper and the vertical driving wedge—the repeated yielding causes the formation of microscopic compression kinks in the cellulose microfibrils. Over thousands of cycles, these localized kinks propagate and coalesce into visible macroscopic creases, ultimately resulting in the complete mechanical crushing and broom-like splintering of the cell ends⁶².

Furthermore, cyclic loading in a viscoelastic, porous material like wood invariably results in hysteretic energy loss⁶³. The area enclosed within the stress-strain hysteresis loop represents mechanical energy that is permanently dissipated as heat during each loading cycle. Under high-frequency cyclic loading (such as modern ultrasonic fatigue testing or high-speed rotary machinery), this hysteresis causes a massive localized temperature spike within the timber, rapidly degrading the lignin binder and accelerating mechanical failure⁶². Fortunately, the traditional wedge press operates at extremely low frequencies. The manual or waterwheel-driven lifting of the stamping pole typically limits impacts to a frequency of 0.1 to 0.5 Hertz⁶². This vast duration between impacts allows the trace thermal energy generated by hysteresis to dissipate harmlessly into the ambient environment, preventing thermal breakdown. Nevertheless, to survive the cumulative mechanical damage over a commercial lifespan, the press components must be fabricated from a hardwood species exhibiting exceptional impact toughness (measured in kilojoules per square meter) and towering fatigue limits.

Metallurgical-Equivalent Hardwood Selection

To satisfy the extreme, concurrent demands of parallel and perpendicular compressive strength, towering longitudinal shear capacity, and unwavering cyclic impact resistance, the meticulous selection of the hardwood species is the paramount engineering decision in the construction of the press. Based on the rigorous strength classifications outlined in EN 338 and advanced mechanical property testing protocols, three primary European deciduous species are traditionally evaluated for heavy industrial applications: White Oak (*Quercus petraea*), European Beech (*Fagus sylvatica*), and European Hornbeam (*Carpinus betulus*)⁶⁶.

Comparative Mechanical Data Matrix

Structural	White Oak	European Beech	European
------------	-----------	----------------	----------

Property / Parameter	(<i>Quercus petraea</i>)	(<i>Fagus sylvatica</i>)	Hornbeam (<i>Carpinus betulus</i>)
Density (Air Dry, ρ_k)	0.67 – 0.75 g/cm ³	0.70 – 0.74 g/cm ³	0.74 – 0.83 g/cm ³
Compressive Strength Parallel ($f_{c,0,k}$)	54 – 66 MPa	55 – 62 MPa	68 – 85 MPa
Compressive Strength Perpendicular ($f_{c,90,k}$)	$\approx$ 10 – 11 MPa	$\approx$ 10 – 12 MPa	$\approx$ 13 – 15 MPa
Modulus of Elasticity (MOE)	11,300 – 13,500 MPa	14,000 – 16,000 MPa	12,200 – 17,700 MPa
Brinell Hardness (Perpendicular)	26 – 31 N/mm ²	34 – 38 N/mm ²	33 – 45 N/mm ²
Impact Bending Strength	60 – 70 kJ/m ²	78 – 82 kJ/m ²	60 – 89 kJ/m ²
Shear Strength Parallel to Grain ($f_{v,k}$)	11 – 13 MPa	12 – 14 MPa	14 – 16 MPa

(Note: Data values represent aggregated engineering ranges evaluated at a standardized 12% to 15% equilibrium moisture content⁶⁸).

The Biomechanical Superiority of Hornbeam (*Carpinus betulus*)

While Oak provides unparalleled natural resistance to fungal decay, and Beech offers excellent elasticity and high impact strength, an analysis of the mechanical data reveals that European Hornbeam emerges as the unequivocal, optimal selection for the fabrication of a heavy-duty wooden wedge press.

Hornbeam possesses the absolute highest density among native European diffuse-porous hardwoods, routinely exceeding 0.76 g/cm^3 and reaching up to 0.83 g/cm^3 ⁶⁸. Its compressive strength parallel to the grain approaches a staggering 85 MPa, allowing the physical wedges and stampers to resist catastrophic crushing. Most critically for the main beam, Hornbeam's compressive strength perpendicular to the grain significantly outperforms both oak and

beech⁶⁸. This exceptional $f_{c,90,k}$ value guarantees that the mortise shoulders of the main beam can absorb the extreme, localized crushing forces generated by the laterally expanding wedges without yielding or plastically deforming over time.

Furthermore, Hornbeam is highly renowned in historical timber framing and wheelwrighting for its complex, interlocked grain structure. Unlike straight-grained softwoods or easily cleaved, ring-porous hardwoods, the interlocked and deeply integrated cellulose fibrils of Hornbeam

provide an extraordinarily high fracture toughness and unparalleled shear strength ($f_{v,k}$)⁶⁹.

This structural anomaly makes the wood remarkably resistant to the severe splitting forces and stress concentrations induced by the wedge-action within the deep mortise notch. Due to these extreme mechanical properties, historical millwrights explicitly reserved Hornbeam for the most highly stressed mechanical components, such as gear wheels, heavy levers, mill cogs, and specifically, pressing wedges and stampers, earning it the highly accurate colloquial moniker "ironwood"⁷².

When Hornbeam components are subjected to the brutal, cyclic pounding inherent to the oil extraction process, its high impact bending strength—measuring up to 89 kJ/m^2 —allows the cellular matrix to absorb the violent kinetic energy of the stamper without suffering rapid cyclic fatigue failure or catastrophic brittle fracture⁶⁸. Its supreme Brinell surface hardness, peaking at 45 N/mm^2 , ensures that the acute impact faces of the wedges do not rapidly deform, flatten, or "mushroom" under repetitive strikes, thereby permanently preserving the highly specific geometric angles required to maintain the mechanical advantage and the critical self-locking condition⁶⁸. Under the Eurocode 5 material strength classifications, high-grade Hornbeam readily satisfies the requirements for the elite D60 or D70 strength classes, placing it at the absolute pinnacle of structural timber capabilities⁶⁶.

Physiochemical Effects of Deep Oil Impregnation on Hornbeam Timber

A highly nuanced, third-order dynamic in the long-term operation of a traditional wooden oil press is the inevitable, deep internal impregnation of the structural timber by the extracted vegetable oil. As established previously, this saturation poses a severe tribological challenge by drastically lowering the coefficient of static friction, necessitating highly acute wedge geometries³⁴. However, this deep lipid penetration also provides several profound, highly beneficial mechanical and physiochemical enhancements to the Hornbeam timber.

First, the infusion of oil radically improves the dimensional stability of the press. Wood is an inherently hygroscopic material that relentlessly swells and shrinks in response to fluctuations in ambient atmospheric humidity. When the dense Hornbeam is deeply impregnated with

extracted lipids—such as linseed, rapeseed, or walnut oil—the hydrophobic oil molecules physically occlude the cellular pits and coat the highly reactive hydroxyl groups within the cellulose matrix⁷⁹. This permanent hydrophobic barrier dramatically reduces the timber's capacity for moisture absorption. Empirical testing demonstrates that deep impregnation with drying oils, such as linseed oil, reduces the swelling coefficients in both the tangential and radial directions by 25% to 33%⁷⁹. By locking the timber into a state of permanent dimensional stability, the oil prevents the development of microscopic shrinkage checks (cracks) that frequently occur during dry seasons. Preventing these checks is absolutely vital, as any internal crack serves as a severe stress riser that significantly lowers the energy release rate threshold and accelerates shear failure along the grain⁷⁹.

Second, the impregnation of dense, viscous oil into the microscopic cellular voids of the timber noticeably increases the internal dampening coefficient of the wood. When the stamper strikes the wedge, the resulting high-frequency acoustic shockwaves propagate violently through the press structure. The viscoelastic nature of the oil-saturated cellular matrix acts as an acoustic shock absorber, dampening the vibrational transmission and dissipating the kinetic energy as trace amounts of thermal energy, thereby actively protecting the rigid structural integrity of the main beam from long-term acoustic fatigue⁶².

Finally, the continuous boundary lubrication provided by the penetrating oil virtually eliminates the destructive effects of abrasive mechanical wear between the sliding faces of the driving wedge and the spacer blocks³⁵. In a dry friction scenario, the massive lateral compressive loads would cause the wood fibers on the wedge faces to aggressively tear, splinter, and gall against one another, rapidly destroying the geometry of the tool. However, in the oil-saturated environment of the press trough, the heavily loaded timber elements glide smoothly past one another on a microscopic, incompressible hydrodynamic film. This ensures the longevity of the moving parts and maintains the precise, acute taper angle required for safe and effective operation over thousands of pressing cycles.

Conclusion

The engineering, construction, and operation of a heavy-duty traditional wooden wedge press represents a highly sophisticated, multi-disciplinary manipulation of physical forces, brilliantly conceived to bypass the limitations of pre-industrial power generation. By exploiting the static mechanical advantage of the double-inclined plane, the press architecture seamlessly translates the high-velocity vertical kinetic energy of a falling stamper into immense, sustained lateral compressive forces. These forces, often equating to tens of Megapascals of internal pressure, are precisely what is required to overcome the structural limits of thermally pre-treated, roasted oilseeds, rupturing their cellular membranes and expressing their valuable lipid contents.

A rigorous mathematical analysis of the system's kinematics dictates that to maintain a safe, self-locking state within a heavily oil-lubricated environment, the half-angle of the wedge must be kept highly acute—strictly below 19 degrees, and practically engineered between 10 and 12 degrees—to compensate for the drastic, lubrication-induced drop in the static friction coefficient. Furthermore, evaluating the catastrophic internal stresses via the rigorous protocols of Eurocode 5 reveals that the intense compression perpendicular to the grain,

coupled with severe longitudinal shear stresses and relentless cyclic impact fatigue, far exceeds the structural capacity of standard construction timbers.

Therefore, the successful execution of this design dictates the exclusive use of supreme-density, interlocked-grain hardwoods. European Hornbeam (*Carpinus betulus*) stands as the optimal metallurgical-equivalent material for this demanding application. Its unmatched perpendicular compressive strength, extreme Brinell surface hardness, and profound resistance to splitting ensure that both the main beam and the active wedges can withstand decades of immense hydrodynamic pressure and cyclic pounding, effectively cementing the traditional wooden wedge press as a marvel of organic material science and heavy industrial extraction kinetics.

Works cited

1. The History And Cultural Significance Of Wood-Pressed Oils, <https://aorganicum.com/blogs/news/the-history-and-cultural-significance-of-wood-pressed-oils>
2. Ghani: A traditional method of oil processing in India, <https://www.fao.org/4/t4660t/t4660t0b.htm>
3. The Traditional Process of Making Wooden Pressed Oils - PIP AGRO, <https://pipagro.com/blogs/globo-menu-blog/the-traditional-process-of-making-wooden-pressed-oils-step-by-step>
4. A Brief History of Olive Oil Milling, <https://oliveoilprofessor.com/blog/a-brief-history-of-olive-oil-milling>
5. Biblical Olive Press: Ancient Oil-Making Craft | Kfar Kedem, <https://www.kfar-kedem.com/the-olive-press>
6. 1500-Year-Old Chinese Oil Pressing Technique in Action! - YouTube, https://www.youtube.com/shorts/2DURB9_vbbA
7. Old-School Oil Pressing - YouTube, <https://www.youtube.com/shorts/9nyBE1yjG7k>
8. In-Depth Articles - Technology of the Oil Mill Industries, https://www.engr.psu.edu/mtah/articles/technology_oilmill.htm
9. Technology | Encyclopedia.com, <https://www.encyclopedia.com/science-and-technology/technology/technology-terms-and-concepts/technology>
10. Oilseeds preparation & pressing - Desmet, <https://www.desmet.com/en/feed/oilseeds-preparation-pressing>
11. Research on Mechanical-Structural and Oil Yield Properties during, <https://www.mdpi.com/2227-9717/10/3/564>
12. Oil Pressing and Extraction | Nored Farms, <https://noredfarms.com/articles/oil-pressing.html>
13. mechanical oil expression from selected oilseeds, <https://www.collectionscanada.gc.ca/obj/s4/f2/dsk3/ftp04/nq24003.pdf>
14. Leading Edge Technologies and Perspectives in Industrial Oilseed, <https://pmc.ncbi.nlm.nih.gov/articles/PMC10459726/>
15. Industrial Oilseed Extraction | Encyclopedia MDPI, <https://encyclopedia.pub/entry/48281>

16. Oil and Oilseed Processing II - Oklahoma State University Extension,
<https://extension.okstate.edu/fact-sheets/oil-and-oilseed-processing-ii>
17. Guide To Hot Pressing Temperatures For Oil Extraction From Crops.,
<https://smallagrimachinery.com/blog/guide-to-hot-pressing-temperatures-for-oil-extraction-from-crops/>
18. Optimizing Rapeseed Oil Production Yield and Process Efficiency,
<https://www.oilmillmachinery.net/how-is-rape-seed-oil-made/rape-seed-oil-production-yield-optimization/>
19. How Is Rapeseed Oil Made: Mechanical Pressing Principles and,
<https://www.oilmillmachinery.net/how-is-rape-seed-oil-made/rape-seed-oil-press-production-design/>
20. Mechanical Continuous Oil Expression from Oilseeds: A Review,
https://www.researchgate.net/publication/257764105_Mechanical_Continuous_Oil_Expression_from_Oilseeds_A_Review
21. 9.3 Wedges - Engineering Statics,
https://engineeringstatics.org/Chapter_09-block-and-wedge-friction.html
22. Friction Applications — Analyze wedges, belts, and ... - Varsity Tutors,
<https://www.varsitytutors.com/practice/subjects/statics-and-dynamics/lessons/friction-applications>
23. Falling Object Impact Force Calculator - DROPS Forum,
<https://www.dropsforum.org/falling-object-impact-calculator>
24. How much force in a sledgehammer being swung from overhead?,
https://www.reddit.com/r/AskPhysics/comments/1l1rou0/how_much_force_in_a_sledgehammer_being_swung_from/
25. Mechanical Advantage Calculator,
<https://www.omnicalculator.com/physics/mechanical-advantage>
26. The Wedge Mechanism Explained: How It Works, Formula, Diagram,
<https://www.firgelliauto.com/blogs/mechanisms/the-wedge>
27. Analyze wedges and belt friction (intro) - Varsity Tutors,
<https://www.varsitytutors.com/practice/subjects/statics/lessons/wedges-and-belt-friction>
28. Understanding Friction in Engineering | PDF - Scribd,
<https://www.scribd.com/document/528634875/Module-4>
29. Comparison of the Mechanical Behaviour of Selected Oilseeds,
<https://www.notulaeobotanicae.ro/index.php/nbha/article/download/7444/7016/0>
30. SECTION B APPLICATIONS OF FRICTION IN MACHINES 6/4 Wedges,
https://www.uomus.edu.iq/img/lectures21/MUCLecture_2022_82059406.pdf
31. Friction - Coefficients for Common Materials and Surfaces,
https://www.engineeringtoolbox.com/friction-coefficients-d_778.html
32. Coefficient of Friction for Metals and Materials | Table & Calculator,
<https://us.misumi-ec.com/blog/coefficient-of-friction/>
33. The Comparison of Static Friction Coefficient on Wood Between the,
https://www.researchgate.net/publication/330963114_The_Comparison_of_Static_Friction_Coefficient_on_Wood_Between_the_Combination_of_Wood-Metal_Load_System_and_Wood-Sand_Load_System

34. Friction parameters of woods treated with vegetable oil 1 and,
https://www.researchgate.net/figure/Friction-parameters-of-woods-treated-with-vegetable-oil-1-and-polyurethane-2-and-of_fig2_356020103
35. (PDF) Friction Dynamics of Wood Coated with Vegetable Oil,
https://www.researchgate.net/publication/356020103_Friction_Dynamics_of_Wood_Coated_with_Vegetable_Oil
36. Friction Dynamics of Wood Coated with Vegetable Oil - PubMed,
<https://pubmed.ncbi.nlm.nih.gov/34759113/>
37. Shaft hub connections in mechanical engineering - Felss,
<https://felss.com/en/blog/shaft-hub-connections-in-mechanical-engineering-technologies-comparison-and-standards/>
38. Compression Strength of Oak and Ash Wood Perpendicular to Grain,
https://www.researchgate.net/figure/Strength-of-oak-and-ash-wood-compressed-perpendicular-to-grain-MPa_tbl1_268352965
39. Perpendicular/parallel ratio of some mechanical properties of timber.,
https://www.researchgate.net/figure/Perpendicular-parallel-ratio-of-some-mechanical-properties-of-timber_fig3_237714629
40. Compressive Strength Properties Perpendicular to the Grain ... - MDPI,
<https://www.mdpi.com/2073-4360/14/16/3403>
41. CLT (X-LAM) THEORY AND DESIGN GUIDE - AXISVM,
https://download.axisvm.eu/manual/axisvm_clt_guide_en.pdf
42. Compression perpendicular to the grain Summary 1. Introduction 2,
<https://publikationen.bibliothek.kit.edu/1000002867/685544>
43. Eurocode 5: Timber Structures Design | PDF | Screw - Scribd,
<https://www.scribd.com/document/708925492/Borrador-Eurocodigo-20XX>
44. Compression Perpendicular to Grain Guide | SPEC Toolbox,
<https://spectoolbox.com/compression-perpendicular-to-grain/>
45. ESSAY 2.1 HJ Larsen Compression perpendicular to grain - CIB-W18,
https://cib-w18.com/sites/default/files/styles/pdf_small/public/sites/default/files/pdfs/6%20Essays.pdf
46. The Problem of Compressive Strength in Direction Perpendicular to,
https://www.researchgate.net/publication/339755430_The_Problem_of_Compressive_Strength_in_Direction_Perpendicular_to_the_Grains_on_Example_of_Tests_of_the_Load-Bearing_Capacity_of_the_Continuously_Supported_Timber-Frame_Sill_Plates
47. Timber Beam Design Example per Eurocode 5 | PDF - Scribd,
<https://www.scribd.com/document/544424551/HESAP-O-RNEG-I>
48. AxisVM Timber Design Summary,
http://www.axisvm.co.uk/up-demo-docs/English/Documents/timber_design_summary.pdf
49. NUMERICAL ANALYSIS OF COMPRESSION PERPENDICULAR,
<https://www.byggmek.lth.se/fileadmin/byggnadsmekanik/publications/tvsm5000/web5181.pdf>
50. Structural Wood Strength Capacities According To Eurocode,
<https://www.structuralbasics.com/structural-wood-strength-capacities/>

51. The Problem of Compressive Strength in Direction Perpendicular to,
<https://pmc.ncbi.nlm.nih.gov/articles/PMC7085190/>
52. Define a Beam with a Notch at the Support_5,
https://www.graitec.com/Help/Advance_Design/En/beam-notch-support_5.htm
53. Connections in Timber Reciprocal Frames,
<https://publications.lib.chalmers.se/records/fulltext/243237/243237.pdf>
54. Calculation For Shear Strength in A Timber Beam With A Notch at Its,
<https://www.scribd.com/document/150123892/Calculation-for-Shear-Strength-in-a-Timber-Beam-With-a-Notch-at-Its-Lower-Side-Where-It-is-Supported>
55. EN 1995-1-1 Timber Checks,
https://download.infograph.de/man_en/en1995_timber_checks.pdf
56. Energy release rate (fracture mechanics) - Wikipedia,
[https://en.wikipedia.org/wiki/Energy_release_rate_\(fracture_mechanics\)](https://en.wikipedia.org/wiki/Energy_release_rate_(fracture_mechanics))
57. Estimation of fracture toughness and shear yield stress of orthotropic,
https://mostwiedzy.pl/pl/publication/download/1/estimation-of-fracture-toughness-and-shear-yield-stress-of-orthotropic-materials-in-cutting-with-rot_2378.pdf
58. Failure in tension perpendicular to grain in timber joint.,
https://www.researchgate.net/figure/Failure-in-tension-perpendicular-to-grain-in-timber-joint_fig1_268326009
59. FATIGUE OF TIMBER CONNECTIONS: A REVIEW OF FAILURE,
<https://www.proceedings.com/content/080/080513-0419open.pdf>
60. numerical modeling of the fatigue strength of timber joint,
<https://www.ceer.com.pl/pdf-205779-126944?filename=126944.pdf>
61. determination of fatigue and static strength of scots pine and beech,
<https://www.centrumdp.sk/wr/201504/16.pdf>
62. Fatigue properties of wood at different load ratios tested at 50 Hz,
<https://d-nb.info/1254130705/34>
63. Fatigue and hysteresis effects in wood-based panels under cyclic,
<https://scispace.com/pdf/fatigue-and-hysteresis-effects-in-wood-based-panels-under-3aypu0cald.pdf>
64. Fatigue and damage evolution in wood T-shaped mortise and tenon,
<https://pmc.ncbi.nlm.nih.gov/articles/PMC11401834/>
65. Fatigue treatment of wood by high-frequency cyclic loading,
<https://www.tappi.org/content/events/07impc/07impc40.pdf>
66. Determination of the Properties of Some Selected Timber Species,
https://www.researchgate.net/publication/370918636_Determination_of_the_Properties_of_Some_Selected_Timber_Species_for_Structural_Application
67. Architect's Pocket Book (Routledge Pocket Books ... - dokumen.pub,
<https://dokumen.pub/architects-pocket-book-routledge-pocket-books-6nbsped-1032414111-9781032414119.html>
68. Holzarten ABC - Berlin - Holz Possling,
<https://www.possling.de/holzarten-abc.php>
69. PROPERTIES OF HORNBEAM (Carpinus betulus) WOOD,
<https://df.tuzvo.sk/sites/default/files/03-02-19.pdf>
70. Selected Properties of Densified Hornbeam and Paulownia Wood,

- <https://pmc.ncbi.nlm.nih.gov/articles/PMC9324522/>
71. (PDF) The density, compression strength and surface hardness of,
https://www.researchgate.net/publication/251071448_The_density_compression_strength_and_surface_hardness_of_heat_treated_hornbeam_Carpinus_betulus_wood
 72. Comparative Investigation of Physical and Mechanical Properties of,
<https://www.drewno-wood.pl/pdf-208616-143247?filename=Comparative-Investigation.pdf>
 73. (PDF) Physical and Mechanical Properties of Hornbeam Wood from,
https://www.researchgate.net/publication/324075693_Physical_and_Mechanical_Properties_of_Hornbeam_Wood_from_Dominant_and_Suppressed_Trees
 74. (PDF) Oven dry density of sessile oak, Turkey oak and hornbeam in,
https://www.researchgate.net/publication/296835684_Oven_dry_density_of_sessile_oak_Turkey_oak_and_hornbeam_in_different_region_of_Mecsek_Mountain
 75. process zone length and fracture energy of spruce wood in mode-I,
<https://wfs.swst.org/index.php/wfs/article/download/1689/1689>
 76. 27775848.pdf - Open Research Online,
<https://oro.open.ac.uk/63791/1/27775848.pdf>
 77. Surface Engineering of Woodworking Tools, a Review - MDPI,
<https://www.mdpi.com/2076-3417/12/20/10389>
 78. Allocation of Central European hardwoods into EN 1912,
https://www.irbnet.de/daten/iconda/CIB_DC34403.pdf
 79. efficacy of linseed oil-treated wood to improve,
<https://www.woodresearch.sk/cms/wp-content/uploads/2021/10/Efficacy-Of-Linseed-Oil-Treated-Wood-To-Improve-Hydrophobicity-Dimensional-Stability-And-Thermostability.pdf>
 80. Effects of Surface Roughness and Wood Grain on the Friction,
https://www.researchgate.net/publication/264865562_Effects_of_Surface_Roughness_and_Wood_Grain_on_the_Friction_Coefficient_of_Wooden_Materials_for_Wood-Wood_Frictional_Pair
 81. Decay resistance and dimensional stability of wood impregnated,
https://www.researchgate.net/publication/375278423_Decay_resistance_and_dimensional_stability_of_wood_impregnated_with_castor_oil_using_a_pressure_treatment
 82. Effects of Moisture Absorption on the Mechanical and Fatigue,
<https://www.mdpi.com/2073-4360/17/14/1996>